

Girder Type	Girder Spacing (ft)	Span Length (ft)	Cast-in-place Closures Length (ft)	PT Ducts - Strands/Duct (Duct#4 @ Bottom)				Jacking Force (kips)	Tendon Force after Seating (kips)	Tendon Loss (kips)	E1 (in)	E3 (in)
				1	2	3	4					
WF100PTG Post-tensioned Before Slab Casting	6	230	2	22	22	22	22	4000	3630	370	55	15
	8	210	2	22	22	22	22	4000	3630	400	55	15
	10	195	2	22	22	22	22	4000	3630	420	55	15
	12	185	2	22	22	22	22	4000	3630	460	55	15
	14	170	2	22	22	22	22	4000	3630	460	55	15
WF100PTG Post-tensioned After Slab Casting	6	255	2	22	22	22	22	4000	3560	440	55	15
	8	245	2	22	22	22	22	4000	3550	460	55	15
	10	235	2	22	22	22	22	4000	3540	460	55	15
	12	220	2	22	22	22	22	4000	3530	480	55	15
	14	210	2	22	22	22	22	4000	3520	500	55	15