

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22

DIVISION7.GR7

Drainage Structures, Storm Sewers, Sanitary Sewers, Water Mains, and Conduits

7-06.INST1.GR7

(Section 7-06 is revised to read)
Must use once preceding any of the following:

7-06.SA1.FR7

(Temporary Stream Diversion)
(January 2, 2018)
Use in all projects that require a temporary stream diversion.
Contact the HQ Hydraulics Office for fill-in information.
If a contingency system is required, use **7-06.SA2.FR7** instead.
(1 fill-in)

7-06.SA2.FR7

(Temporary Stream Diversion and Contingency System)
(January 2, 2018)
Use in all projects that require a temporary stream diversion and require a contingency system to supplement the flows conveyed by the primary temporary stream diversion.
Fill-in #1: Contact the HQ Hydraulics Office for fill-in information.
Fill-in #2: The fill-in shall include the combined flow of the primary and contingency systems in cubic feet.
(2 fill-ins)