

# **Maintenance Manual**

**M 51-01**  
**March 2002**



**Washington State**  
**Department of Transportation**

Maintenance & Operations



Persons with disabilities may request this information be prepared and supplied in alternate forms by calling the WSDOT ADA Accommodation Hotline collect (206) 389-2839. Persons with hearing impairments may access WA State Telecommunications Relay Service at TT 1-800-833-6388, Tele-Braille 1-800-833-6385, or Voice 1-800-833-6384, and ask to be connected to (360) 705-7097.

**Engineering Publications**

Washington State Department of Transportation  
PO Box 47408  
Olympia, WA 98504-7408  
E-mail: [willisr@wsdot.wa.gov](mailto:willisr@wsdot.wa.gov)


Phone: (360) 705-7430  
Fax: (360) 705-6861

<http://www.wsdot.wa.gov/fasc/EngineeringPublications/>


## FOREWORD

---

Reliable, well-maintained highway transportation facilities are essential to the well being of the state, its citizens, and its commerce. The Washington Department of Transportation's Maintenance and Operations personnel are essential to the state's transportation backbone – the state highway system. Public safety and the safety of our employees is a high priority and must be considered in every decision and activity affecting the highway facilities. The goal of Maintenance and Operations is to retain the highway system in a condition as near as possible to the condition of its initial construction or subsequent improvement. We all take pride in and strive for excellence in the maintenance and operations of our highway system.



Ken Kirkland  
State Maintenance Engineer



Brian Ziegler  
Director of Maintenance &  
Operations

## **Introduction**

### **Purpose of this Manual**

The purpose of this Maintenance Manual is to provide Maintenance personnel with guidance on how to conduct a wide variety of activities performed within the Maintenance Programs. The focus is on types of equipment, materials, techniques, and other information needed to properly carry out basic maintenance activities such as patching a pothole or removing snow from a roadway. Although this guidance does not establish absolute standards, it helps to promote uniform operating procedures and performance guidelines. Highway maintenance is carried out in a dynamic environment where varying factors can lead to different solutions to maintenance problems. Maintenance and Operations personnel need flexibility to match the appropriate solutions to different conditions. The Maintenance Manual is one of many resources that are available for trained maintenance personnel to utilize in applying their professional judgment to their daily work.

### **Performance Measurement**

The extent to which maintenance activities are conducted is primarily determined by the level of funding provided each biennium by the Washington State Legislature. By placing their trust, in the form of a two hundred fifty million dollar appropriation per biennium, both the Legislature and the public are expecting the Departments Maintenance organizations to deliver their program in a timely and efficient manner.

To better communicate the outcomes of the maintenance program, the Maintenance Accountability Program (MAP) has been developed and integrated into the Highway Maintenance Program. The MAP uses performance measures to communicate in easily understood terms the Level of Service (LOS) Maintenance delivers for various maintenance activities. A comprehensive MAP manual has been developed and is available for use by maintenance personnel. The MAP manual is available by visiting the Headquarters Maintenance organizations internet web site.

LOS is based on a letter-grade scale of "A" (highest level of funding) to "F" (lowest level of funding). The LOS for each activity is determined by conducting field condition assessments at highway locations randomly-selected throughout the state during the fall and spring of each year. The LOS targets, by MAP activity, are determined by statewide Maintenance staff utilizing both funding and Legislative guidance to provide the appropriate emphasis. Since uncontrollable factors such as winter weather, flood damage, and third-party damages can have a significant bearing on the LOS that is provided, it is highly probable that during the biennium some variations will occur between the targets and actual performance. The semi-annual surveys can be a valuable management tool for Maintenance Managers in not only allocating funds amongst various maintenance activities but also to adjust their work schedules to achieve LOS targets.

### **Environmental Responsibilities**

Just as we are entrusted with public monies to maintain the highway system, we are also entrusted with being good stewards of the public right-of-way associated with the highway system. As the population of Washington State continues to grow, the environmental value of the highway right-of-way and adja-



cent lands is also increasing. Whether the right-of-way or adjacent lands serve as habitat for burrowing owls, a conveyance for stormwater runoff into salmon-bearing streams, or as a haven for native plant species, it is reasonable to expect that the increasing environmental protection requirements will necessitate changes in how many maintenance activities are performed.

Many resources are available to assist maintenance personnel in conducting maintenance activities in compliance with environmental requirements. Several environmental guidance documents are available on the Headquarters Maintenance and Operations web site. Particularly applicable to specific maintenance activities is the WSDOT Maintenance Manual for Water Quality and Habitat Protection. This manual contains a number of best management practices that can be used for a variety of activities and/or conditions to ensure environmental compliance. Personnel are available in both the Headquarters Maintenance and Operations Office as well as Regional Environmental offices to assist in providing guidance on environmental issues. One of the most valued environmental resources that can be developed by maintenance personnel is a positive work relationship with local environmental regulators such as the Washington Department of Fish and Wildlife's Area Habitat Biologists. Such a positive work relationship will help maintenance personnel to not only deliver their program in a timely manner but to do so in conformance with environmental best practice methods.

## **Fiscal Management**

Sound fiscal management is a key ingredient in delivering the maintenance program in an effective and efficient manner. Once the biennial budget is distributed to region maintenance organizations it is essential that the expenditure for various activities be accurately documented. This is accomplished through the Departments labor collection and voucher processing systems which not only provide an expenditure record for each maintenance activity but also the detailed components that make up the cost, i.e., regular time, overtime, vendor services, materials, and equipment. By tracking the expenditure of activities Maintenance Managers are not only aware of the costs of doing business relative to targets but are better positioned to adjust their schedules to meet evolving problems and/or deliver their programs.

# **Environmental Policy Statement**

## **Washington State Department of Transportation**

**September 26, 2001**

The Department of Transportation acknowledges the state's vital interests in protecting and preserving natural resources and other environmental assets and its citizens' health and safety. These interests must be integrated with other vital interests committed to the Department, including the cost-effective delivery and operation of transportation systems and services that meet public needs.

The Department shall conduct all its affairs in accordance with the dictates of sound environmental protection practices, including pollution prevention wherever reasonably possible. The Department shall also avoid, minimize and appropriately mitigate adverse environmental impacts. These undertakings extend to the construction, maintenance and operation of its systems and facilities. Legal obligations in these matters are established by applicable laws and regulations; this Policy Statement is not intended to create further or additional legally-enforceable requirements.

To support the performance of the Department's responsibilities and undertakings, as Secretary of Transportation, I hereby commit the Department:

To implement and maintain an environmental management system that embraces all the Department's program functions;

To establish, maintain and make available to the public appropriate performance indicators of the Department's exercise of its environmental stewardship and to consistently review these indicators as a basis to improve the Department's performance;

To comply with all environmental laws and regulations applicable to our business and activities;


To assure that employees of the Department receive training appropriate to their functions concerning the Department's environmental responsibilities;

To communicate to contractors, designers, consultants and other participants in the Department's work the management practices and compliance requirements established to further the aims of this Policy Statement;

To encourage employees and all other citizens to communicate with the Department about ways to increase the effectiveness of Department's practices supporting its mission of environmental stewardship;

To make every reasonable effort to also protect the cultural and historic resources of the state.

Each employee of the Department is charged to exercise his or her responsibility on behalf of the Department to assure that the intentions of the Policy Statement are diligently carried out.



Douglas B. MacDonald  
Secretary of Transportation

---

**Chapter 1****Emergency Procedures**

---

	<b>Page</b>
General Responsibilities	1-2
Regional Emergency Response Plans	1-3
WSDOT Disaster Plan	1-3
Concepts of Operations	1-3
Organization and Assignment of Responsibilities	1-4
Administration and Logistics	1-4
Plan Development and Maintenance	1-4
Training and Exercises	1-4
Emergency Operating Procedures	1-5
General	1-5
Maintenance Field Personnel	1-5
Maintenance Superintendent or Supervisor	1-6
Abandoned Cargo	1-7
Clearing the Highway	1-7
Open Road Policy	1-7

---

**Chapter 2****Work Zone Traffic Control and Safety**

---

	<b>Page</b>
General	2-2
Fundamental Principles	2-2
Traffic Control Zones	2-3
Traffic Control Devices	2-4
Signs and Supports	2-4
Channelizing Devices	2-6
Cone Placement Procedure	2-6
Water and Concrete Barrier	2-7
Hand Signaling Devices	2-8
Lighting Devices	2-8
Traffic Control Procedures	2-9
Off-Road Activities	2-10
Nighttime Activities	2-10
Non-motorized Traffic Control	2-11
Pedestrian Control	2-11
Bicycle Control	2-11
Safety	2-12
Work Zone Operations	2-12
Enforcement	2-13
Resources for Traffic Control and Work Zone Safety	2-13

---

**Chapter 3****Pavement Patching & Repair**

---

	<b>Page</b>
General	3-3
Maintenance of Flexible Pavements	3-3
Load & Speed Restrictions	3-4
Pavement Deficiencies	3-4
Rutting	3-4
Alligator Cracking	3-4
Longitudinal Cracking	3-4
Transverse Cracking	3-5
Potholes	3-5
Raveling & Pitting	3-5
Flushing	3-5
Sags & Humps	3-6
Edge Raveling	3-6
Pavement Maintenance Techniques	3-6
Patching	3-6
Patching with Base Repair	3-6
Overlay Patches	3-8
Spreader Box Patching	3-8
Grader Patching	3-9
Rolling Hot Mix Patches	3-9
Effects on Traffic on a Patching Operation	3-11
Crack Sealing (or Pouring)	3-11
Hot Pour Method	3-11
Cold Pour Method	3-12
Maintenance of Rigid Pavements	3-12
Portland Cement Concrete Pavement Crack Pouring	3-12
Asphalt Emulsion Surface Treatments	3-15
Fog Seals	3-15
Sand Seal	3-15
Aggregate (Chip) Seal	3-16
Pavement Conditions for a Successful Project	3-16
Material Selection	3-16
Asphalts and Emulsions	3-16
Common Types of Emulsions Used for Chip Seals	3-17
Aggregate	3-17
Weather	3-17
Roadway Preparation	3-17
Equipment	3-18
Distributor	3-18

## **Contents**

---

	<b>Page</b>
Calibration Procedures	3-18
Nozzle Size	3-19
Proper Pressure	3-19
Spray Bar Height	3-22
Proper Nozzle Angle	3-23
Streaking Will Occur	3-23
Cleaning of Distributor	3-23
Checking the Bitumeter	3-23
Traffic Control	3-24
Application of Asphalt	3-24
Spreading Aggregate	3-25
Chipsreader Calibration	3-25
Chip Spreader	3-26
Rolling	3-26
Spreading of Fines or Choking Optional	3-27
Post-Seal Inspection	3-28
Do's of Seal Coating	3-28
Do Not's of Seal Coating	3-29
Blade Mixed Asphalt Mix	3-29
Handling Emulsified Asphalts	3-30

## **Chapter 4**

## **Drainage**

---

	<b>Page</b>
General	4-2
Drainage from Abutting Properties	4-2
Ditches and Gutters	4-3
Rockfall Ditches and Slope Benches	4-4
Dry Wells	4-4
Culverts	4-4
Automatic Pumps	4-5
Underdrains	4-5
Storm Sewers	4-5
Bank Protection	4-6
Detention Ponds and Tanks	4-6
Oil Separators	4-6

---

**Chapter 5****Maintenance of Structures**

---

	<b>Page</b>
General	5-2
Major Structures	5-2
Minor Structures	5-2
Inspection	5-2
Bridge Repair Guidelines	5-4
Environmental Aspects	5-4

---

**Chapter 6****Roadside Management**

---

	<b>Page</b>
General	6-3
Roadside Functions	6-4
Roadside Treatment	6-5
Maintenance Involvement in the Roadside Management Process	6-5
Roadside Maintenance and the Maintenance Accountability Process	6-6
Roadside Management Zones	6-7
Integrated Vegetation Management	6-11
Noxious Weed Control	6-13
Danger Trees	6-14
Disposal of Logs Dumped on Right of Way	6-14
Removal of Dangerous Objects and Structures	6-15
Trespass and Encroachment	6-15
Encroachments - General	6-15
Encroachment - Maintenance Crew Responsibilities	6-15
Franchises and Permits	6-16
The Use of Pesticides	6-16
Pesticide License	6-17
Record Keeping	6-17
Product Labels	6-17
Posting Requirements	6-17
Aquatic Pesticide Applications	6-17
Pesticide Sensitive Individuals	6-18
Container Disposal	6-17
Use of Mowing Equipment	6-18
Other Cutting Methods	6-19
Cultural Control Methods	6-19

## **Contents**

---

	<b>Page</b>
Biological Control	6-20
Burning Debris	6-20
Illegal Tree Removal	6-20
Significant Roadside Activities	6-21
Removal of Debris and Rubbish	6-22
Litter Control and Partnerships for Roadside Enhancement	6-22
Adopt-a-Highway	6-22
Program Rules	6-23
Participant Eligibility	6-23
Assignment of Sections	6-23
Volunteer Adoptions	6-24
Sponsored Adoptions	6-24
General Permits for Roadside Enhancement	6-25
AAH Administrative Roles and Responsibilities	6-26
Maintenance & Operations Programs Responsibilities	6-26
Region Responsibilities	6-26
Auxiliary Facilities	6-27
Safety Rest Areas	6-27
Park and Rides Lots	6-28
Historical Markers	6-28
Viewpoints	6-28

## **Chapter 7**

## **Snow and Ice Control**

---

	<b>Page</b>
General	7-2
Preparation for Winter Operations	7-2
Highway Categories	7-3
Special Criteria	7-4
Work on State Highways	7-4
Area of Responsibility	7-4
Snow Control Operations	7-4
Ice Control Operations	7-4
Anti-Icing and Deicing Chemicals	7-4
Level of Service Coordination	7-5
Tandem Plowing	7-5
Spinner Shut-Off	7-5
Operations at Interchanges	7-5
Railroad Crossings	7-5
Widening	7-5
Drainage Ways	7-5

## **Contents**

---

	<b>Page</b>
Highway Sign Installations	7-5
Construction Projects	7-5
Pedestrian Facilities	7-5
City Streets on the State Highway System	7-5
Work on Other Roads and Areas	7-6
Other Governmental Agencies	7-6
Private Approaches	7-6
Abandoned or Illegally Parked Vehicles	7-6
Closures	7-6
Emergency Assistance	7-7
Precautions	7-8
Service Level Quality Measurement	7-8

## **Chapter 8**

## **Traffic Services**

---

	<b>Page</b>
General	8-2
Reconstruction Principles	8-2
Signing	8-3
Signing Responsibility	8-3
Sign Installation	8-3
Maintenance	8-4
Inspection	8-4
Field Repair	8-4
Sign Visibility	8-5
Sign Storage and Transportation	8-5
Delineation	8-5
Pavement Markings	8-5
Materials	8-7
Application	8-7
Marking Renewal or Replacement Frequency	8-7
Removal of Markings	8-8
Guideposts	8-8
Traffic Barriers and Impact Attenuators	8-8
Maintenance	8-8
Inspection	8-9
Repair	8-9
Standard Run of Barrier	8-9
Terminals and Anchors	8-10
Transitions	8-10



## **Contents**

---

	<b>Page</b>
Impact Attenuators	8-11
Maintenance	8-11
Islands	8-11
Transit Vehicle Stop Zones	8-12
Maintenance	8-12

## **Chapter 9**

## **Electrical System Maintenance**

---

	<b>Page</b>
General	9-2
Wiring and Connection Maintenance	9-2
Enclosure Maintenance	9-2
Documentation	9-2
Changeable Message Sign Systems	9-2
Drain Pump Systems	9-3
Gate and Barrier Systems	9-3
Minor	9-3
Major	9-3
Intersection Control Beacons	9-3
(Includes Hazard Beacons)	
Illumination Systems	9-3
Roadway Illumination Systems	9-3
Sign Lighting Systems	9-4
Services	9-4
Signal Systems	9-4
Vehicle Detection Systems	9-4
Pedestrian Detection and Display System	9-4
Vehicle Display Systems	9-4
Signal Control Systems	9-5
Sprinkler Systems	9-5
Television Systems	9-5

## **Chapter 10**

## **Miscellaneous**

---

	<b>Page</b>
Right of Way Fences	10-2
Road Approaches-General	10-2
Typical Maintenance Responsibilities in Cities	10-2
Maintenance Yards	10-6
Stockpile Sites	10-7
Materials from State Quarries or Pits	10-7

## ***Contents***

---

	<b>Page</b>
Procurement of Materials	10-8
Material Specifications - General	10-8
Disposal of Surplus Items	10-8
Equipment	10-8
Inventoried Items	10-8
Non-Inventoried Items	10-8
Instructions for Radio Operation	10-8
General Technique	10-8
Helpful Reminders	10-9
Work Scheduling and Reporting	10-9
Budget	10-9
Scheduling	10-10
Reporting	10-10
Environmental Sensitivity	10-10

## ***Appendices***

---

	<b>Page</b>
City Streets As Part of State Highways	Ai-1
Traffic Control Plans	
Lane Closure on Divided Roadway	A1
Multiple Lane Closure	A2
Lane Closure on 2 Lane Roadway- Short Duration	A3
Lane Closure on 2 Lane Roadway- Flagging Provided	A4
Pedestrian Control	A5
Emergency Procedures Manual	
Work Zone Traffic Control Guidelines	
Highway Field Formulas	
Acronyms & Abbreviations	
Index	

	<b>Page</b>
General Responsibilities	1-2
Regional Emergency Response Plans	1-3
WSDOT Disaster Plan	1-3
Concepts of Operations	1-3
Organization and Assignment of Responsibilities	1-4
Administration and Logistics	1-4
Plan Development and Maintenance	1-4
Training and Exercises	1-4
Emergency Operating Procedures	1-5
General	1-5
Maintenance Field Personnel	1-5
Maintenance Superintendent or Supervisor	1-6
Abandoned Cargo	1-7
Clearing the Highway	1-7
Open Road Policy	1-7



## General Responsibilities

This chapter provides guidance to reduce the vulnerability of the state transportation system from any emergency or disaster by:

1. Establishing capabilities for protecting the transportation system and employees from the effects of emergencies or disasters
2. Responding efficiently to emergencies and disasters
3. Assist in recovering in the aftermath of any emergency or disaster

This chapter also incorporates some of the day-to-day operational procedures that are used in responding to incidents such as small spills, snow/ice removal, traffic accidents, emergencies, disaster events, and recovery efforts. The Washington State Department of Transportation (WSDOT) Disaster Plan and the Emergency Procedures Manual (M30-14) define the details of how the Department responds to these types of events and is included as an Appendix for reference purposes.

An emergency is defined as a situation involving natural phenomena, disasters, casualties, national defense or security measures, etc. and includes response activities that must be taken to prevent the imminent loss of human life or property.

WSDOT will perform the following functions in emergency situations:

- Determine usable portions of the state highway network. Coordinate and control emergency highway traffic regulations in conjunction with the Washington State Patrol.
- Notify your local Washington Department of Fish and Wildlife (WDFW) local habitat biologist that an emergency action needs to be taken and obtain the Hydraulic Project Approval (HPA) as soon as possible after taking the emergency action.
- Notify the “National Marine Fisheries Service and U.S. Fish and Wildlife Service” that maintenance is taking an emergency action that could result in an “after the fact” consultation under the endangered species act, if the emergency action involves threatened or endangered species’ water bodies.
- Follow the memorandum of understanding on “Emergency Actions in Water Courses” with the Washington Department of Fish and Wildlife.
- Meet the conditions of the Washington Department of Fish and Wildlife (HPA) permit if applicable and possible.

- Reconstruct, repair and maintain state highways, bridges, and alternate routes. Coordinate the mobilization of personnel and equipment required for emergency engineering services.
- Maintain liaison with the Washington State Chapter of the Associated General Contractors of Washington and America, construction, and equipment rental companies.
- Provide initial damage assessment estimates on state and local facilities (both for federal aid eligible roads and non-federal aid eligible roads) and public/private airports as a member of the Preliminary Damage Assessment (PDA) Team.
- Participate on Damage Survey/Inspection Report Teams, conducting inspections of federal aid and non-federal aid system highway facilities damaged by a disaster.
- Coordinate all transportation related missions including, emergency air, marine and rail transportation of personnel and essential supplies.
- Conduct aerial reconnaissance and photographic missions.
- Provide public information support to the Office of the Governor and the Washington Emergency Operations Center during emergency response and recovery operations.

## **Regional Emergency Response Plans**

Each Region shall develop and maintain an Emergency Response Plan that will establish day-to-day operational procedures to cope with routine spills, accidents, etc. Regions will also develop procedures to address their response capabilities for those events that are beyond the normal day-to-day operational mode. Each of these procedures shall clearly define employee roles and responsibilities.

## **WSDOT Disaster Plan**

### **Concepts of Operations**

Governments have the responsibility to make every effort to protect life and property during emergencies. When the emergency exceeds the capability of government to respond, assistance will be requested from the next higher level of government.

For example:

Local government may request state assistance and state government may request federal assistance.

However, this plan heavily emphasizes the responsibility and capability of local governments to respond

to and accomplish short-term recovery during emergencies/disasters.

The WSDOT Disaster Plan recognizes that emergency functions for groups and individuals should parallel normal day-to-day functions. When this is not possible, managers should attempt to maintain organizational continuity and assign familiar tasks to employees.

## **Organization and Assignment of Responsibilities**

Service Centers and Regional Offices have emergency functions in addition to normal duties. Each Service Center and Regional Office establishes procedures for:

- Operations during emergencies.
- Emergency Personnel Roster.
- Compliance with WSDOT Responsibilities and Authorities.

## **Administration and Logistics**

WSDOT acknowledges that in a time of crisis, some administrative procedures should be suspended, relaxed or made optional. However, it is desirable to foresee and plan for necessary changes in administrative procedures.

Documentation is critical for successful reimbursement of funds or to support liability issues. All actions taken, especially changes to established procedures, shall be documented. This is the responsibility of Maintenance Lead Technicians, Maintenance Supervisors and Superintendents. It is proper in these situations to use all tools that are available in order to provide a clear documentation trail. Maintenance office staff are to be provided the documentation and then are tasked with filling out the proper records and forms to be forwarded to the Regional Maintenance administration.

## **Plan Development and Maintenance**

The WSDOT Disaster Plan is the principal source of documented department emergency management activities. Most Service Centers and Regional Offices are responsible for developing or accomplishing tasks in some part of the plan. This may require simultaneous coordination with local, state and federal agencies. Overall, the Headquarters WSDOT Disaster Plan development, maintenance and coordination is the WSDOT Emergency Management Program Manager's responsibility in cooperation with Service Centers and Regional Offices.

## **Training and Exercises**

WSDOT will periodically provide training and conduct exercises to test the WSDOT Disaster Plan and Procedures to assure maintenance of a readiness mode and reflection of current department operational practices.

## **Emergency Operating Procedures**

### **General**

There are many situations when transportation crews may be exposed to situations requiring emergency action. The most common emergency situations maintenance crews may encounter are vehicle accidents and hazardous material spills.

Hazardous materials are those substances which, when spilled, may make driving on the roadway unsafe, endanger the lives of people in the vicinity, or contaminate the environment. These materials may make the roadway surface slippery, impair visibility, or cause lane and road closures. Materials that may be dangerous in themselves include: explosives, flammables, corrosives, poisons, and radioactive materials. Other materials may not be hazardous but cause hazardous conditions such as fine powder-like materials which create visibility problems or bulky materials which cause lane closure.

WSDOT employees at the scene of an accident or spill will take emergency actions only as required to protect human life and property until the Washington State Patrol has control of the situation. The State Patrol has the responsibility for safety measures at an accident site and for coordination with Department of Ecology for the clean-up of spilled substances. The Washington State Patrol may request assistance from WSDOT for traffic control and to clean up an accident site. WSDOT employees must not attempt to clean up any hazardous material spills. In most cases WSDOT Maintenance employee's have not been trained and/or do not have the proper resources to clean up hazardous spills. Clean up is the responsibility of the owner or shipper of the cargo, if they can be identified. If the owner/generator is unknown, the Department of Ecology is responsible for the clean up. In general terms Ecology personnel only respond onsite to spills greater than 50 gallons of hazardous material.

### **Maintenance Field Personnel**

Maintenance employees will take the following actions when encountering a hazardous condition:

- Advise the Area Maintenance Supervisor or Superintendent of the problem, and request aid from the Washington State Patrol.
- Take precautionary actions to protect themselves, maintenance crews, and the traveling public from any exposure.
- Provide traffic control, including closure of the highway if appropriate, to ensure that no one comes in contact with the hazardous material.
- Survey the situation and report the exact location, cause of the temporary closure, and extent of the closure to the Area or Regional Maintenance Office (or your Maintenance Supervisor or Lead Technician). Notification should also go to the TMC, Traffic Management Center, in each Region if they have one in place.



- If the spilled substance is identified and is spreading toward water courses, additional traffic lanes, or likely to cause ground water damage, take appropriate action to absorb or confine the spill. Always use careful judgment and only take actions you know and understand are safe for you to do. Examples of commonly spilled materials include gas, oil and diesel.
- Never take action on an unknown substance or on a known substance that is extremely dangerous to life and property. Examples would include those products with greater harm than gas, oil and diesel. If employee's are not sure what the product is they are to stay clear of the area.
- Some accident scenes include human tissue and blood residues. Contact with these materials is to be avoided. Fire response should wash this residue from the highway or highway feature surfaces. The Washington State Patrol is the incident commander and should assure that the accident scene is ultimately safe.
- Stay on site to safeguard traffic until proper traffic control devices are installed and/or until relieved by your Maintenance Supervisor, Lead Technician, or a Washington State Patrol Trooper.
- Patrol for stranded motorists in isolated areas when traffic has been controlled and when applicable.

### **Maintenance Superintendent or Supervisor**

- Coordinate personnel and equipment to close a highway or restrain traffic from entering a hazardous area.
- Make a complete report of the closure to the Regional Maintenance Engineer/Manager and Traffic Control Center (TMC).
- Ensure the hazardous section of highway is being monitored, then patrol the area to make sure there are not stranded motorists.
- Provide detours around partial closures when safe to do so. Whenever possible, establish detours on existing state routes. Other local roads should only be used after surfaces, bridges, and overhead clearance restrictions have been reviewed and approved by the appropriate local jurisdiction. Detours will be signed and other traffic control devices (e.g., barricades and flashing lights) will be installed. Station flaggers at barricaded points when necessary.
- Arrange to advise the Regional Public Information Office so that announcements of the closure can be made on the WSDOT public service and communications networks.

- If a closure is requested by the Washington State Patrol, and the local Maintenance Superintendent is not available, contact the Regional Maintenance Manager or the Regional Administrator to advise of the request and provide recommendations concerning the need for the proposed temporary closure.
- Reopen the roadway when the physical blockage is eliminated or the hazardous conditions that caused the closure have abated.
- Advise the Area Maintenance Superintendent, Regional Maintenance Manager, or Regional Administrator of the reopening by the fastest means available.
- Arrange to relay notice of the reopening to the Regional Public Information Office to ensure that information on the public service and communications network is current.

## **Abandoned Cargo**

- All cargo spilled on WSDOT property will be removed at the owner's expense if the owner can be identified. A determination that the cargo is hazardous material will necessitate the procedures outlined earlier. State law (RCW 4.24.512) dictates that the responsible party has the responsibility for clean up of hazardous materials.
- If the spilled material is hazardous, stay safely back from the hazard, establish traffic control, and call the Washington State Patrol who in turn will call the Department of Ecology Spill Response Team. The Department of Ecology is responsible for coordinating clean-up of hazardous materials. If dropped material is identified as hazardous but the container is not leaking or severely damaged, it can be removed to the edge of the shoulder to allow traffic flow if this action must be taken prior to Ecology's arrival at the scene. It should not be taken back to the maintenance facility.
- If dropped material is identified as non-hazardous and is reusable it should be returned to the maintenance facility. After a determination of ownership is made and if the commodity is not reclaimed within (30) days it becomes the property of the department and may be used for its intended purpose, if appropriate.

## **Clearing the Highway**

### **Open Road Policy**

- The January 1999 WSP/WSDOT "Joint Operating Policy Statement" was developed to stress the importance of the Agencies' responsibility to do what-

ever is reasonable to reduce the delays associated with incidents and collisions. The open roads philosophy of this policy statement is that WSP and WSDOT shall open the roadway as soon as possible on an urgent basis.

- It is a goal of WSDOT to minimize traffic delays caused by vehicle accidents and incidents. WSDOT Maintenance personnel assisting at vehicle accidents will make every reasonable effort to clear the traveled way as quickly as possible.
- First priority -safety: It is the departments' obligation and responsibility to provide a safe environment for its employees and the public.
- Second priority- Minimizing traffic delay: Maintenance personnel responding to vehicle accidents which involve lane closures will consider every reasonable measure in coordination with WSP, to clear the lane as quickly as possible. At accident scenes which involve spilled or damaged cargo, the overriding strategy will be to minimize traffic delay. Salvage of the cargo will be secondary and at the convenience and benefit of transportation movement. Criteria to be used in making "Open Road" decisions include:
  - crime scene investigation
  - traffic volume
  - time of day
- Lowest priority- The potential salvage of the cargo should be the last consideration in decisions related to minimizing traffic delay.



## **Chapter 2**

## **Work Zone Traffic Control and Safety**

	<b>Page</b>
General	2-2
Fundamental Principles	2-2
Traffic Control Zones	2-3
Traffic Control Devices	2-4
Signs and Supports	2-4
Channelizing Devices	2-6
Cone Placement Procedure	2-6
Water and Concrete Barrier	2-7
Hand Signaling Devices	2-8
Lighting Devices	2-8
Traffic Control Procedures	2-9
Off-Road Activities	2-10
Nighttime Activities	2-10
Non-motorized Traffic Control	2-11
Pedestrian Control	2-11
Bicycle Control	2-11
Safety	2-12
Work Zone Operations	2-12
Enforcement	2-13
Resources for Traffic Control and Work Zone Safety	2-13



## Chapter 2

## Work Zone Traffic Control and Safety

---

### General

Safe and effective traffic control is vital for the safety of the traveling public. It is also essential to protect construction, maintenance and utility workers whose work places them near high speed traffic. The traffic control guidelines in this manual provide the driving public positive and consistent guidance through work zones. These procedures will also reduce the risk to maintenance workers who are exposed to potential traffic hazards

The Secretary of Transportation has adopted the Manual on Uniform Traffic Control Devices (MUTCD) as the legal standard as required by RCW 47.36.030. **It is mandatory that traffic control measures on maintenance projects comply with the MUTCD requirements.** The MUTCD outlines basic principles and prescribes standards for the design, application, installation, and maintenance of traffic control devices. The MUTCD details requirements for color, size, shape, location and need for traffic control devices.

In some cases WSDOT has standards that exceed those in the MUTCD (e.g., see Traffic Manual, M51-02, Chapter 5 and the Work Zone Traffic Control Guidelines Book, M 54-44) which is included as an appendix. In such situations the most stringent standard is the legal standard you must follow. Learn those standards before you perform traffic control.

Consult the Regional Traffic Engineer when standard layouts are not applicable.

This chapter reflects the work and recommendations provided by the Work Zone Safety Task Force. The Work Zone Traffic Control Guidelines Book (M 54-44) incorporates the recommendations of the Work Zone Safety Task Force and the standards of the MUTCD, and is intended to be used as the companion resource to the guidance in this chapter.

The maintenance employee in charge at a work zone is responsible to see all standards are followed. This includes ensuring temporary signs, warning devices, and flag persons are placed appropriately to protect both motorists and workers. **Motorist and worker safety are of primary importance. Safety takes precedence over all efforts to maintain a highway or structure.**

### Fundamental Principles

Principles to enhance motorist and worker safety in maintenance work areas:

- Develop a comprehensive traffic control strategy that can be implemented at the work site. Evaluation of the work operation, site, and traffic conditions should determine the traffic control measures to be utilized. Refer to the Work Zone Traffic Control Guidelines Book, “checklist for establishing a temporary traffic control zone” and the Traffic Manual, “traffic control planning and strategy checklist”.
- Maintain traffic flow as close to normal highway situations as possible.

- Do not surprise the motorist. Locate and place devices to maintain adequate sight distance for driver recognition and reaction on straight highway sections if possible.
- Prepare, understand, and implement a traffic control plan. Don't routinely rely on minimum standards. Evaluation of the work operation, site and traffic conditions should be determined to the appropriate level of traffic control measures.
- Avoid frequent and abrupt changes in alignment.
- Minimize worker exposure time to traffic.
- Provide adequate warning, delineation, and channelization.
- Remove inappropriate pavement markings on long-term projects.
- Provide flagging only when other methods of traffic control are inadequate.
- Inspect traffic set-up control measures prior to work.
- Monitor traffic control and modify where changing traffic conditions warrant.
- Remove, cover, or turn control devices away from traffic when not needed or in use.
- Channelize traffic with pavement markings, signing, cones, plastic barrels, water filled barriers, or lightweight devices.
- Sand bags may be used for sign ballast. Do not use heavy, solid weights, (e.g., concrete blocks) for stabilizing portable sign supports.
- Traffic control measures must be selected and implemented with the drivers' perspective in mind. Credible messages must be sent to the driver to provide a reasonable expectation that the driver will comply.
- Plan ahead for work operations and the associated traffic control. Don't rely completely on standard devices and procedures when more effective measures should be considered.
- Use traffic control devices (cones and barrels) to define the closed portion of the roadway that is the work zone. Even short term operations can realize a safety benefit from placing cones in a manner that sends an obvious message to drivers that a portion of the road is closed and they must divert around the work zone.

## **Traffic Control Zones**

The traffic control zone is the work area between the first advance warning sign and the point beyond where traffic is no longer affected (see Figure 2-1). Traffic control zones are divided into the following areas:

- Advance warning area
- Transition area (for lane or shoulder closures)
- Buffer space
- Work area
- Termination area

1. **Advance warning area** - The Advance Warning Signs are located before the



transition area to provide ample opportunity for motorists to accomplish a desired maneuver. Where there is no lane or shoulder closure, as in mowing operations, one sign will suffice. Use signs on both sides of two-way, two lane highways and multilane roadways.

Message - Information - Action (MIA) - signing must relate to all three action words.

The first sign to appear in the advance warning area tells motorists they are approaching a work zone (e.g., ROAD WORK AHEAD). The next sign display provides more detailed information about the situation ahead (e.g., ONE LANE ROAD AHEAD), and the third sign states what action to take (e.g., BE PREPARED TO STOP).

2. **Transition area** - This is the zone where the lane and/or shoulder is closed by cones or channelizing devices. The rate of taper is in accordance with the traffic control plans in the Standard Plans. If restricted sight distance is a problem (e.g., sharp vertical or horizontal curve), begin the lane closure well in advance of the view obstruction. Do not hide the beginning of lane closures behind curves.
3. **Buffer space** - This is the unoccupied space between the transition and work areas. It is there to provide a margin of safety for both traffic and workers. With moving operations, buffer space is the space between the attenuator/buffer truck and the work vehicle.
4. **Work area** - Where equipment and workers perform maintenance functions.
5. **Termination area** - Allows traffic to resume normal driving immediately after leaving the work area.

## **Traffic Control Devices**

Traffic control devices are used to warn, regulate, and guide traffic. They include: signs, signals, lighting devices, pavement markings, delineators, channeling devices, hand signaling devices, and temporary barriers. **Traffic control devices must conform to WSDOT and MUTCD standards.** Use traffic control devices where necessary. Remove, cover, or turn them away from traffic when they are not in use or no longer applicable.

1. **Signs and Supports** - Sign supports are either portable or fixed depending on the duration of work. Small sand bags may be used to stabilize portable sign supports. Do not use objects that could become a projectile upon impact (e.g., concrete, chain, etc.). Sign supports should be lightweight, yielding or breakaway in composition.

Signs on portable supports must be (1) foot above the roadway. Those mounted on fixed posts must

be (5) feet above the roadway in rural areas and (7) feet above the roadway in urban areas.

Sign spacing is set forth in Appendix A. Follow these sign spacing requirements but also consider in-place existing signs when developing traffic control plans.

**Regulatory signs** - (e.g., KEEP RIGHT, DO NOT PASS) These signs impose legal restrictions, and are placed where the regulation applies. Most regulatory signs are black on white. **(Use them only as necessary)**

**Reduced legal speed limits** - Only use reduced legal speed limits when other efforts to control traffic prove to be inadequate. For emergency and other speed reductions, follow speed reduction guidelines outlined in RCW 47.48.020, the WSDOT Construction Manual (M 41-01), and WSDOT Directive D 55-20, Reduced Speed in Maintenance and Construction Work Zones.

To change a speed limit, submit a request to do so to the Regional Traffic Engineer. To ensure a work zone is adequately signed, post the speed limit signs in the work zone. Post regulatory speed limit signs for work hours only (identify hours when the limit is in effect). Remove all signs when the reduced speed limit is not in effect.

**Warning signs** - Their purpose is to give motorists notice of potentially hazardous conditions for traffic. They are erected in advance of the condition. Use warning signs when conditions warrant, particularly if the hazard is not obvious or cannot be seen by approaching motorists. Don't overuse warning signs or they will lose their attention-getting value.

All warning signs shall have black legends on an orange background (except the round railroad advance sign, which is black on yellow). **Do not use double faced (back-to-back) signs.**

**Changeable message signs** - These signs are recommended for high speed, high volume roadways, or work operations that require a highly visible message. Use them to supplement or enhance work zone safety and not to replace required signs. Two message panels are the maximum allowed. Consider truck mounted Portable Changeable Message Signs (PCMS) for shadow/ buffer vehicles.

Some typical situations include:

- Locations where speed of traffic is expected to drop substantially
- Locations where significant delays are expected
- Accident or incident management

Make messages clear and brief, keeping messages to a maximum of two panels. If special messages are necessary, be consistent with conventional signs and standards normally used. Whenever possible use the pre-programmed stored messages the PCMS is equipped with. Never display a message with an arrow from a PCMS that is located on the same shoulder as the arrow direction (right shoulder/right arrow or left shoulder/left arrow.)

2. **Channelizing Devices** - Channelization devices are used to direct traffic away from or around a work area, or to separate two-way traffic. Tubular markers, cones and plastic barrels/drums are effective. Channelization devices must be reflective for night use.

**Cones** - These are the most common device used to separate and guide traffic past a work zone. Cones must be at least 18 inches tall for normal situations. But, they must be 28 inches tall minimum, for high speed, or high volume operations.

Reduced device spacing around work zones is recommended. Make provisions for large work vehicle access as needed (routed off the existing shoulder or through a stagger of channelization devices.)

Place barrels or cones diagonally across closed lanes to show motorists which lanes are closed.

Refer to the Work Zone Traffic Control Guidelines Book for more information on channelization devices, application and placement.

### **Cone Placement Procedure**

Prior to establishing traffic control with cones, a meeting is held by the involved parties to discuss the following procedures:

- Technique (e.g., a whistle or voice actuated headset) for signaling between the cone handler and truck operator.
- Will cone tapers across the closed lanes be done by hand?
- Set up and take down a line of cones along lane or center lines:
- The cone handler should ride in a cone setting cage attached to the front, back or side of the traffic control vehicle, to set and remove cones in the work zone.
- The driver is responsible for: safe operation of the vehicle, maintaining the vehicle at a safe speed, watching the cone side and the front of the vehicle, and watching the cone handler.
- The cone handler is responsible for setting and removing cones, and signaling the driver in case of any obstruction or emergency.
- The driver and cone handler will decide if a shadow vehicle with a truck mounted attenuator is required to protect the cone handler while exposed to traffic.

**Traffic Safety** - Drums are used on freeways due to greater target value and imposing size.

**Barricades** - They protect spot hazards and close roadways and sidewalks with appropriate signing. Barricades can also be used to provide additional protection to work areas. **Lights used to channelize traffic must be steady burning, “Type C”.** Do not use flashing, “Type A”, warning lights on barricades to channelize traffic.

**Temporary pavement markings** - These markings delineate lanes and tapers on long-term projects. Remove existing markings that may confuse motorists. For short-term maintenance operations, it is not practical to remove and then restore pavement markings. If it is necessary to divert traffic across existing pavement markings, the channelizing device used must be so dominant that a motorist’s attention is drawn completely away from the existing marking. Reduced device spacing is recommended. The use of removable black mask tape (see QPL) Qualified Products List may also be considered to temporarily cover existing markings.

**High level warning devices** - They are tall, portable stands with flags or flashing lights visible above traffic. Used with flags only, they may have a sign or flashing light attached, or be attached to vehicles used in moving or mobile work operations. (See MUTCD, Part VI).

3. **Water and Concrete Barriers** - There are three types of barrier protection used in work zones: concrete barrier, movable concrete barrier, and water-filled barrier. While barriers are effective, they may result in more damage to an impacting vehicle.

**Water filled barriers** - They are a portable traffic barrier designed to prevent intrusion of errant vehicles into work areas. Recommended for stationary work areas with high exposure to high speed traffic where it may not be practical to use concrete barrier, but more protection than channelization devices is desired. Up to 23 feet of lateral deflection can occur if the barrier is impacted at high speed.

Consider the use of water barriers for:

- Short term projects (zero to three days) of a minimum 100’ in length.
- **Do not use in lane transitions** until further testing or the situation meets with manufacturer’s specifications.
- Evaluate risk and site conditions. If used, follow manufacturer’s guidelines and specifications. Consult with the Region Traffic Office prior to use.

(Additional information on concrete and water barriers is located in Chapter 5 of the Traffic Manual, M 51-02 and the Work Zone Traffic Control Guidelines Book.)

**Concrete barriers** - They are a rigid barrier designed to prevent intrusion of errant vehicles into work areas considered the most substantial type of barrier to enhance worker safety. Contact the Region Traffic Engineer for site specific placement information.

Consider the use of concrete barriers for:

- High speed roadways and areas with a high potential for worker injuries.
- Work zones in “no escape” areas (e.g., tunnels, bridges, and lane expansion

work).

- Long term, stationary jobs (work occupying a location for more than 3 days).
- Worker and traveling public exposure considerations (e.g., high speed and volume of traffic), when workers are not protected by a vehicle, and in proximity to traffic (e.g., concrete slab repair on freeways).

**Movable barriers** - Consider the use of movable barrier such as Transfer/Transport Vehicle (TVV) barrier and special vehicle) for:

- High volume traffic conditions with very short-term lane closures.
- Continuous operation over an extended period of time, where there is a need to get the lane back in operation at some point in the day. (Could be used in lieu of reduced lane widths or lane reduction, e.g., lane additions, wall next to roadway).

Protect the ends of concrete barriers with crash cushions or berms, unless flared outside the clear zone. Consult with the Region Traffic Engineer to determine the appropriate end treatment. Do not use concrete barriers as a taper, but when/if flared or tapered, channelization must be used in advance (e.g., tubular markers, cones, or plastic barrels) to provide a recovery area for errant vehicles.

4. **Hand Signaling Devices** -If other methods of traffic control are inadequate to warn and direct drivers and flagger traffic control is implemented, stop / slow paddles must be at least 18 inches in diameter and reflective for night use. For high speed, high volume traffic or those locations where more advance driver attention is desired, consider the use of 24" stop/ slow paddles or the Flashing Stop/ Slow Paddle (FSSP).
5. **Lighting Devices** - Use to call attention to hazardous situations, especially at night. Includes warning lights, flashing vehicle lights, floodlights, and flashing arrow boards.

**Warning lights** - These lights are either flashing or steady burn ( Types A, B, or C or strobe) mounted on channelizing devices, barriers and signs. Secure warning lights to the channelizing device or sign so they will not come loose and become a dangerous flying object if impacted by a vehicle. See the MUTCD, Part VI for additional information.

**Flashing vehicle lights** - These lights alert motorists to the potential hazards of maintenance vehicles and workers near the traveled lanes. Use flashing lights to warn of isolated hazards or signs. Snow-removal and other highway maintenance equipment use flashing lights for purposes of identification when working. Use flashing lights anytime over width equipment is on the highway per WAC 468-38-390.

**Floodlights** - Use them to illuminate nighttime work. Floodlights permit the crew to see what they are doing and make the crew visible to motorists. Where planned, night operations require flaggers; flood lighting must be provided to illuminate the flagger. Shield the light source to protect motorists from glare.

**Steady burning lights (Type C)** - Lights used in a series of channelizing devices or barriers form a

taper or separate the work area from traveled lanes. Never use any type of flashing light in sequence for transitions or continuous channelization.

**Flashing arrow boards and changeable message signs** - They are effective for day and nighttime tapered lane closures and moving operations. At night, flashing arrow boards are required to use a photocell which automatically dims (minimum 50% dimming) so that motorists will not be temporarily blinded. When used for lane closures tapers, they are located in the lane (or partially on the shoulder ) being closed, behind the taper of channelizing devices, usually within the first one third of the taper.

Do not use arrow boards or arrow displays on changeable message signs when:

- Work does not require lane closures, except for moving operations on multilane facilities.
- All work is on or outside the shoulder with no interference requiring closure of the adjacent traveled lane.
- The work is on a two-lane, two-way roadway.
- A shoulder closure is required.

Do not use more than one arrow display per lane being closed. An arrow display with a shadow vehicle (early warning) is allowed on mobile or moving lane closure operations. The caution mode (flashing four corner lights) may be used as supplemental warning at work area not requiring a lane closure.

Arrow displays used on PCMS's must meet the same performance standards for flashing arrow boards, see MUTCD, Part VI.

## **Traffic Control Procedures**

Controlling traffic for maintenance operations is dependent upon the activity being performed, the estimated duration of the activity, type of highway, traffic speeds and traffic volume. Safety clothing will be worn by WSDOT employees while in the highway work zone (for more information, see IL 72-96, *Safety Clothing to be Worn by WSDOT Employees while in Highway Work Zones*).

Providing advance warning to drivers approaching road work is required. The specific requirements for advance warning depend on the actual site conditions and could be the flashing beacon on a work vehicle or a series of portable signs and a PCMS. (Refer to the Work Zone Traffic Control Guidelines Book and the MUTCD, Part VI for specific advance warning requirements).

Use an advance warning sign when:

- Any work activity that may distract the driver or require the driver to react, beyond the normal driving requirements for that section of road.
- Work is performed on or immediately adjacent to the roadway. (within 15' of the edge of the roadway).

- Equipment may be moved along or across the highway.
- The shoulder is occupied or closed.
- There is encroachment into traveled lanes.

Typical traffic control plans and additional guidance for maintenance activities are contained in the MUTCD, Part VI and the Work Zone traffic Control Guidelines Book. These plans establish typical signing procedures. The maintenance employee in charge must determine the extent of traffic control required to provide motorist and worker safety.

After establishing traffic control, the maintenance employee in charge will drive through the work area at expected motorist speeds to determine the plan's effectiveness. Periodic monitoring is required to ensure traffic control devices remain in place.

Changing conditions such as traffic, work, or time of day require traffic control adjustment. If an accident or near accident occurs after the control has been set up, make necessary adjustments immediately and monitor for a reasonable period. Remove, cover or turn traffic control devices during non-working hours.

Refer to the Work Zone Traffic Control Guidelines Book and the MUTCD, Part VI for guidance on specific work operations, duration of work requirements and flagging operations.

### **Off-Road Activities**

Where work is being conducted off the roadway and shoulders, but within the right of way, the hazards are usually minimal. However, minimize risks by using an appropriate warning sign (e.g., MOWER). (See above section on advance warning signs).

### **Nighttime Activities**

Nighttime maintenance activities are commonly performed because of lower traffic volumes and reduced traffic disruption. Nighttime work is also necessary to respond to emergencies such as fallen trees, mud slides, etc.

Night operations present additional safety concerns. All signs used at night shall be reflectorized or illuminated as specified in the MUTCD - Section 6F-5. Street or highway lighting does not meet the requirements for traffic control device illumination.

Floodlights may be necessary to provide work area illumination and to permit the crew and flaggers to be visible to the motorist. The light source must be shielded to protect drivers from glare. Consult the Safety and Traffic Offices to review WSDOT illumination practices.

The effectiveness of flagging is diminished at night as the flagger may not be visible to the motorist. Make efforts to control traffic by other means when possible. When used, the flagger is located within a coned area (usually the shoulder or other relatively safe location) but not within the taper itself. As with

other workers in night work zones, flaggers shall wear traffic vests made of highly visible materials supplemented with reflective material visible on all sides of the wearer and a highly visible hard hat with reflective qualities.

Portable traffic signals require approval in the traffic control plan developed by the Region Traffic Office. Portable traffic signals and lights with on-board generators are effective for controlling traffic at intersections or at each end of the work area. These units can be remote controlled by a worker, thus eliminating the need for a flagger.

## **Non-motorized Traffic Control**

Give consideration to pedestrian and bicycle traffic where appropriate. Provide alternative routes where designated walkways or bicycle routes are temporarily interrupted due to maintenance operations. Alternative routes need to be free of obstructions and hazards (e.g., holes, debris, mud, construction and stored materials, etc.) Clearly delineate all hazards near or adjacent to the path (e.g., ditches, trenches, excavations, etc.). Bicyclists are subject to the same flagging procedures as vehicles. Do not place signs and other traffic control devices to pose a hazard.

## **Pedestrian Control**

Alternative pedestrian walkways are provided when pedestrian activity is apparent where:

- Walkways traverse the work zone.
- A designated school route traverses the work zone.
- Significant evidence of pedestrian activity exists (e.g., a worn path).
- Existing land use generates pedestrian activity.

Consider the following principles for designing/constructing alternative pedestrian facilities:

- Separate pedestrians and vehicles by barrier or channelizing devices. Use barriers on high speed facilities. Use channelizing devices on low speed (35 mph or less) facilities.
- Walkways used at night, (especially if adjacent walkways are lighted) need temporary lighting.
- Use warning lights to delineate pathways and mark hazards.
- Pedestrians will not go out of their way. Make alternate pathways reasonable.

## **Bicycle Control**

Bicycles have a legal right of access to most highway facilities and provisions for their safe conduct through work zones are necessary.

Provide and sign an appropriate alternate route when maintenance activities close a designated (signed) bicycle path or shoulder bikeway. Where horizontal separation for bicycles and pedestrians existed



prior to work, give consideration to separating during work.

When laying out alternative bicycle paths, make sure no overhead obstructions present a direct hazard to normal bicycle operation.

## **Safety**

The safety and welfare of WSDOT employees is paramount. Injuries are costly in terms of both human suffering and economics. For these reasons, WSDOT initiated the employee safety program over 50 years ago.

Guidelines for maintenance employee safety are contained in the Department's safety manual. Any questions about safety concerns can and should be raised to the employee's supervisor or the regional safety officer. Accidents involving equipment, falls, and other trauma injuries are a major part of worker safety. As the materials and chemicals used in maintenance become more complex, then the risks to employees also increase. Employees must be trained to know the rules, policies and practices intended to promote a safe work environment.

Safety pays dividends on all jobs. A positive attitude toward safety will not only help to protect the employee from injury, but will also lead to continued job satisfaction. Every employee needs to develop the habit of thinking safety before and during the work to be done.

## **Work Zone Operations**

Maintenance operations require employees to be on the alert to protect themselves, fellow crew members and the traveling public. Performing jobs safely is a priority and an integral part of maintenance operations.

The fundamental guide for all staff in the control of maintenance work zones is Part VI of the "Manual on Uniform Traffic Control Devices" (MUTCD).

Work zone safety has two aspects that are sometimes not kept in balance. One is when there is too much pressure for production efficiency. The other is when there is too much fear of liability resulting from a traffic accident. Each maintenance employee, as well as each motorist, is entitled to have a work or traffic environment which is reasonably safe. Every effort must be made to ensure that the most effective traffic control strategy is implemented. This strategy must address the needs and requirements of both the workers and drivers. The development and implementation of a comprehensive traffic control strategy will satisfy the concerns of production and potential liability while providing an effective and safe work zone.

Maintenance employees may have innovative ideas that will create improved flow of traffic through a work zone or better protection of the workers. Make sure to get formal approval from the Regional Traffic Engineer to test and evaluate the idea in the field if it is a deviation from the Maintenance Manual or MUTCD. This will limit WSDOT's liability if a motor vehicle accident occurs during the testing.

## **Enforcement**

Maintenance supervisors should encourage law enforcement officers to patrol through work zones as frequently as possible. The presence of law enforcement personnel near work zones increases safety and motorist compliance with traffic control regulations.

Contractual use of law enforcement in work zones is based on a combination of local knowledge, sound judgment, and the advice of the Regions' Traffic Engineering staff. Consider the type of work activity, complexity of the traffic control plan, possible speed reduction needs, traffic volumes, nighttime work activity, geometric conditions, associated cost for use of enforcement (cost benefit analysis), and actual traffic problems observed as the work progresses.

Refer to Instructional Letter IL 4008.00 for specific guidance on the use of WSP traffic control assistance.

An agreement GC 9131, between WSDOT and WSP exists to keep the payment process consistent statewide. Maintenance offices charge enforcement work to the particular work order number for the control section where the work is done. Contact the Region Traffic Office for assistance with WSP traffic control assistance.

## **Resources for Traffic Control and Work Zone Safety**

The following information may provide additional guidance and more specific detail. This list includes manuals, reference documents and staff mentioned throughout this chapter.

- Work Zone Traffic Control Guidelines M 54-44 (required for each crew)
- MUTCD Part VI (required for each crew)
- Traffic Manual, Chapter 5, M 51-02
- Work Zone Safety Task Force Recommendations
- Quality Standards for Work Zone Traffic Control Devices (ATSSA)
- Work Zone Traffic Control Supervisors Notebook
- Planning and Scheduling Work Zone Traffic Control (FHWA IP-81-6)
- IL 4008.00 WSP Traffic Control Assistance
- Directive D 55-20, Reduced Speed in Maintenance and Construction Work Zones
- Region Maintenance or Traffic Office and Public Information Officer (Traffic Engineer or Traffic Control Specialist)
- OSC FOSSC Traffic Office, State Traffic Control Engineer

## Chapter 3

## Pavement Patching & Repair

---

	Page
General	3-3
Maintenance of Flexible Pavements	3-3
Load & Speed Restrictions	3-4
Pavement Deficiencies	3-4
Rutting	3-4
Alligator Cracking	3-4
Longitudinal Cracking	3-4
Transverse Cracking	3-5
Potholes	3-5
Raveling & Pitting	3-5
Flushing	3-5
Sags & Humps	3-6
Edge Raveling	3-6
Pavement Maintenance Techniques	3-6
Patching	3-6
Patching with Base Repair	3-6
Overlay Patches	3-8
Spreader Box Patching	3-8
Grader Patching	3-9
Rolling Hot Mix Patches	3-9
Effects on Traffic on a Patching Operation	3-11
Crack Sealing (or Pouring)	3-11
Hot Pour Method	3-11
Cold Pour Method	3-12
Maintenance of Rigid Pavements	3-12
Portland Cement Concrete Pavement Crack Pouring	3-12
Asphalt Emulsion Surface Treatments	3-15
Fog Seals	3-15
Sand Seal	3-15
Aggregate (Chip) Seal	3-16
Pavement Conditions for a Successful Project	3-16
Material Selection	3-16
Asphalts and Emulsions	3-16
Common Types of Emulsions Used for Chip Seals	3-17
Aggregate	3-17
Weather	3-17
Roadway Preparation	3-17
Equipment	3-18
Distributor	3-18
Calibration Procedures	3-18
Nozzle Size	3-19
Proper Pressure	3-19
Spray Bar Height	3-22

	<b>Page</b>
Proper Nozzle Angle	3-23
Streaking Will Occur	3-23
Cleaning of Distributor	3-23
Checking the Bitumeter	3-23
Traffic Control	3-24
Application of Asphalt	3-24
Spreading Aggregate	3-25
Chipspreader Calibration	3-25
Chip Spreader	3-26
Rolling	3-26
Spreading of Fines or Choking Optional	3-27
Post-Seal Inspection	3-28
Do's of Seal Coating	3-28
Do Not's of Seal Coating	3-29
Blade Mixed Asphalt Mix	3-29
Handling Emulsified Asphalts	3-30

### General

The roadway is the paved or otherwise improved portion of a public highway ordinarily used for vehicular travel. The roadway surface is normally classified as rigid (consisting of Portland cement concrete) or flexible (consisting of asphaltic materials).

A smooth surface with good skid resistance, free of alligator cracks, pumping, pushing, wheel rutting, raveling, frost heaving, and pot holing, is desirable for safe travel by the people we serve.

Maintenance of the state's roadways must include a program to preserve these characteristics. Ideally, the maintenance of pavement should be accomplished with minimum expense and with the least possible traffic disruption. Maintenance of pavements is a necessary investment made to protect the pavement from costly renovation or reconstruction.

Preventive maintenance is much more cost effective than performing major repairs. Area maintenance staff are required to inspect each section of highway at least once a year to detect and schedule deficiency repairs prior to their becoming a major problem.

A biennial appropriation corresponding with a specific, (LOS) Level of Service for roadway maintenance and operations activities is provided by the Washington State Legislature. The maintenance area's roadway surface program should be managed to meet these LOS commitments. In doing so, it is essential that each Area work with its Program Management, Design and Construction offices to ensure that the work being planned is coordinated with the work that these offices are planning and/or constructing.

It is advised that written recommendations for pavement repairs be submitted to the Regional Maintenance Engineer. The Regional Maintenance Engineer then shares the region wide roadway surface maintenance program with the Regional Construction Engineer. This allows better coordination between the maintenance and construction programs.

Pay special attention to the drainage of roadway sections when planning maintenance activities. Poor drainage can lead to premature aging of the roadway surface and sub-grade.

Work zone safety and traffic control are extremely important. Maintenance employees are required to know and closely follow the chapter in this manual on traffic control and safety.

### Maintenance of Flexible Pavements

Flexible pavements generally are referred to as asphaltic concrete pavement (ACP) or bituminous surface treatment (BST). Flexible pavements develop strength from the tight interlocking of crushed rocks with an asphalt material binding them together. This mixture deflects when loaded by traffic and exerts pressure on the subgrade. Consequently, both the pavement and the subgrade must be in good condition to avoid maintenance problems.

## **Load & Speed Restrictions**

If the subgrade temporarily lacks strength to carry heavy loads due to excess moisture and/or thawing, any class of vehicles can be restricted by weight and/or speed. Maintenance staff must monitor the roadway condition during threatening weather conditions. Take action according to directive D 54-43 (MR), Emergency Restrictions for Roads, before the subgrade becomes saturated and soft. This will avoid unnecessary stress which can lead to permanent damage.

Restrictions should be no more severe or of longer duration than necessary to protect the roadway. Consider the economic effect to the users. The damage caused by failure to place restrictions on soft roadways can have a severe effect on a maintenance budget and their ability to meet LOS targets.

## **Pavement Deficiencies**

Damage and deterioration of pavements will become apparent in a variety of ways. A number of factors can contribute to the appearance of pavement deficiencies. For example, an overlay with excess asphalt or poorly graded or inadequately fractured paving material may not have adequate particle interlock; thus pushing, rutting, & humps may develop. Poor subgrade drainage, heavy tonnage, and accelerating or decelerating traffic are all potential sources of surface irregularities. Pavement deficiencies are explained in more detail as follows:

### **Rutting**

Rutting is a surface depression within the wheel path and is a result of permanent deformation of the pavement or subgrade. This condition is normally caused by heavy loads on roads lacking sufficient strength to support the loading. In some cases, rutting can also be caused by studded tire use. Wheel ruts, if not repaired, can trap water and cause hydroplaning.

### **Alligator Cracking**

The condition known as alligator cracking is attained when discontinuous longitudinal cracks begin to interconnect to form a series of small polygons that resemble an alligator's skin. This distress is usually caused by poor drainage, poor mix design, or subgrade failure.

Ideally the surface should be treated with a seal coat or overlaid with suitable material before water has an opportunity to penetrate the surface and lead to alligator cracking. If it is neglected and alligator cracks appear, heavy traffic can push the surfacing rock into the wet soil beneath it. This forces mud up through the asphalt surface (pumping) causing permanent damage that can not be repaired by a seal or overlay. Spots where severe pumping has occurred will often need to be dug out, and the base rock, surfacing rock, and asphalt replaced.

### **Longitudinal Cracking**

A longitudinal crack follows a course approximately parallel to the centerline. These are typically resultant of natural causes or traffic loading.

## **Transverse Cracking**

Transverse cracks run roughly perpendicular to the roadway centerline. They may be due to surface shrinkage caused by low temperatures, hardening of the asphalt, or cracks in underlying pavement layers such as PCCP slabs. They may extend partially or fully across the roadway.

## **Potholes**

Potholes are voids in the roadway surface where pieces of the pavement have become dislodged. Areas in which many potholes occur become suspect for fundamental problems such as inadequate drainage, pavement strength, or base/subgrade problems. Single or infrequent potholes may be the only pavement distress to occur in an area, and beyond the treatment of the individual pothole no other pavement repair work may be required.

The location of potholes which receive a temporary fix should be documented so they are addressed as part of the Area's annual permanent fix program. The number of potholes that appear in the wet or winter seasons is often an indicator of the effectiveness of the permanent fix program.

## **Raveling & Pitting**

Raveling and pitting distresses are characterized by the loss or dislodgment of surface aggregate particles. Oxidized asphalt binder is often the cause of raveling and pitting. It could also be caused by poor compaction, letting the mix get cold when paving, dirty aggregate, not enough asphalt in the mix, overheating the mix during manufacture, or aging.

Routine maintenance repairs are made to raveled or pitted surfaces as soon as conditions permit and/or materials are available. The most important consideration in scheduling repair of raveled or pitted areas is to perform the repairs before a more serious condition develops, and prior to the onset of inclement weather.

Open grade pavements that allow water to drain through and out the side don't need to be sealed if they are properly constructed. But, pavement that is raveling must be sealed. Unsealed pavements will continue to ravel and will also age and harden at a much faster rate than normal. This condition may also encourage the loss or stripping of the asphalt within the pavement. Timely sealing can add significantly to the life of the pavement. Open grade pavements should be fog sealed on a schedule recommended by the Region Materials Engineer. Failure to do so can lead to premature failure of the open grade mat and lead to difficult maintenance problems.

## **Flushing**

Flushing (or bleeding) is free asphalt on the surface of the pavement caused by, too many fines in the mix, too few voids, too much asphalt in patches, or a chip seal that has lost its rock. This type of distress often shows as a shiny, glass-like reflective surface. It is inherent to unstable mixes and often results in other roadway surface distresses if not corrected.

Removal and replacement of flushed or bleeding pavement areas is an expensive, but sometimes cost-effective method of repair. Thin overlays of flushed or bleeding areas will frequently have the “fat spot” show through in hot weather and exhibit the same characteristics as in the “before” condition. If repairs are not possible prior to a seasonally wet period, contact the Regional Traffic Engineer to evaluate the need for posting “Slippery When Wet” signs.

## **Sags and Humps**

Sags and humps are localized depressions or elevated areas of the pavement that result from settlement, pavement shoving, displacement due to subgrade swelling, or displacement due to tree roots. The deficiency usually occurs in isolated areas of the roadway surface.

## **Edge Raveling**

Edge raveling occurs when the pavement edge breaks and is most commonly found on those roadways that were constructed without curbs or paved shoulders.

## **Pavement Maintenance Techniques**

### **Patching**

All flexible pavements require patching at some time during their service life. Surface patching should be performed to a standard commensurate with resource availability and the objective of retaining a smooth ride as long as possible. Since patching materials are one of the larger material costs a high quality patch is one of the most cost effective means of utilizing available resources.

There are two principal methods of repairing asphalt pavements:

1. Remove and replace the defective pavement and surfacing or base material.
2. Cover the defective area with an overlay of a suitable material to renew the surface, seal the defective area, and stabilize the affected pavement.

These repairs can be called ‘dig-outs’ or ‘overlays’ according to the method used.

### **Patching with Base Repair**

‘Dig-out patches’ are used for making permanent repairs to the pavement. Defective pavement and unstable surfacing materials are removed down to a stable base. This may mean removal of some of the subgrade material. The excavated area should extend into the good pavement around the defective area by about 12 inches. Cut the edges of the patch area vertically and in straight lines to provide a good line for compaction later. A pavement saw makes a good tool for a fast, neat cut in pavement patching.

After the cut is made and the defective pavement and/or base material is removed, level and compact the base material. This will make an adequate foundation for the new asphalt concrete material. Surfacing materials (gravel base, crushed surfacing) and pavement must always be replaced in depths at least equal to the original design or by additional depth of ACP compacted in lifts of (1) to (3) inches. Apply a tack coat of asphalt to the vertical sides of the hole to assure a good bond and



seal between old and new pavements.

For best results in a patch of this nature, back fill the hole with a hot plant-mix material such as Asphalt Concrete Class B. The asphalt should be compacted in lifts of no more than 3 inches thick to obtain optimum patch life. Small patch projects can be compacted with a vibrating plate compactor, while a roller works best on large patches. During hot weather it might be advantageous having some water on hand to help cool the mix between lifts. Standing water should not be allowed on the mix between lifts.

After the intermediate lifts of the patch have been compacted sufficiently, the surface lift can be completed. Take special care to ensure that it is compacted to be even and flush with the surrounding surface, so it provides a good riding surface. Some compaction will occur by traffic as the mix is further kneaded into place. The patch should be cool enough before traffic is allowed on it, so it will not leave marks in the surface. Deeper patches will require more time to cool and must be planned for accordingly.

Potholes and localized failures should be repaired as soon as possible after they are reported. Asphalt pre-mix (cold mix) should be available throughout the year so any potholes that appear can be patched immediately. Fiber reinforced, and other specialized 'winter mix' have been found to be effective in many locations. Many times the use of a propane torch to dry the holes and heat the mix for good compaction is time well spent.

The use of an asphalt 'tack' is highly recommended. A higher success rate is normally achieved when they are squared up and tack is added to the edge of the pothole. If the lack of availability or storage of standard tack is a problem, try using one of the cold pour crack pouring materials. They are available in (5) gallon buckets with a pour spout. Many pothole patching crews use this as standard procedure.

Don't use sand, clay, or other temporary patching material to patch or "pad" potholes or frost boils. On today's roads these methods usually cost more in the long run and often leave unsafe conditions for the traveling public. Asphalt pre-mix is the preferred method, even if it has to be replaced when final repairs are made.

For permanent pothole patching proceed as follows:

- Remove the defective material down to a stable base
- Square off the edge of the hole vertically
- Dry the hole as much as possible (fiber reinforced mix often does well in wet holes).
- Tack the hole if possible
- Place and compact the mix

Compaction is very important in making the repair permanent (heat applied to the mix is very beneficial to good compaction). If traffic is picking the fresh mix out of the hole try dusting the finished patch with some roadside dirt. Spend a little more time patching the pothole the first time. This will often keep you from returning to patch the same hole repeatedly. Permanent repairs are normally made with hot mix if available.

## **Overlay Patches**

Overlay patches are generally applied when an area is too large to be economically repaired by hand with a small crew. The overlay patch, with hot plant-mix asphalt, also has the advantage of setting quickly. It does, however, commit a considerable investment in labor, equipment, and materials.

Typically, overlay patches are applied in areas of pavement failure or wear problems rather than areas with a base or subgrade problem. Ruts, raveling, pitting, minor cracking, and oxidation are typical failures where overlay can be effective in quickly and permanently restoring the surface. When addressing pavement rutting, mix should be placed in lifts when patching rutted areas in order to get uniform compaction. This method of compaction will help prevent the rut from reflecting into the finished patch. To obtain proper compaction in the wheel ruts, a rubber tired roller should be used. Steel wheel rollers will bridge the rut and very little compaction will occur. After the ruts are filled and if it is decided to overlay the entire lane then a steel wheel roller would be used for compaction.

Application of any overlay patch requires a considerable degree of skill, coordination, and planning. All loose, broken asphalt should be removed and replaced. Any deep ruts, depressions, or humps should be repaired or pre leveled in advance of the overlay so that the overlay may proceed efficiently. It is necessary to repair these areas prior to the overlay in order to provide an even platform for the new pavement. This is essential to proper compaction and consequently to pavement life. If, for instance, wheel path ruts are overlaid without pre leveling, the ruts will not get the same compaction from rolling that the thinner high spots will. Then traffic wheel loads will eventually compact the deeper new sections, causing ruts to reappear. All areas should be tacked before patching to ensure a good bond and minimize raveling in thin areas. The tack rate should be 0.4 to 1.4 gallon per square yard of applied tack (0.2 to 0.8 residual).

Be careful when repairing the roadway surface in an area of unpaved shoulders. Widening over thin gravel or dirt shoulders will usually lead to cracking and failure. This is because of the lack of sufficient top course material. If there is the need to widen the paved roadway, make sure the shoulder is prepared properly to support the anticipated loading.

## **Spreader Box Patching**

On small paving jobs it is often convenient and economical to use a tow-behind paver, or spreader box. These pavers hook to the rear of the trucks that are hauling the mix. The asphalt is dumped directly in the hopper of the paver which places it on the roadway or base material.

As the towing vehicle moves ahead, the mix is struck off by an adjustable height blade (cutter bar or screed) and is surface-finished by the screed. Starting the paving at full depth requires setting the screed on blocks before filling the hopper. The hopper should be kept uniformly full during paving to ensure an even spread. An even towing speed is necessary to maintain a uniform spread thickness.

Spreader boxes vary greatly in size, operating controls, accessories, and capabilities. Working with them requires skill and experience. Manufacturers and construction equipment dealers can provide assistance in the operation and care of particular models.

Clean-up of equipment and tools after each day's operation is essential to good patches. This is

especially true of the spreader box. It must be kept free from the accumulation of cold asphalt. Diesel is generally the most common and effective release agent used for cleaning tools and equipment. However, the diesel-asphalt waste mixture must be captured (i.e. not allowed to spill on the ground) and placed into (55) gallon containers for disposal as a "Dangerous Waste". A "Dangerous Waste" label should be placed on the waste container and the date entered as to when the accumulation began.

Spreader box patching with hot plant-mix material has the advantage of providing a smooth finished surface, when the equipment is properly operated. Several people are required to operate a spreader box efficiently. Careful planning of the patching operation is very important to economical and cost-effective pavement maintenance. The spreader boxes can work well if surface irregularities are pre-leveled with equipment appropriate for the conditions. The entire surface should be tacked, both before preleveling and before starting the spreader box patch.

Rolling of the hot plant-mix should begin immediately after placement of the mix. If the mix is allowed to cool below 185 degrees before rolling, adequate compaction will not be possible.

## **Grader Patching**

Road graders are a useful pavement patching tool. These graders vary in size, model, and capabilities depending on their intended use.

One efficient way of blade patching is using two graders facing each other. This method is quicker than the single blade method, and can help in getting the patch laid before the mix gets cold. It helps keep coarse mix away from the ends of the patches, making smoother approaches, and helps keep a straighter edge. Also, a two grader operation offers a good opportunity to train inexperienced grader operators.

Hot plant-mix patching with graders is frequently accomplished when it is not practical or economical to use other means. Gradgers are especially valuable for leveling to eliminate sharp depressions or sags and to lay a leveling course of pavement prior to placing finish courses with asphalt spreader boxes. They are excellent to place a leveling course to restore the roadway grade and shape when it cannot be done with a paver or spreader box. All of the area to be blade patched should be tacked. Road graders with a long wheel base and smooth-tread tires are often used for spreading hot plant-mix asphalt in leveling operations. The roller must follow the grader immediately after the mix is spread while it is still hot.

Graders are not efficient at carrying large quantities of material over long distances, so the dumping of asphalt should be carefully controlled for an efficient operation. A dump person should be utilized. Make as few passes as possible with the grader to reduce segregation of the material.

## **Rolling Hot Mix Patches**

It is always desirable to use the most effective tools for the job at hand, including asphalt work. The use of a finish lute person on the patching crew is highly desirable. The quality and ride of the patch is often much better due to their expertise. If short handed, consider borrowing people from an adjacent section so you can provide a quality product. Since patching is one of the most expensive

operations to perform, it is essential to develop work schedules that ensure the following are present: desirable weather conditions, adequate staffing and proper equipment.

A ten ton or larger steel-wheeled roller is valuable to an efficient asphalt patching operation. A lighter vibratory roller is a poor substitute, as it can slow the operation considerably. On larger paving projects, one roller may be used to do the breakdown rolling or initial compaction, with another used for the finish rolling.

The patching operation should match the speed of the roller. If the patching crew outpaces the roller, it forces the rolling of mix that is too cold and a poorer quality patch can result. If the operation needs to move faster and the roller can't keep up, use a larger roller or a second roller. Do not compact hot mix asphalt concrete at a temperature below 185 degrees F. Rolling mix that is too cold can cause it to crack. Rolling mix that is too hot can cause pushing. The maximum temperature of mix from the plant is 350 degrees.

Compaction is among the most important phases of the operation. All asphalt concrete patches, small or large, must be compacted to consolidate the material. The properly compacted asphalt patch will be tough and dense and will stand up to the wear of traffic and weather much better than if compaction is inadequate. However you compact the mix, do it well; it is very important.

Rolling for compaction should begin as soon as the paving material is laid. The initial rolling or "breakdown" gives the highest percentage of compaction of any rolling phase. Consequently, it also offers the most potential for material displacement at the edges. It is important to make the initial breakdown pass at least 4 inches away from the edges of the mat. A subsequent pass will level this edge.

Avoid stopping the roller or reversing direction on the hot mat. Do not turn on the mat while moving. This can affect the ride of the patch.

Intermediate rolling further compacts and seals the surface. Finish rolling removes any roller marks and other blemishes left by prior rolling.

Various roller types are used in asphalt compaction. Steel-wheeled, vibratory, and pneumatic tired are the types most commonly available. Steel wheeled and vibratory rollers are used for all three phases of asphalt rolling. Vibratory rollers should not be operated on thin lifts and so are not generally used in maintenance patching operations. Rubber-tired rollers are not normally used in maintenance operations.

All rollers used in asphalt paving or patching operations should be:

- In good operating condition.
- Used according to the manufacturer's recommendations.
- Capable of reversing direction without backlash.
- Able to operate at speeds low enough to avoid displacement of the hot asphalt.

Do not use rollers producing pickup, washboard, uneven compaction, or otherwise undesirable effects. Vibratory rollers under vibration should not exceed (3) mph. Steel-wheeled rollers should be limited to (4) mph and pneumatic tired rollers to (5) mph maximum. The drive wheel of the roller should always be pulling the roller to prevent displacement and pushing of the material. This is

particularly important on steeper grades and in breakdown rolling passes.

## **Effects of Traffic on a Patching Operation**

Timing is critical while doing hot asphalt mix patching. Cold asphalt mix yields inferior patches. Flaggers must avoid delaying asphalt trucks and paving equipment while hot mix patching. Don't let traffic drive on any unrolled mix. A finished patch should be cool enough to hold your hand on before traffic is allowed to drive normal speeds on it. A pilot car offers a big advantage for multiple patches over an extended section of roadway. The use of a third flagger to keep traffic off the unfinished mix and away from the equipment is desirable. Traffic striping that is blacked out or covered should be remarked the same day for safety reasons.

## **Crack Sealing (or Pouring)**

There are significant costs involved in filling cracks, both for materials and labor, the supervisor needs to be aware of the nature, extent, and severity of the cracking problem and also of the next scheduled contract for resurfacing. Filling cracks in an area scheduled for immediate reconstruction or resurfacing by contract is not recommended unless it is a part of the overall project. Minor repair and crack sealing is often part of the contractor's responsibility. However, sealing minor cracking may extend the useful pavement life for several years when an overlay project is not scheduled.

Generally, alligatoring or more general cracking can be repaired most cheaply by chip seals. Serious cracking and settlement of the pavement may indicate the need for excavation to repair the subgrade before patching can be successful.

The main purpose of crack pouring is to prevent water from entering the subgrade and causing damage. There are two widely used types of crack pouring material in highway maintenance, hot pour and cold pour. The two types use different techniques and equipment. The purpose of the two is the same, to minimize water entry and resulting damage.

Over-poured cracks can be a safety hazard to motorcycles. Overband (over-poured) crack pouring, especially on longitudinal cracks, can cause loss of control for motorcycles. The problem is compounded on curves or when the surface is wet. Cracks that are not over filled do not seem to cause a problem. Areas that have excessive crack pouring material from past practices should be addressed.

## **Hot Pour Method**

This method utilizes blocks of crack pour material heated in specialized crack pouring machines. The most common type in maintenance are trailer mounted, oil jacketed units. This method is often used by contractors and maintenance crack sealing distressed areas that are not going to be removed and repaired prior to an overlay. It is a common method of sealing the joint between the edge of a PCC road surface and the asphalt shoulder. It works well for large volume work involving large cracks. Often the cracks are routed out first. If not, they should be cleaned and dried with compressed air prior to pouring. Filling cracks with this method requires a large crew and specialized equipment.

Safety is a big concern in a hot crack pour operation. This material is extremely hot and can cause

severe burns when loading the machine or applying the material.

## **Cold Pour Method**

This method utilizes cold applied liquid material and does not require specialized equipment. This type of material is available in five gallon to fifty gallon containers. It can be sanded lightly after application and opened to traffic. One person can apply it using the spout on the five gallon bucket it comes in.

Experience has shown that for maintenance purposes cold pour seems to prevent water entry into the subgrade as well as hot pour material. It also resists build up on bumps better than the hot material does.

Cold pour is excellent as tack for small asphalt patches and pothole repairs. It greatly simplifies the problems of tack storage, transporting, and application. A sealed five gallon bucket can be carried easily by a pothole patching crew.

This material works well for hand pouring the cracks around an isolated bridge drain or catch basin if a piece of foam 'backer rod' is poked down into the crack before pouring to serve as a bottom for the material. It can also be poured against rubber expansion joints without melting the rubber joint.

## **Maintenance of Rigid Pavements**

Rigid pavements are generally referred to as Portland cement concrete pavement (PCC). PCC pavements should be patched with Portland cement concrete or one of the WSDOT approved patching materials. Prepare and apply patching materials according to the manufacturer instructions. If recommended by the patching material manufacturer, use a bonding agent.

The PCC surface to be repaired should have all loose material removed down to solid material or to full depth if necessary. A jackhammer or similar equipment may be necessary to remove some of the material in the area to be patched. The area to be repaired needs to be squared by concrete sawing, then sand blasted, cleaned and dried.

Delamination occurs when a thin layer of surface concrete has lost bond with the underlying concrete. The area around the patch should be checked for delamination. Tapping on the surface with a hammer and listening for a hollow sound is one way to find the delaminated areas.

If reinforcing steel is encountered, remove or neutralize all rust. Coat exposed reinforcing steel with a WSDOT approved product to prevent rust from reoccurring. Then proceed with patching the area.

Traffic should be kept off the new patch as specified by the manufacturer, until it gains sufficient strength to support traffic.

## **Portland Cement Concrete Pavement Crack Pouring**

Joints in Portland cement concrete pavements (PCC) compensate for thermal movements of the pavement and provide load transfers between slabs. Properly sealed joints in concrete pavements

prevent water from entering into and weakening the underlying base and subgrade materials. Properly sealed joints also prevent incompressible materials such as dirt and gravel from penetrating into joints, which then restricts thermal joint movements. Materials that restrict the natural expansion of the pavement joints can cause diagonal slab cracking, slab blowups, or tipping and spalling.

PCC joints and cracks should be checked before the wet season to make sure they are sealed to prevent entry of damaging water.

Even fine cracks in steel reinforced slabs can be serious. They can allow water or chlorides to reach the steel causing corrosion and serious damage.

PCC crack pouring is most effective when the pavement is cold and has contracted and opened the cracks. Don't pour cracks when the pavement temperature is below 45 degrees. Always use WSDOT approved crack sealant material.

Cracks must be routed out before pouring. If not, they should be cleaned and dried with compressed air prior to pouring. Foam backer rod can be used in larger cracks to keep the sealant in the top (1) inch of the crack.

Safety is a big concern in a hot pour operation. This material is extremely hot and can cause severe burns when loading the machine or applying the material.

#### **ASPHALT CONCRETE PAVING QUANTITIES (TONS/100 LIN FT)**

WIDTH (FT)	DEPTH OF MIX (COMPACTED)					
	1 "	2 "	3 "	4 "	5 "	6 "
2	1.2	2.4	3.6	4.8	6	7.6
4	2.5	5	7.5	10	15	15.2
6	3.8	7.6	11.4	15.2	19	22.8
8	5	10.1	15	20	25	30.4
10	6.3	12.6	18.9	25.2	31.5	38
11	7	14	21	28	35	42
12	7.6	15.2	22.8	30.4	38	45.6
16	10.1	20.2	30.4	40.6	50.7	60.8
18	11.4	22.8	34.2	45.6	57	68.4
20	12.4	25.2	37.2	49.6	62	76
22	14	28	41.8	56	70	83.7
24	15.2	30.4	45.7	60.8	76	91.3

Mix Quantities in Patches		
MIX CLASS CLASS A	SIZE 5/8"-0"	higher grade mix, more fractured rock, has good strength
CLASS B	5/8"-0"	standard mix in many areas
CLASS D	3/8"-0"	open grade mix, used in thin overlays, can ravel bad as it ages
CLASS E	1 1/4"-0"	coarse mix
CLASS F	5/8"-0"	lower grade mix, less fracture, more round rock, contains more fines & has less strength
CLASS G	3/8"-0"	fine mix, good for wheel ruts & skin patches
ASPHALT TREATED BASE MIX	2"-0"	specs allow down to 1/2" maximum size rock

#### CLASSES OF ASPHALT CONCRETE PAVEMENT (ACP)

#### Sources for Additional Pavement Maintenance Information

Asphalt Institute publications:

MS-4	The Asphalt Handbook
MS-5	Introduction to Asphalt
MS-8	Asphalt Paving Manual
MS-14	Asphalt cold-Mix Manual
MS-15	Drainage of Asphalt Pavement Structures
MS-16	Asphalt in Pavement Maintenance



MS-17 Asphalt Overlays for Highway and Street Rehabilitation

MS-19 Basic Asphalt Emulsion Manual

WSDOT Publications:

Standard Specifications for Road, Bridge, and Municipal Construction (M 41-10)

Construction Manual (M 41-01)

Design Manual (M 22-01)

## **Asphalt Emulsion Surface Treatments**

Preventive maintenance programs started early in life of a pavement (1-3 years) provide the protection needed to greatly improve service life. For aged pavements, surface treatments can delay the costs of major reconstruction. Asphalt emulsion surface treatments are excellent for preventing the development of early pavement damage or distress. The surface treatment seals the pavement, retards the aging process and prevents the old pavement from further hardening. One method of sealing minor cracks and providing a renewed roadway surface is called Bituminous Surface Treatment (BST). BST is used to seal small cracks, repair a dry raveling surface and provide a skid resistant surface.

## **Fog Seals**

In instances of a pavement with very minor raveling, a fog seal may adequately seal the pavement and prevent further raveling. Fog Seals are very light applications of diluted, quick breaking asphalt emulsions. Some of the asphalt materials used for fog seals are: CSS-1 and STE-1 which are cationic (positively charged) emulsions, while HFE-100S-50% diluted is an Anionic (negatively charged) emulsion. These products may require cover material (1/4 - 0) depending on the surface and application rate. The decision whether to use a cationic or anionic formulation should be based on knowledge of the charge of the existing materials used as part of the pavement. Understand that like charged materials repel each other and opposites attract. We want the materials to attract each other and make a tight bond. The Region or the Headquarters Materials Lab can assist in the determination.

Asphalt emulsions used for fog seals are usually diluted 50% with water or other types of cut-backs as prescribed by the manufacturer. The Fog Seals are applied at the rate of 0.1 to 0.2 gallons (of diluted material) per square yard, depending on the texture and porosity of the old pavement. The application rate will be determined by the amount of emulsion the old pavement surface can absorb without becoming slippery. Traffic control may be required for up to two hours, depending on location and volume of traffic.

## **Sand Seal**

Where more raveling has occurred, a sand seal may be needed to adequately seal the surface and provide a quality surface. A sand seal is an application of liquid or emulsified asphalt covered with

fine aggregate. It is used to seal against air and water infiltration, or improve skid resistance. Applications are 0.1 to 0.2 gallons of CRS-2 or CMS-2 per square yard covered with ten pounds of 3/8 minus aggregate. Some regions have found 1/4 minus to be better suited for sand seals.

## **Aggregate (Chip) Seal**

If the raveling becomes more advanced, an aggregate or chip seal may be needed. In cases where raveling is allowed to progress to the point where the ride is affected, a thin overlay, or pre-leveling followed by a chip seal, might be needed. An aggregate seal is a single spray application, usually of a liquid or emulsified asphalt. Immediately following is a single layer of aggregate of as uniform a gradation (size) as practicable. This type of seal reduces the infiltration of air and water into the mat and may be used to improve skid resistance of slippery pavements.

Chip seals are useful and can be applied in many different ways: Full lane width, partial lane width, short longitudinal sections or for long sections.

A typical example of a BST uses application rates for CRS-2 or HFE-100S at .40 to .60 gallons/per square yard with 30 to 40 pounds of 5/8 - 1/4 Crushed Cover Stone per square yard. Look in the Standard Specification Manual, section 5-02, 9-02, and 9-03.4 for additional information on Bituminous Surface Treatment and materials.

## **Pavement Conditions for a Successful Project**

Prior to sealing thoroughly, examine the roadway surface. Then decide what kind of repair is needed. A chip seal does not add to the structural integrity of pavement. Therefore, the existing pavement must be structurally sound in order to obtain a long performance life. Existing pavements may have to be repaired; patched, crack sealed and then allowed to cure before a chip seal can be applied. Always clean the existing roadway surface before starting the chip seal process.

Since chip seals follow the original profile of the pavement, they do not correct surface irregularities. Chip seals cannot be used on pavements with more than 3/8" to 9/16" of rutting. Aggregates in the ruts can not be fully compacted. Cleaning loose aggregate from the rut with a power broom will dislodge the aggregate from the non-rutted area. If the surface has light-to-moderate bleeding, the binder application rate should be reduced. Don't use a chip seal on pavements with a high severity of bleeding.

## **Material Selection**

### **Asphalts and Emulsions**

The two general types of asphalt for seal coating are liquid asphalt and emulsified asphalt. Liquid asphalts are graded by viscosity. SC-Slow Cure-70, MC-Medium Cure-70, RC-Rapid Cure-70, have the lowest viscosity. SC, MC, RC 3000 have the highest viscosity. Liquid asphalts are also graded by the type of solvent used to thin them: SC with light oil, MC with kerosene, and RC with naphtha cutback. MC 3000, RC 3000, or RC 800 are the liquid asphalts used for chip sealing. Emulsified asphalts are manufactured by suspending asphalt particles in water with the aid of an emulsifying agent. Asphalts for Bituminous Surface Treatment are listed in the Standard Specification Manual. (9-02)

## **Common Types of Emulsions Used for Chip Seals**

CRS-2 (Cationic Rapid Set Emulsion) is one of the most widely used emulsions. This emulsion will run into wheel ruts and down super elevated roadways if applied at rates above 0.4 gallons per square yard. CRS-2 provides a good seal on low volume highways.

HFRSP2/HFE-100S (Anionic Styrelf Polymer High Float Emulsion) is used for chip seals. It is a rapid setting emulsion that binds the chips very fast and can be used on high volume roads. This product should not bleed under high pavement temperatures.

## **Aggregate**

Aggregate for bituminous surface treatment must conform to the requirements in the Standard Specifications Manual 9-03.4 for grading and quality. The material must meet the requirements for grading and quality when placed in hauling vehicles for delivery to the roadway. During manufacture and placement into a temporary stockpile the exact point of acceptance will be determined by the Engineer or Area Superintendent. The finished product shall be clean, uniform in quality, and free from wood, bark, roots, and other contaminants. Crushed screenings must be substantially free from adherent coatings.

## **Weather**

The best time of year for a seal coat is when the weather is hot and dry during, and for some weeks after, treatment. Specifications require the air temperature in the shade to be at least 60 degrees Fahrenheit before work begins. No matter what the temperature of the asphalt when sprayed, it will cool to the temperature of the pavement surface in one minute. BST treatments should be placed between May 15th and August 15th for best results.

Never start a BST when the surface is wet or when it is threatening to rain. If the fresh seal gets wet, the combination of water, fresh seal coat, and traffic will result in loss of the cover aggregate.

## **Roadway Preparation**

The surface should be thoroughly cleaned of all loose materials prior to application of asphalt. Sweep the roadway surface before starting the job. This allows the dust to be either flushed with water or blown off the roadway surface by traffic.

If patching is needed, allow time for the patch material to cure prior to sealing. Generally, two weeks should be allowed for hot mix to cure. Allow six weeks at temperatures of 50 degrees to 60 degrees Fahrenheit for cold mix to cure. To preserve the centerline location place flexible reflective markers prior to the seal. These can also be used to indicate the beginning and end of no passing zones. Flexible reflective markers have a removable cover so that they retain their reflectivity after the seal. They will also function as guidance for the striper truck.

## **Equipment**

Before any work begins, examine all equipment to ensure it is in good working condition. Check spreader boxes or aggregate spreaders to see they are in proper working order. The roller operator should make sure that each tire on the roller is equally inflated to correct pressure and that controls for steering, starting, and stopping operate smoothly. All tires should be the same size and the water spray and scraper system must be checked to ensure material does not bond to the tires.

## **Distributor**

New distributors use a ground speed control sensor and computer to regulate material application rates. Set the computer to the desired rate and the application will be correct even if the vehicle speed varies.

Older distributors are equipped with hydrostatic drive systems. The hydrostatic drive consists of a variable output pump driven by the truck power take off (P.T.O.). This in turn drives the distributor asphalt pump with a hydrostatic motor. Once the correct ratio between ground speed and pump flow rate is established for a given transmission setting, the truck ground speed may be varied without affecting the application rate. The operator needs a dry run to establish correct ratio between pump flow rate and ground speed.

Determine from the road computer (Slide Rule) the correct ground speed (F.P.M.) and pump flow rate (G.P.M.) for the desired spray bar length (FT.) and application rate (GAL/SQ.YD.). Follow the correct operation procedures set up in your distributor manual for calibration.

## **Calibration Procedures**

### **DISTRIBUTOR CALIBRATION**

Step 1 - Calculate how much material is in the holding tank.

The following methods work to calibrate an older distributor and calculate the application rate.

Method 1 - Determine the number of gallons in the distributor. This can be done by several methods. The first and most accurate is to weigh the distributor before loading and after loading. Subtract the weights and divide by the pounds per gallon the emulsion weighs. This equals the total gallons.

Method 2 - Find a level spot (the distributor tank must be level). Use a dip stick to dip the tank. Measure the number of inches covered with asphalt. After you know the size of the tank, you can calculate the number of gallons in the tank.

Method 3 - Use the meter on the distributor tank. This is a good method for checking the above calculations but is **not recommended** for calibrating purposes.

Methods 1 and 2 are recommended for Measuring Distributor Tank (MDT) equipment prior to the

start of the project.

**Step 2** - Apply asphalt to a known distance (minimum 200 feet) and established width.

**Step 3** - Determine the total square yards covered with emulsion. This can be done by doing the following calculation:

$$\frac{\text{Length Traveled (feet)} \times \text{Width Covered (feet)}}{9} = \text{Square Yards}$$

**Step 4** - Determine the number of gallons remaining on the distributor. Again use Method 1 or Method 2 explained in Step 1.

**Step 5** - Subtract the total gallons on the distributor originally from the total gallons left on after applying asphalt. This will give the gallons used.

**Step 6** - Divide the total gallons used by the total square yards covered:

$$\frac{\text{Total Gallons}}{\text{Total Sq. Yd.}} = \text{Gallons/Sq. Yd.}$$

**Step 7** - To check your application rate on the project, follow the same steps except use Method 3 outlined in Step 1 to determine the number of gallons on the distributor.

## **Nozzle Size**

The spray bar and nozzles are an important part of the distributor. The proper quantity of asphalt must be spread uniformly on the road surface through the spray nozzles. To achieve good results, correctly sized nozzles must be selected for the job conditions. For example: if nozzles are too large for the desired application, pulsation of the spray may occur, resulting in uneven longitudinal spreading of the asphalt.

Each equipment manufacturer has specific recommendations for the size of spray nozzles to be used for different applications. Use the manufacturer's recommendation when choosing the correct nozzle size. All nozzles selected for use at any one time should have the same size opening.

## **Proper Pressure**

The spray bar must have a constant, uniform pressure along its entire length for equal output from all nozzles. Be sure the spray bar and nozzles are CLEAN.

Although several methods are used to maintain pressure, distributors use gear-type pumps to deliver asphalt to the spray bar. Pressure is governed by variable pump speed on some distributors and by constant pump speed and a pressure relief valve on others. Each application should be checked, as recommended by the manufacturer.

The correct pump speed or pressure are critical to the proper application of the asphalt. Too low a

pressure will result in a non-uniform discharge/streaking of material from the individual nozzles. Too high a pressure, in addition to atomizing the asphalt, will distort the spray fan.

When a metering system is used, the manufacturer supplies the distributor with charts for finding the proper pump speed for each application rate.

When a pressure relief valve is used, the pump runs at a constant speed and the pressure is automatically held in the spray bar. The manufacturer supplies charts for determining the discharge in gallons per minute for each size nozzle, the proper truck speeds for various application rates, and the corrections for temperature-viscosity variations.

# GALLONS OF EMULSIFIED ASPHALT REQUIRED PER 100 LINEAR FEET: VARIOUS WIDTHS AND RATES

Gall. Per Sq. Yd.	WIDTH—FEET														
	1	2	6	7	8	9	10	11	12	14	16	18	20	22	24
0.10	1.1	2.2	6.7	7.8	8.9	10.0	11.1	12.2	13.3	15.6	17.8	20.0	22.2	24.4	26.7
0.15	1.7	3.3	10.0	11.7	13.3	15.0	16.7	18.3	20.0	23.3	26.7	30.0	33.3	36.7	40.0
0.20	2.2	4.4	13.3	15.6	17.8	20.0	22.2	24.4	26.7	31.1	35.6	40.0	44.4	48.9	53.3
0.25	2.8	5.6	16.7	19.4	22.2	25.0	27.8	30.6	33.3	38.9	44.4	50.0	55.6	61.1	66.7
0.30	3.3	6.7	20.0	23.3	26.7	30.0	33.3	36.7	40.0	46.7	53.3	60.0	66.7	73.3	80.0
0.35	3.9	7.8	23.3	27.2	31.1	35.0	38.9	42.8	46.7	54.4	63.2	70.0	77.8	85.5	93.3
0.40	4.4	8.9	26.7	31.1	35.6	40.0	44.4	48.9	53.3	62.2	71.1	80.0	88.9	97.8	107
0.45	5.0	10.0	30.0	35.0	40.0	45.0	50.0	55.0	60.0	70.0	80.0	90.0	100	110	120
0.50	5.6	11.1	33.3	38.9	44.4	50.0	55.5	61.1	66.7	77.8	88.9	100	111	122	133
0.55	6.1	12.2	36.7	42.8	48.9	55.0	61.1	67.2	73.3	85.5	97.8	110	122	134	147
0.60	6.7	13.3	40.0	46.7	53.3	60.0	66.7	73.3	80.0	93.3	107	120	133	147	160
0.65	7.2	14.4	43.3	50.6	57.8	65.0	72.2	79.4	86.7	101	115	130	144	158	172
0.70	7.8	15.6	46.7	54.4	62.2	70.0	77.8	85.5	93.3	109	124	140	155	170	185
0.75	8.3	16.7	50.0	58.3	66.7	75.0	83.3	91.7	100	117	133	150	167	183	200
0.80	8.9	17.8	53.3	62.2	71.1	80.0	88.9	97.8	107	124	142	160	178	196	213
0.85	9.4	18.9	56.7	66.1	75.5	85.0	94.4	104	113	132	151	170	189	208	227
0.90	10.0	20.0	60.0	70.0	80.0	90.0	100	110	120	140	160	180	200	220	240
0.95	10.6	21.1	63.3	73.9	84.4	95.0	106	116	127	148	169	190	211	232	253
1.00	11.1	22.2	66.7	77.8	88.9	100	111	122	133	156	178	200	222	244	267
1.10	12.2	24.4	73.3	85.5	97.8	110	122	134	147	171	196	220	244	269	293
1.20	13.3	26.7	80.0	93.3	107	120	133	147	160	187	213	240	267	293	320
1.25	13.9	27.8	83.3	97.2	111	125	139	153	167	194	222	250	278	306	333
1.30	14.4	28.9	86.7	101	116	130	144	159	173	202	230	260	288	318	347
1.40	15.6	31.1	93.3	109	124	140	156	171	187	218	249	280	311	342	373
1.50	16.7	33.3	100	117	133	150	167	183	200	233	267	300	333	367	400
1.75	19.4	38.9	117	136	156	175	194	214	233	272	311	350	389	428	467
2.00	22.2	44.4	133	155	178	200	222	244	267	311	356	400	444	489	533
2.25	25.0	50.0	150	175	200	225	250	275	300	350	400	450	500	550	600
2.50	27.8	55.6	167	194	222	250	278	306	333	389	444	500	556	611	667
2.75	30.6	61.1	183	214	244	275	306	336	367	428	489	550	611	672	733
3.00	33.3	66.7	200	233	267	300	333	367	400	467	533	600	667	733	800

Note: Formula used for calculation:  $Q = \frac{100W}{9}$   $R = 11.11WR$

Where: Q = Quantity of asphalt required, in gallons per 100 ft. (l/m)

R = Rate of application in gallons per sq. yd. (l/m<sup>2</sup>)

W = Width of application, in feet (m)

For metric conversion factors see pages 6-A&B Metric formula for calculation:  $Q = LWR$  where L = length in metres.

## **Spray Bar Height**

The height of the spray bar above the pavement surface is probably the most important adjustment to assure uniformity of asphalt spread. Correct height must be maintained during the entire application. If the spray bar is too low or too high, streaking will result.

The preset height above the pavement surface should not vary more than 1/2-inch. The bar will not stay within this tolerance, however, unless the manufacturer or the contractor takes steps to ensure that it does. As the asphalt leaves the spray bar, the load lightens and the springs raise the distributor. If there is an appreciable amount of deflection in the springs, the spray bar can rise as much as 4 inches, resulting in an uneven application.

Excess vertical movement of the spray bar can be corrected in several ways. After the bar height is adjusted with a full load in the tank, the frame of the distributor can be tied down to the axle during the spreading runs. If it is a truck-mounted distributor and has an adjustable type spray bar, mechanical controls can be supplied by the manufacturer to maintain the proper height, regardless of the deflection in the springs. On trailer-mounted distributors, bar height control is not necessary because of the small deflection of trailer springs. In any event, the height of the bar should be checked after each run and any necessary adjustment made at that time.

### **Triple Coverage:**

This is where any point on the roadway surface will receive overlapping spray from the two adjoining nozzles.

4-Inch nozzle - Best results with 4-inch nozzle spacing will come from an exact triple coverage of the spray fans.

A simple test procedure assures the proper height setting of a spray bar with 4-inch nozzle spacing. One can determine by visual inspection whether or not an exact single coverage of asphalt is being applied. To begin, the second and third, fifth and sixth, eighth and ninth, etc., nozzles are closed, using the center section of the bar only. The distributor is then operated at the correct pump speed/pressure with the spray bar height changed not more than 1/2-inch at a time until the proper height is obtained. When an even single coverage of asphalt, heated to the proper spraying viscosity, is applied to the surface, it will give a uniform triple coverage with all nozzles operating.

6-inch nozzle - The height of bar necessary to give a triple coverage will frequently cause wind distortion of the spray fans, resulting in non-uniform application. A double coverage is therefore recommended for 6-inch nozzle spacing.

### **Double Coverage:**

This involves the same procedure as above except that every other nozzle is left open; the remaining ones are shut off. If the distributor has already been checked for double coverage, increasing the spray bar height by 50 percent will give triple coverage.



## **Proper Nozzle Angle**

Adjust nozzle opening angles so the spray fans will not interfere with each other. The nozzle angle will vary according to the make of the distributor. The angle recommended by the Asphalt Institute, measured from the spray bar axis, is 15 degrees to 30 degrees.

Manufacturers furnish special wrenches for setting the angle of the nozzles. The use of these wrenches is recommended, as it is extremely difficult to obtain a uniform spread with visually set nozzles. All nozzles should be set at the same angle except for the cut-off nozzle. (end nozzle) Manufacturers make a nozzle with 1/2 spray pattern for this purpose.

At the time the angle of the nozzles is set, the edges of the nozzle openings should be inspected to see that they are not damaged. A nicked or otherwise damaged edge will produce a distorted fan of asphalt.

## **Streaking Will Occur:**

- \* If the asphalt is too cold.
- \* When the viscosity of the asphalt is too high.
- \* If the snivies are not at the same angle.
- \* When the bar is too high.
- \* When the bar is too low.
- \* When the bar pressure is too high it cuts furrows because the snivies are too small and/or there is too much pump pressure.
- \* When the bar varies in height from a full to an empty distributor, blocking or locking against the overload springs will reduce or eliminate this variance in height.
- \* When the bar is too long and/or the snivy openings are too large for the pump capacity, this results in narrow and fluttering fans. Smaller snivies and/or higher pump capacity will correct this.
- \* If the pump pressure is too low it will create narrower spray fans and fluttering.
- \* If the distributor tank is allowed to run completely empty, an irregular pattern of misses and fluttering will occur across the bar. For this reason, the shot should be terminated while approximately 100 gallons are left in the distributor.

## **Cleaning of Distributor**

Cleaning of the distributor should take place in an area determined by its characteristics that are protective of the environment. For example: areas near waterways or with high seasonal water tables would not be necessarily suitable. These cleaning areas may require all fluids to flow through an oil water separator and all tank and bar cleaning agents to be barreled and labeled for disposal. No discharging or blowing your distributor bars in the ditch line, upon the right-of-ways or on private property is allowed, this could result in a serious violation.

## **Checking the Bitumeter**

A bitumeter consists of a rubber-tired wheel, mounted on a retractable frame, with a cable leading to a circular dial in the cab of the vehicle. The dial registers the rate of travel in feet per minute and the total distance of each trip in feet. At least one manufacturer furnishes a dial that registers the appli-

cation rate in gallons per square yard in addition to travel in feet per minute.

Check the bitumeter at regular intervals to ensure accurate registering of speeds when the distributor is spraying asphalt. To check the bitumeter, a distance of 500 feet to 1,000 feet is marked off accurately on a straight and level length of road. The distributor is driven at constant speed over this length and the trip is timed with a stopwatch. Then the speed in feet per minute is calculated and compared with the bitumeter dial reading recorded during the run. This procedure is repeated for a number of other speeds, bracketing the speed to be used for spraying.

Errors found at the various speeds are tabulated or plotted on a graph so they can be readily applied when using the distributor. The bitumeter when used must be kept clean to ensure accurate registering of the truck speed. A build-up of asphalt on the wheel will produce an error.

## **Traffic Control**

Traffic control is important and must be maintained throughout the work area. High speed traffic over a fresh seal coat displaces aggregate, causing bleeding of asphalt. Traffic should be allowed only in the lane not being sealed. When work is completed, traffic speed should be maintained at less than 35 mph, or the legal speed if under 35 mph, until the asphalt sets. Warning signs, flag persons, and pilot cars are essential for traffic control. Route trucks hauling aggregate to the aggregate spreader in a direction opposite of the seal coat operation. This prevents loaded trucks being turned on freshly placed seal coat.

Some emulsions such as High Floats may require up to 24 hours of traffic control or until the first sweeping occurs. This is in areas of high volume traffic or areas where vehicle weight exceeds the normal load range.

## **Application of Asphalt**

It is very important that the correct amount of asphalt be applied to the surface, as too much or too little asphalt will cause a slick roadway surface. If not enough asphalt is shot, the rock will ravel off leaving a surface rich in asphalt. If too much asphalt is shot, it will flush to the surface.

Many factors are used to determine the amount of asphalt to shoot, including the grade of asphalt, size of aggregate, condition of roadway surface, and traffic. After a rate of application is determined, a shot of asphalt should be put down, covered with aggregate, and rolled. A field check should be made by checking to see that the asphalt depth is approximately three-quarters of the way up on the firmly placed aggregate. Any adjustment needed should be made in the asphalt application rate at this time. A field check should be performed periodically during the day to assure correct application rates are maintained throughout the entire project.

Rough and unsightly transverse joints can be avoided by starting and stopping the asphalt spread on building paper. The distributor, traveling at the correct speed for the desired application rate, starts spraying on the paper so that a full, uniform application of asphalt results when reaching the exposed surface. The use of smaller, more absorptive aggregate at the ends has been successfully used instead of paper.

A longitudinal joint is usually unavoidable because traffic lanes must be maintained. If possible, longitudinal joints should be made along the centerline or center of lane of the pavement and never in the wheel tracks. To prevent aggregate from building up on the longitudinal joint, the edge of the aggregate spread should coincide with the edge of the full thickness of applied asphalt. This allows a width where asphalt is present in partial thickness, due to outside nozzle spray, that can be overlapped when asphalt is applied in the adjacent lanes.

## **Spreading Aggregate**

All aggregate required for the planned spread should be on hand before starting. It should be dampened if necessary, as described in the section on Material Selection. When the distributor moves forward to spray asphalt, the aggregate spreader should follow immediately behind it. The asphalt must be covered as soon as possible, otherwise the cooling of the asphalt will prevent good adhesion between asphalt and aggregate. It is important that the aggregate be spread uniformly and at the proper rate of one rock thickness. Marking the length that each truckload of aggregate should cover aids in controlling distribution.

## **Chipsreader Calibration**

The following is a step-by-step procedure on how to calibrate your chip spreader and calculate the application rate.

1. Construct a one square yard shallow box or tarp, with shallow and narrow sides.
2. Place the box/tarp in the middle of the roadway a minimum of 50 feet in front of the chip spreader.
3. Get the chip spreader up to speed and apply chips over the top of the box/tarp.
4. Remove the box/tarp with the chips from the road.
5. Find an accurate materials scale. If in the field, the scale must be leveled and checked.
6. Place the chips from the box/tarp in a small bucket and weigh the bucket with the chips.
7. Empty the chips out and weigh the empty bucket.
8. Subtract the weight of the empty bucket from the weight of the bucket with the chips.
9. Since you had a one-square yard box/tarp, the weight from Step 8 is your pounds per square yard of chips.
10. Repeat the process at two to three gears and two to three RPM or speeds. You can then develop a chart.

**NOTE:** The aggregate weight may vary a couple of pounds if the chips are wet.

# **TONS OF AGGREGATE REQUIRED PER MILE FOR VARIOUS WIDTHS AND RATES**

Spread Rate	Spread Width (in Feet)						
	8	9	10	12	16	18	20
lb/yd <sup>2</sup>	Tons Per Mile	Tons Per Mile	Tons Per Mile	Tons Per Mile	Tons Per Mile	Tons Per Mile	Tons Per Mile
5	12	13	15	18	23	26	29
10	23	26	29	35	47	53	59
15	35	40	44	53	70	79	88
20	47	53	59	70	94	106	117
25	59	66	73	88	117	132	147
30	70	79	88	106	141	158	176
35	82	92	103	123	164	185	205
40	94	106	117	141	188	211	235
45	106	119	132	158	211	238	264
50	117	132	147	176	235	264	293
60	141	158	176	211	282	317	352
75	176	198	220	264	352	396	440
100	235	264	293	352	469	528	587
150	352	396	440	528	704	792	880
200	469	528	587	704	939	1056	1173
250	587	660	733	880	1173	1320	1467
300	704	792	880	1056	1408	1584	1760

To convert from

*Feet  
lb/yd<sup>2</sup>  
tons/mi*

to

*metres  
kg/m<sup>2</sup>  
Mg/km*

Multiply by

*0.3048  
0.542492  
0.563698*

## **Chip Spreader**

Chip spreaders kick the aggregate backward or drop the aggregate straight down to reduce aggregate rollover and reduce the degree to which the aggregate picks up on vehicle tires after the section has been opened to traffic. The spreader is a variable width machine and calibrated on pounds per square yard. Dump trucks work in combination with the chip spreader to achieve a uniform application of aggregate.

## **Rolling**

Rolling seats the aggregate in the asphalt and promotes the bond necessary to resist traffic stresses.

Pneumatic tired rollers should be used on all seal coat jobs to give uniform ground pressure over the entire area to achieve proper embedment of the aggregate in the asphalt binder. Steel wheeled rollers tend to compact only high spots and can fracture soft aggregates.

Rolling should begin immediately after the aggregate has been distributed and should continue until the aggregate is properly seated in the binder. Rolling should begin at the outer edge of the treatment and proceed in a longitudinal direction, working toward the center of the road. Each trip should overlap the previous trip by about one-half the width of the front wheels. As soon as the asphalt has a definite set or hardening, rolling should be discontinued, to prevent the bond between the surface and aggregate from being broken by the roller.

Rollers should be operated at slow speeds (4 to 6 mph) to set the rock, not displace it. The number of rollers required for a seal coat project depends on the length of the operation. It takes two to four passes of the roller to set the rock. These rollers should have tire pressures of (45) psi or more.

Loose aggregate should be swept along the longitudinal joint and from the uncovered lane prior to application of asphalt. Brooming loose aggregate on a completed sealed surface should be done as soon as practicable, and during the cool part of the day, to minimize flying rock problems.


Relying on traffic to seat the aggregate has been successful, if speed is controlled, but using rollers gives better control and improves the chances for success.

### **Spreading of Fines or Choking - Optional**

The need for applying fines will vary with the types of emulsions used and application rates. Those rates must be closely monitored. The most common material used for choking is 3/8" to #10 or 1/4" minus maintenance sand. In urban areas clean masonry sand can be used. Spreading these fines on a seal helps fill the voids, key the stone, reduces the chances of bleeding, and stops the squeezing and tracking of asphalt. The application of these fines prior to the roller, or after the roller depends on the types of emulsions used, and the location of the project. Fines application should not cover the coarse aggregate but merely fill the voids. The spreading of fines could be achieved by using a Hopper Sander with a mid mount spinner. This vehicle may be placed before or after the rollers depending on the type of operation.

## Post-Seal Inspection

The embedment of the aggregate into the asphalt should be checked a day or so after the construction of the seal coat. Remove several of the largest stones and determine if the 50 percent to 70 percent embedment has been obtained.



If an inadequate application of asphalt was applied, a fog seal can enrich and tie down the seal rock. A diluted CSS-1 (usually 50/50) is applied at the rate of .1 to .2 gallons per square yard of the dilution. (Application can vary depending on pavement texture, local conditions, and traffic.) No cover aggregate is required; however, if a tighter seal is desired, a sand or 1/4" 0-0 cover may follow. Traffic should be controlled until the CSS-1 has cured.

## DOs of Seal Coating

- \* Do turn spray nozzles so that fans are at proper angle to spray bar, so sprays do not touch or merge.
- \* Do check bar height at start of each shot to determine ground-to-nozzle distance over entire bar length.
- \* Do check spraying pressure so as to give constant uniform spray. Pressure too high will cause spray to fog and distort, pressure too low will cause spray to sag with heavy edges and pronounced longitudinal streaking.

- \* Do heat asphalt to upper part of spraying temperature range to eliminate heavy edge that is characteristic of all fan type sprays.
- \* Do keep spray bars in proper working order by regular cleaning and inspecting of strainers. Clean spray bars after each day's operation.
- \* Do keep aggregate stockpiles clean and free of contaminants.
- \* Do clean out tank thoroughly when changing asphalts from emulsified to cutback asphalts or from cationic to anionic emulsions.
- \* Do keep equipment on the same side of the roadway that the sealing operation is on, so traffic flow is not impeded.
- \* Do cover shot as soon as possible and roll immediately to ensure a good bond.

### **DO NOTS of Seal Coating**

- \* Do not use worn nozzles or ones that have mechanical imperfections.
- \* Do not heat asphalt material above maximum temperature range, which would cause spray patterns of the fans to be uneven.
- \* Do not use asphalts that are too cold. Material will be too viscous and cause narrow spray fan, and materials will not flow together.
- \* Do not try to seal a wet or dirty road surface.
- \* Do not try to seal coat if air or road surface is too cold. Don't seal when windy.
- \* Do not make shots too long before applying aggregate.
- \* Do not turn equipment on a fresh patch.

### **Blade Mixed Asphalt Mix**

Blade mixing of asphalt cold mixes is an economical and versatile method of producing material for construction or repair of highway pavement. High production rates are possible with a comparatively low expenditure, and entirely satisfactory pavements can be achieved with blade mixed cold asphalt. However, proper attention must be devoted to ensuring uniform quantities of aggregates, uniform aggregate gradation, and correct, uniformly applied quantities of asphalt are combined into the final mix design.

A wide variety of aggregates ranging from well graded crushed rock to silty sands can be mixed satisfactorily by cold blade methods. The optimum results will be obtained by using a uniformly graded manufactured aggregate with a maximum particle size of 1/2 inch or less and not more than 10 percent passing the No. 200 sieve.

Emulsified or cutback asphalts may be used in the production of cold mixes. Up to 3 percent surface moisture may be required on aggregates for successful mixing with emulsified asphalts and subsequent compacting of the mixture. The surface moisture of aggregates should be as low as possible if cutback asphalts are used.

Well graded mixes are made using an asphalt with a fairly slow rate of curing such as MC, SC, SS, or CSS. Open graded mixes are made with a faster curing asphalt such as MC or CMS, or RC if it is to be spread and compacted immediately. Asphalt cold mixes which are to be made and placed into stockpile for future use are made with an MC or SC asphalt of 250 or 800 grade.

Prior to beginning the mixing operation, a permanent base pad must be prepared at the site upon which the cold mix will be made. The pad should be reasonably level, 3 to 4 feet wider than the distributor spray bar, and must be surfaced with compacted hot or cold asphalt mix. The length of the pad can vary depending upon conditions but should be approximately 400 feet if possible.

The cold mix is made in batches, the size of which will depend upon the capacity of the distributor and the desired asphalt content. For a uniform manufactured aggregate of 1/2 inch to 0 inch gradation, with a desired asphalt content of 5 percent and using a 1,000 gallon distributor, the batch size will be approximately 60 cubic yards.

Using a truck and tail gate or chip spreader, a layer of aggregate the width of the distributor spray bar is uniformly spread upon the length of the base pad at a rate of approximately 50 pounds per square yard. Heated asphalt is then shot over the layer of aggregate at a rate calibrated to yield the desired asphalt content. The amount of asphalt required will depend on the gradation of the aggregate and will normally range from 4 to 7 percent by weight of the completed mix. Successive layers of aggregate and shots of asphalt are placed one on top of the other until the batch is completed.

Mixing is accomplished by turning and blending the mixture with a grader. If several batches are being produced for stockpiling and production is a factor, the mixing is more efficiently accomplished by using two blades working in opposite directions. Well graded mixes will require a relatively greater mixing effort to coat all of the particles evenly than will be required for open graded mixes. Mixing should continue until a thoroughly uniform mixture is produced. The completed mix is then windrowed and picked up by a front-end loader and placed into stockpile.

Stockpiled mixes made with MC or SC cutback asphalts should be allowed to cure out for a period of time before the mix is used. Cure time varies depending on weather conditions but will normally be approximately two weeks.

## **Handling Emulsified Asphalts**

- DO** when heating emulsified asphalt agitate it to eliminate or reduce skin formation. Agitation also prevents the asphalt lying next to the heating chamber from becoming overheated and boiling.
- DO** protect pumps, valves, and lines from freezing in winter. Drain pumps or fill them with anti-freeze according to the manufacturer's recommendations.
- DO** blow out lines and leave plugs open when they are not in service.



- DO** use pumps with proper clearances for handling emulsified asphalt. Tightly fitting pumps can cause binding and seizing.
- DO** use a mild heating method to apply heat to the pump packing or casing to free a seized pump. Discourage the use of propane torches.
- DO** warm the pump to about 150 F (65 C) to ease start-up.
- DO** when a pump is to be out of service for even a short period of time, fill it with No. 1 fuel oil to ensure a free start-up.
- DO** before diluting grades of emulsified asphalt, check the compatibility of the water with the emulsion by testing in a flask.
- DO** if possible, use warm water for diluting and always add the water slowly to the emulsion (not the emulsion to the water).
- DO** avoid repeated pumping and recycling, if possible, as the viscosity may drop and air may become entrained, causing the emulsion to be unstable.
- DO** guard against mixing different classes, types and grades of emulsified asphalt in storage tanks, transports, and distributors. For example, if cationic and anionic emulsified asphalts are mixed, the blend will break and separate into water and coagulated asphalt that will be difficult to remove. Because it is hard to determine visually the difference between various emulsified asphalts, always make a trial blend of the newly-delivered emulsion and the stored emulsion before pumping off. Check the trial blend for compatibility.
- DO** place inlet pipes and return lines at the bottom of tanks to prevent foaming.
- DO** pump from the bottom of the tank to minimize contamination from skinning that may have formed.
- DO** remember that emulsions with the same grade designation can be very different chemically and in performance.
- DO** haul emulsion in truck transports with baffle plates to prevent sloshing.
- DO** mix by circulation, or otherwise emulsions that have been in prolonged storage may not be the proper consistency, as emulsions tend to separate when stored for extended periods.
- DO NOT** use tight-fitting pumps for pumping emulsified asphalt; they may “freeze”.
- DO NOT** apply severe heat to pump packing glands or pump casings. The pump may be damaged and the asphalt may become even harder.

- DO NOT** dilute rapid-setting grades of emulsified asphalt with water. Medium and slow setting grades may be diluted, but always add water slowly to the asphalt emulsion. Never add the asphalt emulsion to a tank of water when diluting.
- DO NOT** recirculate emulsified asphalts for too many cycles. They tend to lose viscosity when subjected to pumping. Also, air bubbles may become entrained which would render the emulsion unstable.
- NOTE:** Reprinted from Asphalt Institute's/Asphalt Emulsion Manufacturers Associations: A Basic Asphalt Emulsion Manual. Please refer to this manual for additional information.

	Page
General	4-2
Drainage from Abutting Properties	4-2
Ditches and Gutters	4-3
Rockfall Ditches and Slope Benches	4-4
Dry Wells	4-4
Culverts	4-4
Automatic Pumps	4-5
Underdrains	4-5
Storm Sewers	4-5
Bank Protection	4-6
Detention Ponds and Tanks	4-6
Oil Separators	4-6



### General

Water, either liquid or frozen, is the greatest natural destructive element that affects state highways.

Controlling water on the right of way requires a drainage system that effectively responds to the immediate environment. A typical highway drainage system includes ditches of all types, gutters, drains, culverts, storm sewers, and other miscellaneous drainage structures.

The system is designed and constructed to collect and remove water from the highway right of way. It must be properly maintained to:

- Permit the maximum use of the roadway
- Prevent damage to the highway structure
- Protect natural resources
- Protect abutting property from physical damage.

Maintain and preserve drainage facilities as nearly as possible in the condition and at the capacity for which they were originally designed and constructed.

Inspect the entire drainage system at least twice a year and correct deficiencies. Additional inspections may be required during heavy storms and periods of high runoff in order to determine the effectiveness of the system. Observe and record high water marks. Look for conditions that threaten damage to the drainage facility or the highway.

Maintenance personnel must be continually alert to assure that all natural water course channels crossing the right of way remain open.

### Drainage from Abutting Properties

Storm water is the only effluent allowed to be discharged upon the highway right of way. State law “RCW 47.44” allows persons and entities who have been issued utility franchises or permits to encroach on or cross highway right of way to install and maintain the item for which the permit was granted.

Population growth, urban sprawl, and numerous new regulations restrict how maintenance crews can maintain surface and subsurface drainage systems. Regulations that may affect drainage maintenance:

- Endangered species act
- Storm water management
- Wetlands preservation
- Growth management
- Shorelines
- Irrigation limitations

It is important that the Department not allow abutting property owners to discharge water onto the highway right of way without obtaining a permit. Property owners may obtain permits by applying at the WSDOT Area or Region office. Drainage design engineers and maintenance staff review potential drainage impacts from the abutting property to the highway right of way. The property owner may be required to mitigate water quality and/or quantity impacts to obtain a permit.

Maintenance personnel who routinely patrol a roadway section must be trained in the basic knowledge of what types of direct drainage and sheet flow from abutting property may require a permit. These include new:

- Commercial developments such as shopping centers
- Subdivisions
- Industrial development
- Automobile wrecking yards
- Dairy and other intensive farming activities

Maintenance personnel should report land use changes they observe to their supervisor. The supervisor will forward this information to the appropriate reviewer.

### **Ditches and Gutters**

Open ditches should be routinely checked and maintained to the line, grade, depth and cross section to which they were constructed. Where practical, non-standard ditches should be modified to produce a relatively flat, shallow ditch to enhance motorist safety.

Vegetation in ditches often helps prevent erosion and treats storm water. Remove vegetation only when flow is blocked or excess sediments have accumulated. Remove vegetation using “best management practices” that minimize erosion and sediment escape to water bodies.

Excessive erosion of drainage ditches must be controlled or repaired. Ditch linings of loose or grouted rock and concrete or other energy dissipation methods can control erosion. However, these linings need be checked frequently and repaired as necessary.

Keep ditches and gutters free of litter and debris. Repair all cracks and breaks as necessary.

Be especially careful when chemicals are used for brush and grass control in open ditches. Herbicides must be carefully controlled so as not to contaminate water or to transfer and concentrate chemicals in adjacent areas where environmental damage may result. Always follow product application instructions.

Be alert for diversion ditches on top of cut slopes that prevent slope erosion by intercepting surface drainage. Diversion ditches must be maintained to retain their diversion shape and capability.

Surplus material that results from ditch cleaning can often be used for widening. Material placed into the adjacent portions of the highway or disposal areas must not obstruct or impair other roadside drainage areas. Do not use material that may cause sedimentation problems to water bodies. Take care to avoid causing erosion problems or loose unstable fills. Don't use non-porous materials such as clay. They can become unstable when wet and trap water in the existing fill. If there is doubt about using such surplus material contact the Region Soils Engineer for assistance.

Don't blade ditch cleanings across roadway surfaces. Dirt and debris remaining on the pavement after ditch cleaning operations must be swept from the pavement.

Avoid undercutting the roadway back slope or in slope. Undercutting weakens the slope and will cause damaging slip-outs and other forms of slope erosion.

### **Rockfall Ditches and Slope Benches**

Keep rock fall ditches and slope benches clean. Large amounts of slough or rock fall and other slide material that effectively block the ditch or bench should be removed as soon as possible after they occur.

### **Dry Wells**

Dry wells accommodate the drainage flow in certain areas where:

- Natural outfalls for a drainage system were not available.
- Their use reduces the need for or size of downstream facilities.

These dry wells should be inspected periodically. Replace the drain rock if storm water no longer percolates into the soil.

### **Culverts**

A culvert is a conduit or pipe used as an artificial channel under a roadway or embankment to maintain flow from a natural channel or drainage ditch. Inspect all culverts at least twice a year. Keep them clean and in good operating condition.

Changes in the up stream watershed due to logging, land development activities, farming practices, forest fires, etc., may increase water run off, sedimentation and debris. With these conditions more frequent inspections, particularly after periods of high runoff, are necessary to enable maintenance personnel to take corrective measures if damage has occurred. During storms and floods, critical areas need to be inspected and the culvert inlets kept clear.

Repair and replace badly worn or broken culverts to minimize the possibility of damage to the roadbed by water saturating the fill material.

Culverts with 50 percent or more constriction should be flushed or otherwise cleaned to restore the culvert's original capacity. (Use BMP's to minimize fish impacts when doing this work.) Some of the larger culverts in flowing streams are designed for construction below the stream bed, to accommodate fish life. In these cases, the culvert should also be cleared of obstructions that may be detrimental to the passage of fish.

Check culverts for scour around the inlet and outlet. Repair scoured areas with rip-rap or some other protection if necessary. In some cases standing water is desirable at the inlet end of the culvert to settle out sediment. Vegetation at culvert ends can be controlled by residual herbicides or mechanical means. Controlled burning of vegetation at culvert ends is a feasible alternative at some locations. Whatever method of vegetation control utilized needs to be accompanied by erosion and sediment control features/practices.

Pavement markings that show the location of culverts should be renewed annually. These markings are critical for quickly locating culverts for both emergency and routine maintenance. Pavement markings of more permanent materials, such as thermoplastics, are encouraged.

### **Automatic Pumps**

Automatic pumps, sumps, and pipes at underpass structures or draining depressed sections of highway must be kept in good operating condition at all times. Each installation must be inspected on a routine basis, at least once per week. Inspections should include the electrical, ventilation, greasing and drainage systems.

### **Under Drains**

Under drains are often constructed in the sub-grade to intercept subsurface water from springs and seepage water from the surface or percolating from below. Control of this water is essential to ensure the stability of the sub-grade upon which the highway is constructed.

Inspect under drains on the same schedule as culverts. Keep their outlets open and clean. Choked under drains can be cleaned by high pressure flushing with water or flexible sewer rods. In cases where roots effectively block the drainage, the use of herbicides may be indicated. Whatever method of cleaning is used, consideration for erosion and sediment control is needed.

### **Storm Sewers**

In many areas underground pipe systems are necessary to carry storm runoff normally handled by ditches. Storm sewers are often used in long, depressed highways or along curbed sections on city streets. Water carried by the system is generally collected through inlets, catch basins, or manholes and carried by pipe to an out fall on a natural waterway.

Clogged pipes can often be cleaned with high-pressure water jets. But, if tree roots or broken pipes are causing the clogging, more service will be required. Flexible rotary cutters will remove roots intruding into a pipe.

Broken pipes may be repaired by jacking an insert liner into the failed location. Otherwise, the failed pipe may have to be excavated and relayed to repair it. Whatever method of cleaning is selected, consideration for erosion and sediment control is needed. In no case can debris or sediment be allowed to enter a water body.

Manholes are generally used where there is a change in profile or alignment and also at strategic points in long, straight sections in order to provide access for cleaning the conduit.

Periodically inspect and clean inlets, catch basins, and manholes using a vacuum truck or manual cleaning methods. Conduct inspections during storms to ensure that the inlet grates are not becoming clogged with water-born debris. Schedule sweeping operations to help prevent the accumulation of leaves, paper, or other clogging debris.

When pavement is overlaid by contract or maintenance work crews be sure that the manhole covers are flush with the finished pavement elevations.



## Bank Protection

Maintenance personnel must be continually alert to conditions that may cause scour, undermining, or washout of highway embankments or structures by storms, floods, or wave action.

Highways adjacent to water courses, drainage ways, and embankments throughout the state are protected in a variety of ways against damage due to high water. These include barbs, stone rip-rap, grouted rip-rap, pile revetments, retaining walls and cribs, rock and wire mesh (gabions), and vegetation.

These features must be inspected during storms or periods of high water, as well as at least once each spring or after major high water periods, and repairs made where required. Make repairs with materials similar to those in place. If possible take corrective measures to eliminate the direct cause of the damage.

Hydraulic permits may be necessary and protection measures for fish habitat are required.

When the need for significant additional bank protection around structures or embankments is indicated, the Area Superintendent is to be notified immediately and a determination made as to whether or not the protection materials will be placed by maintenance or construction forces.

## Detention Ponds and Tanks

Designers are increasingly specifying the use of detention ponds and tanks that store water runoff and release it slowly through a controlled out fall or outlet. In this way the size of downstream pipes and culverts can be reduced, erosion is mitigated, and solids that settle out can be removed.

To function correctly the controlled out fall or outlet pipe must be free of debris. Accumulated settled materials must be removed on a schedule based on experience at each site. If oil separators are combined with these facilities, timely removal and proper disposal of oils is essential.

If inspection or cleaning necessitates working inside an underground detention tank, confined space procedures must be followed.

## Oil Separators

Oil separators are being used increasingly by WSDOT in conjunction with catch basins, manholes, and other drainage structures. While they vary in design, all function in much the same manner by reducing the velocity of the water flow through the drainage structure and not allowing floating debris to be flushed through. This allows oils carried by the water to accumulate and be contained within the drainage structure.

Once contained, these oils must be periodically removed and properly disposed of to prevent their being released back into the flow of the drainage system.

Generally, the same conditions that determine the schedule of inspection and cleaning required for standard catch basins and manholes also applies to units with oil separators. Oil separators, however, increase the rate of silt buildup within any drainage structure in which they are installed. Therefore, oil separators may require more frequent inspection and cleaning. Experience can best determine what schedule of inspection and cleaning is required to maintain these units in proper working order.

The Maintenance Accountability Process "MAP" sets the level of service for performing drainage maintenance.



## Chapter 5

## Maintenance of Structures

---

	Page
General	5-2
Major Structures	5-2
Minor Structures	5-2
Inspection	5-2
Bridge Repair Guidelines	5-4
Environmental Aspects	5-4



### General

The proper care of structures is vital to the preservation of the highway network and to the safety of the traveling public. This chapter discusses those items in which area maintenance personnel assist in this maintenance effort. Other more comprehensive references are available to the Maintenance Engineer.

### Major Structures

For maintenance purposes, major structures are identified as those bridges included in the Bridge List (M 23-09). The State Bridge and Structures Engineer is the responsible authority for these structures and must be contacted prior to any major maintenance or modifications to them. The designated contact in Olympia is the Bridge Condition Engineer.

### Minor Structures

For maintenance purposes, minor structures are identified as those drainage structures (culverts, etc.), retaining walls, acoustical barriers, cribbing, etc., that are not listed in the Bridge List. The Region Maintenance Engineer is the responsible authority for minor structures.

Any defects or damage to minor structures should be referred to the Area Maintenance Superintendent, who will coordinate the required action.

### Inspection

Federal regulations require that all major highway structures be inspected by a crew under the supervision of a professional engineer, at intervals not exceeding two years. This requirement is met by the WSDOT Headquarter's Bridge Condition Engineer and his/her crews. Certain bridges, such as steel bridges, untreated timber bridges, bridges having a posted load limit, movable bridges, floating structures, bridges with pending repairs, and bridges with a life expectancy of less than eight years, are inspected annually.

Bridge conditions can change in much less than two years. The Bridge Condition Unit relies on Region maintenance personnel to be alert for settlement, washout, collision damage, and other problems, and to notify their Superintendent as appropriate.

Area maintenance crews are also expected to maintain or repair minor approach settlements, approach guardrail damage, plugged bridge drains, asphalt overlays and other items that are considered to be part of normal maintenance operations. It is unnecessary for WSDOT Headquarter's bridge inspection teams to document such items in their report or to initiate correspondence to the Regions.

All minor structures, related to bridges, should be inspected at least annually by the designated region maintenance supervisors or crews. Inspect more often if warranted by weather conditions or past experience.

Some regions have bridge maintenance crews. In these regions bridge maintenance personnel are responsible to inspect all bridges and designated minor structures annually. For those regions without bridge crews then the area maintenance crews are responsible for that inspection. Record all deficiencies.

cies. Keep the records on file until the deficiencies are corrected. During inspection, the following items should be checked. Deficiencies should be immediately repaired or scheduled for future work

**Conditions of Approach Fills.** Note any deficiency. Pay particular attention to the pavement seats of the structure. Look for sagging, pot holing, scaling, or spalling.

**Conditions of Asphalt Wearing Surface.** Note potholes, scaling, wheel rutting, and general pavement condition.

**Condition of Concrete Deck.** Note scaling, spalling, cracks, and any exposed reinforcing steel.

**Condition of Grid Decks.** Look for and note broken welds or clips, loss of a section due to rust, and any bent members.

**Condition of Curbs and Railings.** Note any deterioration, cracking, spalling, or breakage.

**Condition of Paint.** Note the general condition of the paint. Look for cracking, peeling, fading, and presence of rust or algae.

**Condition of Stringers, Caps, and Floor Beams.** Note any crushing at bearing points, and any warping or cracking.

**Condition of Steel Truss Members.** Note bent or damaged steel, deflection, cracking, vibration, and deterioration due to rust. Pay particular attention to pinned joints at hinges, excessive rust, vibration, missing nuts, or looseness. Immediately inform the designated bridge maintenance representative of any known or suspected problems.

**Condition of Wood Truss Members.** Look for and note damaged or broken members, crushing, cracking, warping, vibration, and deterioration due to rot or boring insects.

**Condition of Expansion Joints.** Note loose, banging, and jammed expansion joints. Also note the presence and condition of the joint material where the joints are of a compression seal type.

**Condition of Abutments, Bulkheads, Piers, and Intermediate Bents.** Note any type of tilting, bulging, and deterioration. Pay particular attention to any scouring or undermining due to high water and erosion.

**Bridge Drains.** Note plugged bridge drains. Check pipe out fall areas to see if soil erosion is occurring. Plugged drains may result in saturation of the bridge approach fills and may explain any unusual erosion or undermining of abutments or bulkheads.

**Waterways.** Note scour and conditions that could cause log jams or ice jams during high water stages. Look for any logs or other debris jammed against piers, bulkheads, or piling. In the winter check all bridges with piers or bulkheads in the water with a floating debris problem during and after each flooding condition.

**General Conditions.** Look for accumulation of dirt, excessive bird droppings or debris on the roadway at bearing points and on the caps or lower chords. Pay particular attention to the presence of

materials that might pose a fire hazard or restrict access for maintenance activities. Note any unauthorized attachments such as private fences.

**Walls and Cribbing.** Inspection can be of a cursory nature according to guidelines designated by the Area Maintenance Superintendent. Check walls for tipping, bulging, cracking, and spalling. Check all weep holes to assure that they are open. If the structure is wooden, check for rot and the presence of fire hazards.

**Tunnels.** Condition of walls, ceiling or liner. Look for cracking, spalling or loose overhead hazards. Note increased water seepage. Condition of wire retention fabrics. Check for tears or failures that may indicate potential structural hazards.

### **Bridge Repair Guidelines**

Minor repairs to railings, curbs, concrete decks, expansion joints, etc., can be performed without the individual approval of the WSDOT Headquarters Bridge and Structures Office. Similarly, loose bolts may be tightened, drift may be removed, clearance lights changed, etc.

Any major or structural repairs need to be coordinated through and approved by the WSDOT Headquarters Bridge Preservation Engineer. If there is any doubt about the structural significance of a damaged or deteriorated bridge component notify the WSDOT Headquarters Bridge Preservation Engineer.

The WSDOT Headquarters Movable Bridge Engineer prepares and updates individual maintenance manuals for all movable bridges. Consult these manuals for both routine and specialized maintenance tasks. Direct questions to the Movable Bridge Engineer in the Bridge and Structures Branch, Project Development Office, Olympia.

### **Environmental Aspects**

WSDOT environmental staff will provide Maintenance Engineers, Area Superintendents and Maintenance Supervisors with training and education on which regulations apply to specific maintenance activities and what is the appropriate response to the regulatory process.

In addition to federal regulations, state environmental agencies, tribes and city or county health ordinances may have environmental restrictions on work done on or near bridges.

Before initiating bridge repair activities, either the Maintenance Engineer, Superintendent, or Supervisor will confirm if environmental permits are required. They will also review the proposed repair method with the environmental staff to determine whether it is both appropriate and/or environmentally sound. The following list provides some of the environmental concern factors that impact bridge maintenance in some localities. This list is not comprehensive or current because the list of environmental factors to be considered continues to change. However, it does provide some insight into the degree to which maintenance is being held to an increasing level of environmental accountability.

- State or federal list of threatened or endangered species
- Species of high interest to state or federal agencies
- Migratory waterfowl habitat

- Anadromous fish habitat
- Trout and other cold water fish habitat
- Habitat for birds of prey
- Wetlands and wetland habitat
- Riparian habitat
- Migratory corridors
- Wintering areas and other critical feeding areas of wildlife
- Important wildlife reproductive habitat
- Public water supplies, including important aquifers
- Islands and other coastal barriers
- Hazardous waste
- Regulatory flood ways and other flood plain areas
- Commercial fish and shellfish production areas
- Important sport fishing areas
- Highly erosional soils
- Listed or proposed wild and scenic rivers
- Navigable waterways
- Significant historic resources
- Natural resource agency holdings or interests (refuges, parks, habitat areas, etc.)



## Chapter 6

## Roadside Management

---

	Page
General	6-3
Roadside Functions	6-4
Roadside Treatment	6-5
Maintenance Involvement in the Roadside Management Process	6-5
Roadside Maintenance and the Maintenance Accountability Process	6-6
Roadside Management Zones	6-7
Integrated Vegetation Management	6-11
Noxious Weed Control	6-13
Danger Trees	6-14
Disposal of Logs Dumped on Right of Way	6-14
Removal of Dangerous Objects and Structures	6-15
Trespass and Encroachment	6-15
Encroachments - General	6-15
Encroachment - Maintenance Crew Responsibilities	6-15
Franchises and Permits	6-16
The Use of Pesticides	6-16
Pesticide License	6-17
Record Keeping	6-17
Product Labels	6-17
Posting Requirements	6-17
Aquatic Pesticide Applications	6-17
Pesticide Sensitive Individuals	6-18
Container Disposal	6-17
Use of Mowing Equipment	6-18
Other Cutting Methods	6-19
Cultural Control Methods	6-19
Biological Control	6-20
Burning Debris	6-20
Illegal Tree Removal	6-20
Significant Roadside Activities	6-21
Removal of Debris and Rubbish	6-22
Litter Control and Partnerships for Roadside Enhancement	6-22
Adopt-a-Highway	6-22
Program Rules	6-23
Participant Eligibility	6-23
Assignment of Sections	6-23
Volunteer Adoptions	6-24
Sponsored Adoptions	6-24

	<b>Page</b>
General Permits for Roadside Enhancement	6-25
AAH Administrative Roles and Responsibilities	6-26
Maintenance & Operations Programs Responsibilities	6-26
Region Responsibilities	6-26
Auxiliary Facilities	6-27
Safety Rest Areas	6-27
Park and Rides Lots	6-28
Historical Markers	6-28
Viewpoints	6-28

### General

This chapter addresses roadside maintenance issues primarily as they relate to vegetation management. It also covers maintenance in relation to litter control and auxiliary features such as Safety Rest Areas, viewpoints and historical markers. Roadside issues as they relate to areas of maintenance such as drainage, pavement and maintenance of structures, are covered in other chapters of the Maintenance Manual.

This chapter has been written to integrate with information relating to roadside management topics presented in all other Departmental documents. In particular it is tied to the contents of the **Roadside Manual**, the **Roadside Classification Plan** and the **Design Manual**. Roadside maintenance managers should be familiar with the contents of these other documents as they relate to roadside maintenance.

### Definitions

**Roadside:** The roadside is the area outside the traveled roadway. This applies to all lands managed by WSDOT and may extend to elements outside the right of way boundaries. It includes unpaved median strips and auxiliary facilities such as rest areas, roadside parks, viewpoints, heritage markers, pedestrian and bicycle facilities, wetlands and their associated buffer areas, stormwater treatment facilities, park and ride lots, and quarries and pit sites within the Right of Way.

**Roadside Management** encompasses the planning, design, construction and maintenance of the roadside.

Its goals include:

- Provide for all the highway functional and operational objectives
- Protect the environment
- Create and/or maintain desirable visual quality

These goals can be achieved with the lowest life cycle costs by:

- Applying consistent, long term strategies throughout the management process
- Using appropriate site specific best management practices (BMPs)
- Using appropriate Integrated Vegetation Management (IVM) techniques

**Integrated Vegetation Management:** Integrated vegetation management (IVM) is defined as a coordinated decision making process that uses the most appropriate vegetation management strategy on a site specific basis. It utilizes a monitoring and evaluation system to ensure achievement of roadside maintenance program goals and objectives. IVM practices are environmentally responsible and economically sound. WSDOT uses IVM to design and construct roadsides which will grow and evolve with the natural ecosystem. The type of site specific vegetation chosen is designed to require the least possible attention from maintenance over the long term.

**Best Management Practices (BMPs):** They are physical, structural, and/or managerial practices

that, when used singly or in combination, reduce the downstream quality and quantity impacts of stormwater.<sup>1</sup> Typical BMP's include biofiltration swales, wet ponds vegetated filter strips, and wet vault/tanks. BMP details can be found in the "Highway Runoff Manual" Chapter #8.

## Reference

Roadside Manual, WSDOT M 25-30  
 Roadside Classification Plan, WSDOT, 1996  
 Integrated Vegetation Management for Roadsides, WSDOT, July 1997  
 WSDOT Maintenance Manual for Water Quality and Habitat Protection  
 Guidance, WSDOT, IL 4020.00, July 1, 1999  
 Highway Runoff Manual, Chapter #8, WSDOT, M31-16  
 Design Manual, Chapters #12 & 13  
 Maintenance Accountability Process Handbook

## Resources

Headquarters Maintenance Office  
 Region Landscape Architects  
 Headquarters Roadside and Site Development Office  
 Regional Environmental Offices

## Roadside Functions

The roadside is managed to fulfill four functional categories: **operational, environmental, visual, and auxiliary functions**. By fulfilling highway needs in these four categories, the roadside contributes to WSDOT's delivery of transportation services. Table 7.01 explains the functions and gives examples.

Function	Examples
<b>Operational</b>	Those functions that provide safe and multi-use road sides. Operational functions include access control, providing vehicle recovery areas and sight distances with accommodations for signs and utilities, and snow storage. The <b>Design Manual</b> provides the primary guidance for operational roadside design guidance.
<b>Environmental</b>	Those functions that protect and enhance our natural and built surroundings. Environmental functions mitigate the roadway's impact on its surrounding ecosystem. Major environmental functions include: <ul style="list-style-type: none"> <li>• Water quality (preservation, protection and improvement)</li> <li>• Storm water detention and retention</li> <li>• Wetland and sensitive area protection</li> </ul>

Functions	Examples
	<ul style="list-style-type: none"> <li>• Noxious weed control</li> <li>• Noise control</li> <li>• Habitat protection and connectivity</li> <li>• Air quality improvement</li> <li>• Erosion control</li> </ul>
<b>Visual</b>	Those functions that are designed and experienced primarily from a visual perspective. Visual functions promote a positive quality of life and are integral to operational, environmental, and auxiliary functions. They include enhancing guidance and navigation, distraction screening, corridor continuity, roadway and adjacent property buffering, and scenic view preservation. There are two primary roadside views: Those from the roadway, and those toward the roadway. In addition many activities such as noxious weed control, wetland and sensitive area preservation, and habitat preservation are readily perceived and evaluated through sight.
<b>Auxiliary</b>	Those functions that provide additional operational, environmental, and visual functions to support or supplement the transportation system. Examples of auxiliary facilities are community enhancement areas, safety rest areas, roadside parks, viewpoints, agricultural uses, heritage markers, bicycle and pedestrian facilities, park and ride lots, and stockpile sites.

Table 7.01

## Roadside Treatment

The **Roadside Classification Plan (RCP)** provides the basis for solutions to site specific questions on how to develop and manage the roadside. This document provides guidance for resolving the roadside functional needs with variations in site conditions, vegetative patterns and geographic surroundings.

## Maintenance Involvement in the Roadside Management Process

Maintenance plays the major role in the roadside management process. The overall goal of roadside maintenance is to sustain the roadside in a manner that satisfies the intent of the RCP and performs as many functions as possible, while requiring the least amount of care.

Roadside maintenance is a unique element within the highway maintenance program because much of the work involves caring for and/or controlling vegetation. Roadside plant communities are alive and

part of a dynamic, ever evolving natural process. Therefore, proper maintenance of the roadside requires understanding of the many factors which contribute to the natural evolution of vegetation over time.

It is in the best interest of Design and Construction organizations to solicit input from the maintenance crews during the process of Planning, Designing and Constructing roadside features. Maintenance personnel should also take the initiative to provide documented input for consideration during this process.

It is vital that local maintenance employees be involved in the regional project development process as it relates to the roadside. The project delivery process within each region will vary. But, before a contract is finalized the project must be thoroughly reviewed by the local maintenance personnel with responsibility to care for the highway and roadside effected. Maintenance personnel can also offer valuable input during construction.

It is in the role of Design and Construction to continuously solicit Maintenance input on the processes of building, preserving and/or improving the highway. Maintenance personnel must take the initiative in offering appropriately documented input for consideration throughout the process of planning, design and construction.

## **Roadside Maintenance and the Maintenance Accountability Process**

The **Maintenance Accountability Process** (MAP) is used by WSDOT to explain the relationship between maintenance service levels and the resources required to deliver those levels. The MAP is a comprehensive management program that provides a clear link between maintenance goals, activities, service levels, the budget, and maintenance performance measures.

The major elements of roadside maintenance are referred to in the MAP as Group 3 - Roadside and Landscape Maintenance. The MAP defines Roadside Maintenance as having five major activities:

- Litter Pickup
- Noxious Weed Control
- Nuisance Vegetation Control
- Control of Vegetation Obstructions
- Landscape Maintenance

These elements serve as “service level” or outcome indicators, and are intended to measure how well the roadside is fulfilling the major functional needs of the highway. All MAP activities are field measured on a regular basis to determine service levels statewide as well as at the regional and maintenance area level.

One of the most valuable features of the MAP for roadside maintenance is its provision of consistent statewide outcomes for roadside maintenance decisions. These service level commitments serve as a basis for setting roadside maintenance action thresholds and help the areas plan roadside activities.

A unique result of applying an outcome based management system to the vegetation management process is the ability to measure results. It's possible to demonstrate an increasing service level over time, without an increase in funding.

Roadside vegetation, if managed properly, can become more naturally self-sustaining over time and require less control from maintenance as it grows and matures. With IVM, the overall service levels for Group 3 will improve over time under the following conditions:

- Consistent adequate resources to use BMP's
- Ability to apply properly timed target specific roadside maintenance treatments

## **Roadside Management Zones**

To address the highway's functional needs (as describe above), the roadside may be divided into as many as three major bands of area referred to as Zone 1-Vegetation Free, Zone 2- Operational, and Zone 3 - Transition/Buffer. Roadside maintenance priorities within these zones are established beginning with activities relating to the safe highway operations and maintenance, and preservation of the highway roadway.


Most "high priority" and routine roadside maintenance activities occur in Zones 1 and 2. They are designed and maintained to facilitate operational roadway functions such as: surface and subsurface drainage, traffic operations visibility and site distance. Zones 1 and 2 also allow unobstructed vehicle recovery where traffic may accidentally leave the roadway (referred to as the **Design Clear Zone**.) The Design Manual, Chapter 650 provides guidance on the required extent of the roadside "clear zone" (Zone 2) for varying highway configurations. In some cases the actual requirements for the clear zone, may extend beyond the right of way lines.

Zone 3 is present where adequate right of way area exists beyond what is necessary to deliver operational functions of the highway. Zone 3 is managed to address some safety functions such as hazard trees and trees shading the roadway. There are other operational functions which may be addressed within the area of Zone 3 such as drainage, noise and visual attenuation, and stormwater management needs. However, Zone 3 is primarily developed and maintained to address the visual, auxiliary, and non-regulated environmental functional needs of the highway. Zone 3 offers the greatest opportunity to create and maintain self-sustaining, low maintenance plant communities.

Roadside maintenance program objectives are established and prioritized to deliver the functional needs of the highway within the three zones.

Figure 7.01 shows a cross-section of a typical divided highway, illustrating typical relationships of the Roadside Management Zones within the highway right of way and giving examples of the functional objectives as they apply to the three zones.

## Typical Roadside Management Zones



### Functional Zone Objectives

**Zone 1 – Vegetation Free**  
(0 to 2 feet from pavement or as necessary)

- Provide for surface drainage
- Reduce fire potential
- Provide for visibility and maintenance of roadside hardware
- Prevent pavement breakup by invasive plants
- Provide sight distance for passing, stopping and at intersections
- Prevent the buildup of wind blown debris and winter sand at the pavement edge

**Zone 2 – Operational**  
(From Zone 1 or pavement edge to meet operational and maintenance needs)

- Maintain design width for vehicle recovery
- Provide sight distance for passing, stopping, at interchanges and at intersections
- Maintain hydraulic capacity of ditches
- Eliminate vegetative obstructions (trees with a trunk diameter of 4" or more)
- Control weeds
- Prevent erosion
- Provide wildlife habitat where compatible with roadway traffic
- Accommodate underground utilities
- Enhance visual quality

**Zone 3 – Transition/Buffer**  
(From Zone 2 to Right of Way line)

- Promote self-sustaining plant communities
- Blend and/or screen adjacent surroundings to meet the goals and objectives of the Roadside Classification Plan
- Eliminate hazard trees causing excessive shade (ice and frost potential) on the highway pavement
- Control weeds
- Prevent erosion
- Maintain and enhance visual quality
- Preserve wetlands and wildlife habitat
- Accommodate utilities
- Preserve and conserve native plants and wildflowers



## Maintenance of Zone 1

### Policy

Zone 1 is maintained to remain free of vegetation. This zone begins at the edge of the pavement and extends outward to Zone 2. Zone 1 is no wider than necessary to achieve the functional objectives.

The optimum maximum width is 2 ft. or to the back side of roadside hardware (guide posts guardrail) if present. Variations in this width may be justified based on the following considerations.

Areas where Zone 1 requirements are less than 2 ft. or unnecessary:

- Roadsides and medians that have adequate profile and ditch to provide surface runoff
- Required by environmental commitment
- Immediately adjacent to flowing or standing water
- Abutting curb and sidewalk sections
- Turf grass areas in rest areas and formal landscapes
- Adjacent to full depth pavement (Where shoulder pavement functions as Zone 1.)
- By agreement/permit where maintenance is done by others

Areas where Zone 1 may be wider than 2 ft.:

- Where visibility and maintenance of highway hardware such as guardrail or fencing must be facilitated
- Where there is a high risk of fire
- Natural rock and gravel ditches where it is impractical to maintain desirable vegetation
- Narrow areas adjacent to formal shrub beds
- Where farming activities take place very close to the roadway shoulder and it's impractical to maintain a strip of grass
- Where drifting sand or snow may accumulate on the roadway as a result of vegetation growth at the edge of the pavement
- For sight visibility at selected intersections or approaches when mowing is not practical

### Methods

Because Zone 1 is maintained to be free of vegetation, it requires more regular and routine maintenance attention than any other zone. The primary tools available to accomplish this are non-selective herbicide products which bind within the soil profile and suppress seed germination throughout the growing season. Non-selective herbicides which eliminate existing living plant material through contact with the leaves or stem may also be used to control emergent vegetation in this zone. But, the use of these non-selective post-emergent products alone may require more than one treatment during a single growing season. Labor time intensive non-herbicide controls are available for special situations.

## **Maintenance of Zone 2**

### **Policy**

Zone 2 is maintained to fulfill the safety and operational functions of the highway roadside. However, maintenance of this zone also has a significant impact on the visual functions, due to human perceptions of roadside neatness and degree of care. Negative visual impacts such as (brown outs) from herbicide applications should be avoided whenever possible.

Zone 2 when present begins at the edge of the pavement or the outside edge of Zone 1. It extends outward to the right of way line or the edge of Zone 3 (where present). The optimum minimum width is determined by the clear zone vehicle recovery criteria which is given in the Design Manual, Chapter 650 and the site distance criteria given in the Design Manual, Chapters 800, 910, 920, and 1020. Roadside clear zone requirements may be eliminated, when appropriate, with the installation of guardrail or concrete barrier.

Variations from the optimum minimum width may be justified based on the following:

Areas where Zone 2 may be less than the minimum width specified in the Design Manual:

- Where compromises exist on older highways and adequate widths were not established during previous construction and Maintenance funding levels do not provide for improvement.

Areas where Zone 2 may be wider than the minimum width specified in the Design Manual:

- Where the edge between Zone 2 and 3 has been set through the Design and Construction process and Maintenance has adequate resources to sustain Zone 2 beyond the minimum required width.
- Where the outside edge of Zone 2 was not established through Design and Construction, but the Roadside Classification Plan allows for and Maintenance has adequate resources to accomplish Nuisance Vegetation Control beyond the required minimum width.
- Where visual access is desirable across the right of way either from the road out or from lands adjacent to the right of way.

### **Methods**

Most maintenance activities applied in Zone 2 are intended to keep vegetation from encroaching on the highway's safety and operational functions. The maintenance focus in Zone 2 is to selectively cut back or remove vegetation which impacts these functions. Selective methods should be used whenever possible to control unwanted vegetation. An example is using a broadleaf controlling herbicide to remove noxious weeds or nuisance vegetation from a grass stand. Other methods may be non-selective, such as mowing of a grass stand as needed to prevent undesirable vegetation from maturing or setting seed.

Maintenance work in Zone 2 presents some of the most visible evidence of roadside management.

Methods selected may have a significant impact (positive or negative) on visual quality. The MAP does not directly measure visual quality as part of the service level for roadsides. However, visual quality is important to the traveling public who perceive this as an indication of the overall maintenance service level.

Legislative service level commitments and funding levels often do not allow for consideration of the visual impact from Zone 2 maintenance. Plan the timing of herbicide applications for tree and brush control in Zone 2 to minimize “brown-outs”. Avoid the use of flail or rotary type side arm mowers for side trimming of native vegetation whenever possible.

## **Maintenance of Zone 3**

### **Policy**

Zone 3 exists only when there is adequate right of way beyond the requirements for Zone 2. It is managed to be self sustaining to the greatest degree possible, naturally evolving over time to blend with the surrounding vegetation and compliment the human built environment.

Zone 3 begins at the outside edge of Zone 2, or behind guardrail or concrete barrier. It extends to the right of way boundaries on the outside shoulder, or an opposing edge of Zone 2 such as in a wide median strip or the interior of an interchange configuration. Zone 3 may also include a managed strip along the outside edge of the right of way managed to allow for maintenance access if needed.

### **Methods**

If Zone 3 has been properly designed and developed, very little attention from Maintenance normally is required. Zone 3 maintenance activities are selective whenever possible. Examples of selective maintenance treatment include the removal of noxious or nuisance weeds, hazard trees, or the thinning of trees in areas where shading increases the likelihood of frost or ice on the roadway. Some pruning of trees may be required. The majority of this work must be done by hand. Chippers may be used to dispose waste material on site. Trees should be dropped in place and left to decompose within zone 3 whenever possible.

Preserve desirable vegetation when nuisance vegetation such as Himalayan blackberry or Scotch broom is removed from Zone 3.

## **Integrated Vegetation Management**

Integrated Vegetation Management is a coordinated decision making process that uses the most appropriate vegetation management methods and strategy, along with a monitoring and evaluation system, to achieve roadside maintenance goals and objectives in an environmentally and economically sound manner.

The majority of roadside management work is focused on the control of undesirable vegetation. This goes hand in hand with the establishment of and care for desirable vegetation. To accomplish this, WSDOT is required under RCW 17.15 to utilize Integrated Pest Management (IPM) principles.

WSDOT has defined IPM methodology as it applies to roadside vegetation management in the document **Integrated Vegetation Management for Roadsides, July 1997** and uses the term Integrated Vegetation Management (IVM) as synonymous with IPM. An IVM approach can be applied beginning at any point throughout the roadside management process.

## Methods

The four basic groups of methods employed to manage vegetation are: biological, chemical, cultural and mechanical. Use of the most effective method, or combination of methods within an IVM decision-making framework as described above will result in the highest roadside service levels at the lowest life-cycle costs.

- **Biological** - Methods which use living organisms to inhibit a host plant's ability to survive or reproduce are considered biological controls. Insects, diseases, and foraging animals such as deer and cattle are examples of biological control organisms. Biological methods are typically applied only when weed infestations are so well established that total eradication is not practical or possible. Predators are dependent on the presence of host plants for survival. Careful testing and screening must be applied prior to releasing biological control organisms to ensure they will not also attack native or other desirable plants.
- **Chemical** - The use of herbicides to control weeds and undesirable vegetation, the use of plant growth regulators to reduce pruning or mowing requirements and the use of insecticides to control predatory insects of desirable plants are examples of chemical control methods. There are a wide variety of chemical control products available for vegetation management. Chemical methods can be somewhat controversial due to the potential impact of certain products on human health and the environment. Extra care must be taken when utilizing chemical controls to address public sensitivity to these tools and to minimize potentially adverse impacts.
- **Cultural** - Techniques which benefit the development and/or health of desirable, competitive plant material are considered cultural methods. Cultural methods also include the planting or seeding of desirable species. Planting and establishing the right of way in compliance with the Roadside Classification Plan, through project design and construction are cultural control techniques.
- **Mechanical** - Methods which use equipment to mow, cut, prune, or cultivate in a manner which reduces, removes or prevents undesirable plant growth. Mowing Zone 2 to remove seedling trees and undesirable brush from a grass stand is an example of mechanical vegetation management.

There are many factors to consider when planning for and implementing an IVM program. These include prioritizing needs, and selecting the proper tools and strategies. Roadside maintenance priorities

and Best Management Practices (BMPs) must be developed by the local maintenance crews for their geographic area. Priorities will be specific to the areas unique set of roadside configurations and based on service level commitments in the MAP. It is important for maintenance employees to utilize the many information resources and personnel with roadside expertise within the agency when planning for and carrying out roadside maintenance in their area.

Specific factors to consider when planning for and applying vegetation management techniques include the following:

### **Noxious Weed Control**

Noxious weed species and the processes for regulation and control are defined in RCW 17.10. All state agencies are required to control noxious weeds on lands they own.

Noxious weed control is important because new infestations often appear first along highway corridors. Management of the right of way, because of its linear nature, can impact an enormous number of neighbors. WSDOT must be a responsible steward of state owned land. It supports commerce and the economic viability of the agricultural community. The agency also values environmental preservation. To meet responsibilities it is necessary that noxious weeds be controlled. State law requires the control of certain weed species within highway rights of way. Activities required for control have to be given priority over all other vegetation management activities except those that directly and immediately affect the safety of the public.

Sometimes Maintenance resources do not allow for full control of all noxious weed infestations within a given year. In these situations the area Maintenance Superintendent and the local county weed board will need to negotiate a multi-year strategy for regaining control.

When prioritizing control efforts apply the following guidelines:

#### **First Priority**

Control all Class “A” noxious weed infestations and those weeds on the Class “B” list as designated by each individual county weed board or district to an acceptable level. The highest priority is for new infestations and established weed populations where adjacent neighbors are making an effort to comply with noxious weed regulations.

#### **Second Priority**

Areas where WSDOT has controlled noxious weeds in the past which are adjacent to neighbors that are not making an effort to comply with noxious weed regulations.

Work cooperatively with local weed boards and districts to achieve compliance on the adjacent lands where possible by:

1. Sharing information on new infestations with weed boards.
2. Advising weed boards of adjacent lands that are not in compliance
3. Requesting from the weed boards that appropriate “Weed Free” buffers

- be provided on lands adjacent to WSDOT rights of way.
4. Participating in joint control efforts contracted by weed boards.

### **Lowest Priority**

These are areas where there is no potential for neighbors to be in compliance with noxious weed regulations and there will be ongoing seed production onto the highway right of way.

### **Danger Trees**

Dead, leaning, or structurally unsound trees within the right of way can pose a threat to the traveling public. They can also damage the pavement, structures, or other parts of the highway. Remove all danger trees as soon as possible after they have been identified.

When practical, debris and wastes may be left on site within the boundaries of Zone 3. The regional Maintenance Engineer will direct off site disposal or reuse of the wood. Danger trees outside the highway right of way (or permit boundaries such as in National Forests) may also be removed by WSDOT Maintenance. If possible, consult with the property owner where the danger tree was grown prior to removal. If an emergency exists due to a danger tree outside the right of way, remove the tree immediately and notify the property owner at the earliest opportunity.

In areas where logging activities occur, adjacent clear-cuts may create a fringe of unstable trees on the highway right of way if not removed or thinned at the time of the adjacent logging. Whenever possible dangerous trees should be removed prior to or in conjunction with the adjacent logging operation. the process for removal and disposal (or sale) of timber from state property is outlined in RCW 47.12.140.

Clear cuts adjacent to the highway may create undesirable views from the road. Especially on corridors designated as scenic and recreational highways, care should be taken to preserve and protect as much of the smaller trees and native vegetation on the right of way as possible to maintain the desirable visual character of the corridor.

### **Disposal of Logs Dumped on Right of Way**

Logs dumped on any state roadway, in any state highway drainage ditch, or within 30 feet of the edge of pavement, are to be removed immediately. Logs that remain within the state right of way for a period of 30 days should be confiscated and removed or disposed of as directed by the Maintenance Superintendent.

The log transporting firm is required to immediately remove any logs dumped on the roadway or drainage ditch. If it becomes necessary for the WSDOT to remove such logs in order to comply with the law, the transporting firm will be billed for the operation including any damage to the highway.

If any logs are left on state right of way for a period of 30 days, the region will notify the transporting firm, by letter, that the logs have been confiscated by the state.

The method of disposing of such logs is at the discretion of the Regional Administrator, taking into account the merchantable value.

## **Removal of Dangerous Objects and Structures**

WSDOT has the authority to remove any structure, device, or natural or artificial object located sufficiently close to a state highway to constitute a hazard or obstruction.

Maintenance personnel should not arbitrarily remove any object from the roadside unless the object represents a definite danger to the highway itself or to highway users. The matter should be brought to the attention of the region office for an initial decision unless immediate local action is required. In some cases "Memorandums of Understanding" are in place with agencies like the Forest Service and National Park Service in order to handle these issues in the areas where they have jurisdiction.

## **Trespass and Encroachment**

All WSDOT Maintenance employees are required to obtain permission from property owners before entering private property, except in cases of an immediate emergency.

### **Encroachments- General**

Maintenance field personnel are not expected to be familiar with all the laws and policies pertaining to the use of public right of way for non state highway purposes; however, they should at least be aware of the following basic facts:

No work of any kind shall be permitted on state right of way except that authorized by law. The department has adopted policies, rules, and regulations governing legal encroachments, and permission to occupy the right of way is always covered by a written permit, franchise, or agreement.

On some highways the access rights of abutting property owners have been purchased by the state. This means that no approach roads to the highway can be constructed except those authorized in the access control plan as a result of right of way agreements.

### **Encroachment- Maintenance Crew Responsibilities**

Maintenance Superintendent assigned to sections are charged with the responsibility of reporting to their superintendent any evidence of intended or actual encroachment on the right of way by individuals, firms, or agencies for non state highway purposes.

Most violators are not aware of the law or have encroached inadvertently because of poor communication and/or unclear delineation of the right of way line.

Good public relations require that the local Lead Technician politely inform violators of the legal requirements as soon as an impending encroachment is observed, rather than to permit unauthorized work to proceed without such warning while the matter is being referred to someone else for handling. Major work is quite often contracted, and a contractor's crew may not have knowledge of a permit or franchise even if one has been granted. By a radio inquiry to his area office, the maintenance technician can usually determine if authority has been requested or granted.

Generally it can be assumed that permission has not been granted for anyone to install or erect signs, sub-standard or otherwise, on the right of way. Contact the local maintenance and/or Region Traffic Office if there are questions about the legality of any sign.

Maintenance crews should be familiar with the right of way widths on their sections in order to detect possible encroachments.

## **Franchises and Permits**

Franchises and permits are issued on standard forms that contain applicable legal requirements. Each encroachment document will include its exact location, any applicable special provisions required in the project, and how the installation is to be constructed.

A single application form, in which the applicant describes, with the aid of sketches and/or maps, what he wants to do, is used for both permits and franchises. An area or region employee makes a field investigation to determine whether or not the proposed work is permissible by law, what its effect will be on existing highway conditions, and what construction designs must be adopted to protect the interests and legal requirements of the state. If all is in order, the field investigator submits a recommendation that the application be accepted and approved and what, if any, conditions or restrictions should be included.

Maintenance should check to ensure adequate provisions are included for revegetation of any and all disturbed soil.

Franchises are issued for all utility encroachments that extend along the highway for a distance of more than 300 feet. Approval can only be granted by action of the department after the applicant has furnished proof that he has complied with all the legal requirements of posting and advertising.

Permits are issued for encroachments less than 300 feet in length. Permit forms are shorter than franchise forms and there are no posting and advertising requirements.

All permits on restricted access highways, and permits for any gas or petroleum products crossings except local gas service line, on any highway, regardless of access restrictions, must be approved by the department.

The department has extended authority to the Regional Administrator to approve all other encroachment permits, including those for local gas service crossings and for the cultivation and/or growing of agricultural crops.

See the Utilities Manual (M 22-87) for further information on WSDOT policy on franchises and permits.

## **The Use of Pesticides**

Pesticides are an essential part of an IVM program. Herbicides are the major type of pesticides used by WSDOT. When applied properly as instructed on the product labels and used in combination with other vegetation management methods, herbicides are one of the most effective and economical tools available to the roadside vegetation manager.



Within the IVM decision-making process, herbicides are often used to achieve initial control of weed infestations. Once the infestation has been reduced or eliminated through herbicide applications, other methods can be employed for long-term vegetation management. Therefore, in a successful IVM program, overall herbicide use should decrease and applications become increasingly selective over time as beneficial competitors are allowed to become more established on the roadside.

### **Pesticide License**

All pesticides applied by WSDOT including herbicides, insecticides, fungicides or other pest control agents, must be applied by WSDOT employees or contractors licensed through the Washington State Department of Agriculture (WSDA). Licenses are obtained by passing uniform tests administered by WSDA. In order to maintain a pesticide license, applicators must attend and receive credit for continuing education certified through WSDA. Forty (40) recertification credits are required every four years and no more than fifteen (15) credits can be counted for any one year.

### **Record Keeping**

Record all pesticide application information on DOT Form 540-506 EF, Pesticide Application Record. A computerized database application is available to facilitate the record keeping process. State law, RCW 17.21, requires that records of all pesticide applications be retained for seven years. Send copies of all pesticide application records to the Headquarters Maintenance Office where these files are retained. Copies may be sent electronically via e-mail if entered using the computerized database. Otherwise, paper copies must be sent.

### **Product Labels**

The label for each pesticide restricts how and where the individual product may be used. This protects the environment and non-target plant material, and ensures the safety of the applicator and the public.

Use of a pesticide inconsistent with the label instructions is prohibited by state and federal regulations. Individual pesticide applicators (even though employed by WSDOT) may be held personally liable in a case of misapplication. When planning for the use of pesticides consider all information available. This includes all information on the label of each pesticide container, plus all supplemental information provided by the manufacturer and the Washington State University Cooperative Extension Service.

### **Posting Requirements**

Immediately after the application of pesticides, it is required that signs be posted in those areas that are intended for public access such as Safety Rest Areas and bicycle/pedestrian paths. RCW 17.21.410 lists legal requirements for posting public access. For all other applications made on the right of way with power equipment, posting is required in the form of placards on the spray apparatus. Requirements for posting right of way applications can be found in RCW 17.21.400.

### **Aquatic Pesticide Applications**

Pesticide applications made in or over open water, or within delineated wetlands are subject to addi-

tional regulation and come under the jurisdiction of the Washington State Department of Ecology (WSDOE). Operators making such applications must have aquatic certification on their pesticide applicator's license and a special permit must be obtained through WSDOE. The permit includes limitations on the products available for use and provisions for public posting and notification. The Headquarters Maintenance Office is responsible for negotiating and maintaining statewide coverage for aquatic pesticide applications.

### **Pesticide Sensitive Individuals**

State law requires that pesticide applicators, prior to making an application, will notify individuals who have been medically certified as "pesticide sensitive" and live within one-half mile of the highway application site. The WSDA maintains and annually updates a list of individuals who have received this certification and their addresses. The OSC Maintenance Office is responsible for supplying information on pesticide sensitive individuals to the maintenance areas where notification is required. RCW 17.21.420 explains the process and requirements for establishing the list through WSDA. RCW 17.21.430 explains the requirements for notification of individuals on the list.

### **Container Disposal**

The Washington Administrative Code (WAC) 16-228-185(2) states in part: "No person shall transport, handle, store, load, apply or dispose of any pesticide, pesticide container or apparatus in such a manner as to pollute water supplies or waterways, or cause damage or injury to land, including humans, desirable plants and animals, or wildlife:...."

To comply with the law, all pesticide containers shall be triple rinsed (three times) each time, using a volume of an appropriate solvent (water, diesel, oil, etc.) equal to approximately 10 percent of the container's capacity. Rinsing of containers shall be accomplished as soon as possible after emptying. The rinse solution shall be added to the spray tank and considered as part of the pesticide carrier. Proper triple rinsing removes the "hazardous" stigma from the containers. However, the rinsed container must still be disposed of in the proper manner, as listed on the pesticide label.

The need for rinsing and disposal of containers can be eliminated if products are available in refillable bulk containers. Utilizing bulk and "mini-bulk" containers and metered pumps to transfer products from the container to the spray equipment reduces the chance of human contact. Where this system is used in conjunction with injection type spray equipment, unused product may be returned to the bulk container at the end of the day.

### **Use of Mowing Equipment**

Mowing is often used to achieve a neat and aesthetically pleasing appearance on the roadside, giving the impression of a high maintenance service level. However, mowing can also be an important part of an IVM program on the roadside. In this way mowing is used to maintain the desired service level in relation to controlling vegetative obstructions and nuisance vegetation in Zone 2. Use the minimum number of mowing cycles necessary to accomplish IVM objectives for the specific site. In some cases mowing cycles may be reduced to once every two or three years (or more) without compromising service level commitments.

Annual multiple mowing cycles of non-irrigated erosion control grasses that are not regularly fertilized will cause thinning of the plant population. This will reduce the grasses' competitive capabilities and allow undesirable seedling trees, brush, and weeds to become established.

Avoid mowing in areas where wildlife habitat enhancement is a recognized part of the roadside management scheme. Essential mowing can be accomplished after the nesting period for upland game birds.

Do not remove more than one-third of the total grass height in a single mowing activity, unless the grass has produced seed and dried. Mowing frequency is dictated by this principle for turf areas in formally landscaped situations. Height of mowing for erosion control grasses shall not be less than 4 inches, and preferably between 6 and 8 inches.

Whenever possible, mowing activities should take place after erosion control grasses have matured and set seed. This is desirable for the health and long-term survival of the grass stand because it allows for root growth and development. It is also important to mow during the seasonal dry period to avoid damage to the grass stand from the tires of the mowers. Mowing when soil is wet causes tire slip and compaction. Tears and exposed soil from tire slip creates windows for erosion and weed invasion.

Do not mow newly seeded erosion control grass stands until the grass has been in place one full year. As a rule of thumb, mowing will be necessary only for turf within formal landscaped areas, to improve sight distance, and to respond to local aesthetic considerations. When in doubt about the need to mow, look at the surrounding property. Keep the appearance of the highway roadside compatible with adjacent private property.

### **Other Cutting Methods**

Use saws, axes, and other cutting implements to selectively remove individual plants or parts of plants, and to remove plants that are too large to remove by mowing.

When the total plant is removed by cutting, a follow-up application with an herbicide labeled to prevent re-sprouting at the stump may be used. Cutting conifer trees below the lowest limb will eliminate regrowth. Re-sprouting of any tree or shrub will be minimized if the cutting takes place in the summer after the spring growth period is complete. The months of July, August, and September are the most effective period in which to cut trees, brush, and shrubs.

Avoid non-selective trimming on the sides of trees whenever possible. Trees should never be topped. If possible, remove the entire tree rather than damaging its natural form by pruning or topping. Pruning of trees and shrubs may be necessary to remove unsightly dead stubs or other conditions that may endanger the plant's health.

### **Cultural Control Methods**

Enhancing the competitive capabilities of a desirable vegetation by meeting its nutrient, moisture, and light requirements enables it to dominate the plant community and crowd out undesirable vegetation.

Except in irrigated landscapes it is generally not possible to affect the moisture available to plants. Selective removal of plants that are shading desirable vegetation that needs high levels of light can be done in an integrated management plan. Nutrients are supplied through applications of fertilizers that replenish a depleted food supply.

Cultural control methods are essential to establish a desirable plant complex for the future once the competitors have been eliminated by cutting and/or spraying.

### **Biological Control**

Predators normally depend on a very small number of plant species for their survival. Which is what makes them effective control agents. However, a host plant will never be totally eradicated by biological methods alone. The population ratio of the host plant and its predator varies on a cycle of approximately seven years. When the population of the predator is high, it will dramatically reduce the population of the target host plant. However, when the host plant population begins to dwindle, fewer predators can be supported and the predator population will also begin to decrease.

Generally, biological control only works on introduced species of weeds that dominate due to a lack of natural predators in the ecosystem that the weed has invaded. In most cases, biological control measures are employed to suppress the spread of existing well established weed infestations.

Biological control combined with cultural control can sometimes lead to eradication of a weed species such as Tansy Ragwort. Cinnabar Moth larvae feed on the Tansy Ragwort blooms. A Seed Fly reduces seed production, and a Flea Beetle reduces the plant's vigor by feeding in the crown and stems. Tansy Ragwort is a biennial plant that blooms and then dies if seed is produced in the second year. By introducing the biological predators, the seed produced is very limited. This limited number of seeds has little chance of establishing as plants if the surrounding soils have grass or other native vegetation that has been enhanced by a good fertilizer program.

The Cooperative Extension Service through Washington State University can provide assistance in evaluating the potential success of a biological control program.

### **Burning Debris**

Burning of brush, slash, tumbleweeds or any other waste shall be accomplished in a manner and time that conforms to the rules and regulations of the regulatory agency for that area. Contact local air pollution authorities and fire departments regarding burning requirements.

### **Illegal Tree Removal**

RCW 47.40 states that removal or damage to any desirable plant on the right of way by an unauthorized individual is a misdemeanor and punishable by law. RCW 64.12.030 and 040 discuss how courts assess damages for injury or removal of desirable plants. In cases where actions are witnessed or where it is obvious who the perpetrator is, the state patrol and the Attorney general's Office should be called in for assistance.

Unauthorized removal of materials often occur when adjoining parties feel that the trees are blocking visibility across the highway right of way. A desire to have better visibility for their establishment, their

product advertising, or simply wanting a better view of the surrounding area may lead these parties to remove vegetation without proper permission.

While it is difficult to continually monitor the entire right of way for this type of illegal activity, certain locations are more prone to neighbor's visibility issues than others and should be watched.

### **Significant Roadside Activities**

Maintenance actions on the roadside can have a significant impact on adjacent property owners and others in the public. Involving appropriate customers in significant roadside maintenance activities will often help improve the public's confidence in WSDOT's ability to manage its transportation system in a manner that is responsive to customer needs.

Advance coordination mandated by this policy may increase the initial cost of any project. But, better communication and public involvement will result in fewer complaints, enhance department credibility and improve public trust.

### **Definitions**

**Maintenance Activity:** Any activity undertaken by WSDOT maintenance employees within or adjacent to highways rights of way to preserve, protect, and enhance the safe mobility of the traveling public, the highway facility, and the environment.

**Significant Roadside Activity:** Any activity that will substantially alter the visual appearance of a roadside. Significant activities include, but are not limited to:

- Removal of large stands of vegetation
- Grading to re-contour slopes or ditches
- Removal of natural or constructed noise or visual barriers
- Any activity that alters the visual appearance of more than 1,000 linear feet of roadside

Significant activities do not include ditch and culvert cleaning, herbicide applications, mowing, erosion/slide repairs, grass seeding/fertilizing, highway hardware repair/ installation, litter pickup and/or emergency activities that are required as a result of a national disaster.

### **Notification**

Notify the public and appropriate agencies about upcoming significant activities at least one week prior to action. Notification may include, but is not limited to the following actions:

1. Telephone call
2. Flyer delivered to each residence
3. Mailed notice
4. Posted sign
5. Newspaper news release
6. Personal one on one contact
7. Posted notice on local bulletin boards
8. Public service announcement on radio or television.

9. Legal notice
10. Town meeting

## **Removal of Debris and Rubbish**

Debris and rubbish deposited on or along the highway is picked up and disposed periodically as necessary. Debris such as fallen branches and articles that have fallen from vehicles, rocks or earth slides onto the traveled portion of the roadway or onto shoulders or ditches should be removed immediately.

The remains of animals killed by motor vehicles should be removed promptly and buried at convenient locations. If license tags are present on domestic pets, notification of appropriate city or county is encouraged. The Wildlife Road Kill Report, form 335-002, should be completed, especially for deer and elk, and submitted to the Olympia Service Center. This record of killed wildlife aids in the placement of signing and other preventive measures.

Occasionally, items of value are cleared from the right of way. If possible, the owners of the property should be notified. Otherwise, the property is retained for 30 days and the area office is notified. Generally, owners of such property will contact the department. If the property is not returned to the owners, the region either places the item in inventory or declares it surplus.

## **Litter Control and Partnerships for Roadside Enhancement**

Litter is highly visible. A clean or littered roadside creates a perceived indication of the overall maintenance service level. Litter control and local community roadside enhancement are not high maintenance priorities. Roadside partnerships allow WSDOT to accomplish roadside clean up and enhancement at minimal cost.

Responsibility for litter control on state highways is shared between WSDOT and the Washington State Department of Ecology (DOE).

DOE administers a fund generated through a state tax on the sale of all containerized goods, and is charged with leading education and prevention programs. DOE also utilizes a portion of the fund to pay for litter pick up programs which may be employed to assist with cleaning litter on state highways.

The majority of litter pick up initiated by WSDOT takes place through the administration of the Adopt-a-Highway (AAH) program. WSDOT maintenance employees typically pick litter in advance of mowing operations to prevent shredding and spread of litter by mowing equipment, or where large debris such as discarded furniture items and tire shreds are present and pose a hazard to traffic.

The largest maintenance expenditure for litter control results from the pick up and disposal of bags filled by AAH volunteers, and DOE sponsored programs.

## **Adopt-a-Highway**

The Adopt-A-Highway Program (AAH) allows citizens and businesses an opportunity to contribute to a cleaner environment and an enhanced roadside appearance through partnership with the WSDOT. The program is authorized and governed by state law as defined in RCW 47.40.100.

The program is intended for use in those situations where a volunteer group or business entity wishes to help WSDOT in the performance of litter control or other activities that will enhance the appearance of the roadside. Any activity undertaken as part of this program must be in the primary interest of the traveling public and must contribute to an improved visual and/or environmental condition. The outcome of any activity must be compatible with the surrounding roadside conditions and the Department's overall policy and program goals.

## **Program Rules**

It is important to maintain a level of consistency in administration of the program throughout the state, but the individual area maintenance offices must be somewhat flexible in their interaction with participating groups. Management of the program will therefore vary to some degree throughout the state; these rules and procedures are intended to provide consistency on state-wide programmatic and legal issues.

## **Participant Eligibility**

Any organization, individual, family, business, corporation or combination thereof may participate in the Adopt-a-Highway Program by either voluntary efforts or by financially sponsoring roadside enhancement activities. The terms for each assignment shall be specified on the Adopt-a-Highway Agreement and subject to the following rules:

The name displayed on the AAH recognition sign shall be the official name of the organization, individuals, or business. Only the name may be displayed on the sign, no other information may be included. In the case of privately sponsored adoptions, where logo panels are provided by the sponsoring organization, additional information may be included if it is part of the organization's official logo.

Organizations shall not be eligible if their name:

1. Endorses or opposes a particular candidate for public office.
2. Advocates a position on a specific political issue, initiative, referendum, or piece of legislation.
3. Includes a reference to a political party.
4. Includes any words or reference to anything that may be considered or construed to be obscene to the general public.

Organizations whose agreements are terminated for failure to comply with terms shall be ineligible for participation until five years from the date of the termination.

## **Assignment of Sections**

Sections shall be assigned on a first come, first served basis. Consider the type of location and anticipated volume of litter in relation to the type of group or privately sponsored adoption. Assignment of groups, locations, management of waiting lists and special limitations or restrictions are determined by the regions. Limit volunteer adoptions due to safety concerns in locations with high traffic volumes, high litter volume, or difficult access. Sponsored adoptions may occur anywhere except construction zones. Standard litter control sections range from a minimum of two centerline miles to a maximum of ten centerline miles in length. Single organizations may adopt as many sections as desired, but each section adopted by that organization on a given route must be separated by a minimum of ten miles in the

direction of travel. Wherever possible assign new adoptions next to existing adoptions.

Sometimes the AAH Program is used to initiate a roadside enhancement in addition to or other than litter control. The activities may include planting projects or graffiti removal. In these situations assignments may be made for specific locations less than two miles in length, such as at interchanges or bridge crossings.

For type and placement of AAH participant recognition signs, see Traffic Manual (M51-02) Chapter 2.7.J and Appendix 2-9, signs 16-901 thru 16-905.

AAH agreements last for a minimum period of two years. The termination or renewal date for all agreements is February 28, unless otherwise canceled by either party. Agreements can be terminated by either party upon 30 days notice. For routine two year renewals, organizations with previously assigned sections have first right of refusal for their sections upon renewal.

Interruption of agreements may occur due to highway construction or improvement projects. WSDOT will notify all affected participants in the event of interruptions. During this period the area will be reserved for the original participants. Upon completion of construction the original participants have the option of renewing or terminating the agreement.

In some cases it may be desirable to establish agreements for special clean-up or enhancement activities through a General Permit with Special Provisions for Roadside Maintenance.

### **Volunteer Adoptions**

Volunteer adoptions are established through the form titled: Adopt-a-Highway Agreement for Volunteers (Form # 520-029).

Each volunteer organization participating in the program shall have a designated leader or coordinator.

All participants shall be at least 15 years of age.

All participants will submit a signed volunteer registration form to WSDOT. This includes the requirement for signed parental consent to be submitted for all minors, (participants under the age of 18,) prior to their participation in any roadside activities.

During roadside clean up or enhancement activities, there shall be at least one adult supervisor present for every eight minors.

Upon completion of any and all AAH events, volunteers shall complete and submit to the Department within 7 days, a Volunteer Activity Participant Form # 520-030.

### **Sponsored Adoptions**

Sponsored adoptions are established through the form titled: Adopt-a-Highway Agreement for Privately



Sponsored Work (Form # 520-028). This is a three party agreement between WSDOT, the sponsoring organization and the organization providing the clean up or enhancement. WSDOT is not responsible for agreements or contracts made between a sponsoring organization and the organization providing the clean up or enhancement. Sponsored adoptions may be initiated by either a sponsor or a potential contractor wishing to solicit a sponsor. Agreements are granted on a first come, first served basis and will only be granted when a sponsor or contractor presents a copy of a signed contract to conduct the required work.

The cost of privately sponsored adoptions and the work involved is intended to be covered by the sponsor. The agreement between the sponsor and the sponsor's contractor must include provisions for all the equipment, materials, labor and insurance necessary to accomplish the work specified in the agreement. Sponsors are required to pay a fee to the Department covering the cost of sign fabrication, installation and maintenance. The fee is based on the size and total number of signs required to satisfy the agreement, times the average cost per square foot for fabrication and installation of the signs. The per sign cost also includes a nominal administration fee to help defer the cost of establishing the agreement and coordinating with the sponsor and the sponsor's contractor over time.

Each sponsoring organization shall have a designated contact person. Each organization providing clean up or enhancement work shall have a designated crew leader for each adopted section and a designated central contact for the organization.

If, during the agreement period, the sponsoring organization fails to meet its financial obligation for the activities specified, WSDOT will allow the organization providing the clean up or enhancement to continue work under the agreement for up to 30 days, at their own expense. If the organization providing the enhancement work fails to obtain a new sponsor within 30 days, the agreement automatically terminates and all agreed upon conditions for default shall apply.

If, during the agreement period, the organization providing the clean up fails to meet its obligation or otherwise dissolves its agreement with the sponsoring organization and discontinues work, the sponsoring organization has 30 days to find a new organization to provide the clean up. If the sponsoring organization fails to contract with a new organization to provide the clean up within 30 days the agreement automatically terminate and all agreed upon conditions for default shall apply.

Upon completion of AAH events, the organization providing the clean up completes and submits within 7 days, a Sponsored Contract Activity Report Form to the department.

### **General Permits for Roadside Enhancement**

In some cases a General Permit with Special Provisions for Vegetation Management may serve as the most appropriate means to accomplish proposed roadside enhancement or special clean-up work. Use this as an option over an AAH agreement if:

- The permit Grantee is not interested in recognition through the AAH program

- The proposed work overlaps with existing AAH litter control assignments
- The proposed work is a situation where an abutting neighbor maintains such as a “No Spray” agreement
- The proposed work consists of a limited number of events.

Fill out all General Permits for roadside enhancement work using the AAH database program. This allows information to be recorded and accessed in relation to any questions regarding statewide roadside partnerships.

## **AAH Administrative Roles and Responsibilities**

Each region, and each maintenance area has unique personnel resources and responsibilities. They must assign responsibilities for the AAH Program to fit their maintenance and operations management structure.

## **Maintenance & Operations Responsibilities**

The Chief Maintenance Engineer will designate the AAH Program Manager. This position will be responsible for:

1. Establishing and maintaining standard procedures to provide uniform implementation of the statewide AAH Program.
2. Providing, maintaining and updating a statewide network database containing all participant information and standard forms, agreements, correspondence letters, and recognition certificates for the AAH Program.
3. Developing, producing, updating, and distributing to the regions all public information on the AAH Program. This includes brochures, safety literature, safety videos and State Department of Transportation web site.
4. Maintaining records on all participating sponsored contractors including proof of insurance, and activity reports.
5. Coordinating or assisting the regions in coordination of AAH partnerships through out the State including litter control and enhancement efforts.
6. Overseeing and commenting on all procedures and issues relating to the AAH Program including review of all proposed agreements which include enhancement activities other than litter control prior to signature.
7. Pay premiums or assessments required under the Revised Code of Washington (RCW) 51.12.035 to secure medical aid benefits under Chapter 51.36 RCW for all volunteers participating in the Program.
8. Record all agreement information and participant activity on the state-wide AAH Database and update as needed.

## **Region Responsibilities**

The Regional Administrator may delegate responsibilities for regional management and operation of the AAH Program to best serve the Program in that region. Day to day interaction with AAH participants will occur at the maintenance area level, but the area offices will receive varying levels of assistance from the Regional Offices throughout the State. The Regions shall delegate responsibility for the following:

1. Assignment of participating groups or sponsors to appropriate sections of high way.
2. Work with potential partners to develop proposals for roadside enhancement other than litter control.
3. Determine appropriate specifications for all agreements, including frequency of litter pick up and special provisions and plans for special enhancement projects.
4. Inform, and discuss if requested, with the Washington Federation of State Employees; Regional Chief Shop Steward, any projects other than volunteer litter control prior to approval of the agreement.
5. Erect and maintain AAH Recognition Signs in accordance with signing guidelines contained in the Traffic Manual (M51-02) Chapter 2.7.J.
6. Furnish volunteer groups with trash bags, "Adopt-a-Highway Crew Ahead" advanced warning sign(s) and stand(s), a warning light, hats and vests for all volunteer participants, and all or a portion of the materials and provide assistance required for implementation of enhancement projects other than litter control.
7. Distribute safety information, training aids and provide consultation to volunteer groups and sponsored contractors.
8. Pick up and dispose of litter bags collected by volunteer participants.
9. Collect and distribute funds paid for privately sponsored agreements to cover costs of sign fabrication, installation and maintenance, and processing agreement.

## **Auxiliary Facilities**

### **Safety Rest Areas**

Safety rest areas have been developed throughout the state adjacent to the highway and within the right of way. These facilities provide places where motorists can get off the highway for short periods to nap, stretch, snack and/or use the restroom. They also provide a safe place to pull over and telephone for help in the event of vehicle break down. Rest areas contribute to highway safety by allowing drivers to become refreshed and more alert when they resume their journey.

Regular maintenance of rest areas is important. A clean functioning rest area gives visitors and taxpayers a good impression of the state and of WSDOT. Frequency of maintenance depends largely on the use of the individual areas. Clean and service rest rooms at least twice per day or at four-hour intervals during periods of high use. Empty all trash cans. Pick up ground litter and have it removed on schedule. Wash and clean picnic tables and benches at least once a week or as often as necessary to maintain a neat appearance.

A poorly maintained safety rest area will tend to collect added trash. Users will have little respect or desire to put his trash in a litter barrel when large amounts of trash are already scattered about. Similarly, graffiti and other vandalism must be quickly repaired or additional abuse is likely. Some areas with toilets that are maintained by the department must receive extra attention and be maintained to a high

degree of sanitation. Sewage disposal facilities need scheduled maintenance of septic tanks, drain fields, pumps, filters, and back-flow prevention devices. In some rest areas chemical toilets are provided and maintained under private contract. Check them to assure that they are properly maintained. If they need attention or if there is indication of vandalism, report it immediately.

Some areas are provided with drinking water from springs or wells. Check these regularly for repair and sanitation. Take test samples of water to ensure a clean water supply. Turn off or divert contaminated water supplies until the source of contamination is found and corrected.

### **Park and Ride Lots**

It is the policy of WSDOT to plan, coordinate, develop, and implement effective partnerships for park and ride facilities. Clean, well maintained facilities help to instill a sense of confidence and safety for the users. Maintenance is critical for customer and vehicular safety, accessibility, utilization, protection of the infrastructure investments, and reduction of potential liabilities for the Department and/or transit agency.

Whenever possible, maintenance of park and ride facilities is arranged through agreement with the local transit agency. In cases where WSDOT maintenance is responsible for care of a facility, the WSDOT Park and Ride Facilities Manual (M3010.00) provide guidance on activities and procedures.

### **Historical Markers**

Historical markers and other interpretive signing within the right of way are maintained jointly with the Washington State Parks and Recreation Commission. Historical or interpretive signs and associated structures are maintained by Parks. WSDOT maintains road approaches, parking areas, litter barrels, and advance advisory signing.

### **Viewpoints**

Viewpoints have been provided at many scenic locations. Like safety rest areas they are a definite asset and safety factor to the motorist. They generally consist of a parking area with litter barrels. Maintenance requirements are not as intense as for rest areas. But, viewpoints do require regular checks to keep litter barrels emptied and trash picked up. Maintain parking areas and keep fences and guardrail in good in good repair. Assure all warning signs are in place and clearly legible. Remove all undesirable brush that would reduce sight distance and obstruct the view. Dispose the debris away from the viewpoint.

<sup>1</sup> *Highway Runoff Manual*, M 31-16. WSDOT, pp Glossary 1-2

	Page
General	7-2
Preparation for Winter Operations	7-2
Highway Categories	7-3
Special Criteria	7-4
Work on State Highways	7-4
Area of Responsibility	7-4
Snow Control Operations	7-4
Ice Control Operations	7-4
Anti-Icing and Deicing Chemicals	7-4
Level of Service Coordination	7-5
Tandem Plowing	7-5
Spinner Shut-Off	7-5
Operations at Interchanges	7-5
Railroad Crossings	7-5
Widening	7-5
Drainage Ways	7-5
Highway Sign Installations	7-5
Construction Projects	7-5
Pedestrian Facilities	7-5
City Streets on the State Highway System	7-5
Work on Other Roads and Areas	7-6
Other Governmental Agencies	7-6
Private Approaches	7-6
Abandoned or Illegally Parked Vehicles	7-6
Closures	7-6
Emergency Assistance	7-7
Precautions	7-8
Service Level Quality Measurement	7-8



### General

Removal of snow and ice from the roadway is extremely important and takes precedence over all non-emergency work.

The roadway must be plowed, sanded or deiced if necessary, and widened as quickly as possible. Snow and ice removal continues until the job is done, even if it involves working extra hours at night, weekends, or legal holidays. Work vigorously to maintain the roads in as good a condition as is possible with the equipment, materials, and personnel assigned to the work.

The department's policy is to remove snow from all high priority regularly traveled highways. After priority highways are cleared, snow removal occurs on lower priority highways according to established region/area criteria.

Some mountain passes are closed each year once deep winter snows arrive. These road closures occur where light traffic and deep snowfall does not justify the hazard and expense of attempting to keep roads open.

The snow removal operation is intended to provide the prudent motorist with a reasonably safe traveling surface. Although plowing starts soon after the storm begins, it takes time to complete the operation. During heavy snowfalls there may be periods of time when the roads will not be sanded or deiced and the motorist may need to install chains or other traction devices.

Safety for the traveling department and public personnel is the primary consideration at all times.

Economy and efficiency of operation is the goal of all maintenance personnel.

### Preparation for Winter Operations

Make plans early for winter work. Get snow plowing equipment, anti-icing/deicing equipment, sanding equipment, radio equipment, equipment operators, deicing materials, sanding materials, and supplies including signs, flags, barricades, small tools, and equipment parts ready for the first frost or snowstorm. Don't be caught unprepared for an early snow.

Prepare each roadway for effective plowing.

- Keep side ditches clean.
- Shoulders should be smooth and flush with the pavement.
- Clean sand out from under guardrail.
- Cut and remove all tall weeds, grass, and brush that may cause snow drifting.
- Clear right of way fences of wind-blown weeds and sand drifts.
- Erect snow stakes, if necessary, to indicate hazards or the edge of the roadway which may be covered with snow.

Each Area Maintenance Superintendent has maps that shows local priority routes for anti-icing, snowplowing and sanding in multilane and urban sections. Equipment operators are responsible to

study the maps and become thoroughly familiar with the priority routes. These maps are available at each maintenance section shed before winter begins.

Maintenance Supervisors are responsible to:

- Assure their employees know what is expected of them.
- Keep records that document work directions given to crews.
- Instruct all operators in the proper operation and maintenance of equipment.

WSDOT has a Winter Snow and Ice Training Program in place that instructs employees on how to properly perform winter anti-icing, deicing, snow plowing and sanding. This training especially targets the intermittent, seasonal and new permanent employee.

Calibrate each sand spreader to make the spreads required at a reasonable speed. Several drivers typically operate the same piece of sanding equipment during the winter. Some drivers may not be familiar with the specifications (or quirks) of a particular vehicle. To remedy this, post a card in the cab of each vehicle showing the truck speed or tachometer reading and adjustment to the spreader to deliver specified spreads. Variations from this calibrated rate may be necessary in accordance with actual field conditions.

Get stockpiles of sand ready for winter use. Locate stockpiles on smooth surfaces. If possible, set stockpiles up to work from the south side with maximum exposure to sunlight. Get loaders ready for operation at these sites.

## **Highway Categories**

The priority of maintenance given to a state highway facility is influenced by the functional class and amount of use (traffic) that it receives. In general highways are prioritized according to the following categories.

### **Category -1- Highway**

Interstate with an ADT (greater than) > 80,000

### **Category -2- Highway**

Interstate or Principal Arterial with an ADT (greater than) > 20,000

### **Category -3- Highway**

Interstate or Principal Arterial with an ADT (less than) < 20,000

Minor Arterial with an ADT (greater than) > 10,000

### **Category -4- Highway**

Principal Arterial with an ADT (less than) < 10,000

Minor Arterial with an ADT (less than) < 5,000

Collector with an ADT (greater than) > 5,000

### **Category -5- Highway**

Principal Arterial with an ADT (less than) < 5,000



Minor Arterial with an ADT (less than) < 5,000

Collector with an ADT (less than) < 5,000

### **Special Criteria**

The priority of a highway may be raised or lowered a category, based on the following special criteria:

1. Importance to commerce, truck routes, etc.
2. Important commuter routes
3. School bus routes
4. Proximity to population centers
5. Curvature and grade of highway alignment

### **Work on State Highways**

**Area of Responsibility .** Snow and ice control operations on state highways are restricted to the highway right of way. This includes those portions of intersecting public roads that are within the state highway right of way.

**Snow Control Operations.** Snow control operations consist of removing accumulated snow from the traveled way, shoulders, widened areas, and public highway approaches within highway right of way. When accumulated snow becomes compact and removal is not possible with available equipment, the accumulation is treated as an ice control operation.

**Ice Control Operations .** Ice control operations are done on the highway and on public accesses within highway right of way. This can consist of pretreatment of the roadway surface with anti-icing chemicals or the application of abrasives and/or deicer chemicals. When removal of compact snow and ice is not immediately possible, an abrasive application at bridges, curves, intersections, railroad crossings, steep grades, and isolated shaded areas is acceptable. Ice and compact snow are best removed under thawing conditions.

If possible, schedule ice and compact snow removal operations during the temperature rise that often occurs between 11:00 a.m. and 3:00 p.m. Use this time to clear surfaces of melting snow and ice, and to remove as much slush as possible prior to evening temperature declines. The use of road graders for ice removal is most effective during this period. Proper use of this warmer temperature period can make the difference between efficient and non-efficient cleanup operations.

**Anti-icing & Deicing Chemicals.** The use of anti-icing and deicing chemicals containing reduced chlorides such as Calcium Chloride and Magnesium Chloride or no chloride like Calcium Magnesium Acetate is encouraged. Use anti-icers/deicers in all areas where the Regional Administrator has determined there are benefits of such application.

Adverse impacts of a storm can be reduced when forecasts are used to apply anti-icing chemicals. Roadway weather information systems such as "RWIS" help WSDOT estimate the onset of road surface ice. With this information maintenance crews can apply anti-icing treatments just before a storm or ice condition hits.

**Level of Service Coordination.** Proper snow and ice control operations include coordination between adjacent regions. This assures that obvious changes in level of service on continuous sections of highway are avoided.

**Tandem Plowing.** Tandem plowing can be used for snow removal on multilane highways. Where reversible plows are available, it is often advantageous to operate one plow toward the left plowing to the median strip. In areas where drifting snow is a frequent problem, caution should be exercised in placing snow on the median. A narrow median filled with snow can cause drifting in adjacent lanes. Also, melting snow in the median can cause icy roadways during colder nights. Take care to assure that plowed snow is not thrown into the path of oncoming vehicles or onto a roadway below the highway being plowed.

**Spinner Shut-off.** In most cases spinner assemblies are used to distribute abrasives. In these situations, turn off the spinner temporarily when the sanding truck meets oncoming traffic. Stop sanding temporarily to allow backed up traffic to pass.

**Operations at Interchanges.** Interchange ramps are considered as separate roadways independent of the highway they serve. Priorities are determined by traffic volume. Ramp roadways are normally treated after one or more lanes are open on the main roadway.

**Railroad Crossings.** Never leave a windrow of snow on a railroad grade crossing. Drivers are to raise or otherwise adjust the blade before reaching the crossing to prevent damage to the crossing and/or equipment. Be aware of and avoid any conflicts between snow removal operations and approaching railway traffic.

**Widening.** Widening for snow storage, established turnouts, mailboxes, etc., may be accomplished when available manpower and equipment permit. Shoulders are often plowed in conjunction with the traveled way, or immediately after the storm is over. Clearing shoulders provides storage space for additional snow, makes the highway safer for motorists, helps prevent drifting, damage to the roadbed from moisture infiltration, and excessive runoff onto the pavement. Perform shoulder plowing in the direction of travel. Always establish proper traffic control before plowing against traffic on the median shoulder of divided highways.

**Drainage Ways.** Clear all drainage ways from the roadway surface prior to thawing conditions. Utilize a road grader or wing plow if possible.

**Highway Sign Installations.** Clear snow-covered highway signs after normal snow and ice control operations have been accomplished. Give first attention to regulatory and warning signs.

**Construction Projects.** Perform state-force snow and ice control operations on construction projects only if the project is open to traffic. Before beginning, assure that appropriate arrangements between region maintenance, construction staff and the contractor have been agreed to.

**Pedestrian Facilities.** In some urban locations, plowing operations may clog sidewalks or other pedestrian facilities. Regions need to initiate coordination with local jurisdictions in the fall to establish responsibilities and priorities for keeping pedestrian facilities free of snow. Keep in mind that areas outside the curb line are a city responsibility.

## **City Streets on the State Highway System**

RCW 47.24.20 defines the jurisdiction of the state and the cities for those city streets that serve as a part of the state highway system within the corporate limits of a city.

In respect to snow and ice control, the law provides that a city or town shall remove all snow at its own expense. Except, WSDOT is responsible to plow snow on the roadway when necessary. Cities are also required to clean the streets, including catch basins.

Cities generally plow city streets and are expected to plow the state highways in the city as well. State crews are expected to assist by plowing on the way through town. However, plowing on city streets is a secondary priority to be completed after rural lanes have been cleared.

The general exception is routes within cities that are designated as limited access highways. In those instances, the state exercises full responsibility for the entire facility and all maintenance operations.

## **Work on Other Roads and Areas**

**Other Governmental Agencies.** Snowplowing for other governmental agencies may be performed when authorized, on a reimbursable basis. When winter operations are conducted for other agencies, agreements are processed by the Region Administrator or his/her authorized representative.

Snow and ice control operations on roads and other facilities under the jurisdiction of other governmental agencies are secondary to work on state highways. Work is completed in accordance with the provisions of the agreement with the other governmental agency.

**Private Approaches.** Snow and ice control on private approaches, including that portion that may be located within the state highway right of way, is the responsibility of the abutting property owner.

WSDOT does not remove snow, ice, or sleet from private driveways, including any portion that may be located within the state highway right of way. All such activities are the responsibility of the abutting property owner.

Snow and ice control activities may inadvertently result in the deposit or the wind rowing of snow, ice or sleet onto private approaches. The department does not assume responsibility for the removal or clearance of such material, even if caused by normal winter maintenance operations. However, all employees involved in snow control operations are expected to be sensitive, considerate, and courteous when carrying out these policies.

Mailbox turnouts on the shoulders may be plowed as a part of the shoulder widening operation.

## **Abandoned or Illegally Parked Vehicles**

RCW 46.55.085 allows the State Patrol to impound abandoned or illegally parked vehicles after documented attempts to notify the owner. This process can require several days. However, if the vehicle is determined to be a hazard, the Patrol can arrange for immediate removal. The State Patrol has requested that WSDOT record any department requests for such removal, in order to support the Patrol's actions should a conflict arise with the owner of the vehicle.

## **Closures**

Occasionally winter conditions are so severe they overwhelm the capability of maintenance crews to effectively respond. This happens despite our best planning efforts and highly motivated crews. Temporary road restrictions or closures may be the only safe alternative in these situations.

The Secretary or his designated representative may temporarily close or place temporary traffic restrictions on any state highway for any reason. The Secretary or designee may also close any state highway, without delay, in an emergency. When it becomes apparent that a road section will be closed by snow, ice, snow slides, or for any other reason, maintenance personnel must take immediate action to safeguard themselves, and the public.

The following actions are taken when a road must be closed for more than an hour.

- The Regional Administrator or designee notifies the State Patrol and other pertinent organizations.
- Immediately erect appropriate traffic control devices advising motorists of the closure and possible detours.
- Take all necessary measures to prevent motorists from entering and becoming stranded in the closed section.
- Keep the Regional Public Information Officer apprised of road conditions so that the news media can be informed of closures. Emergency closures require that the Area Superintendent, Regional Maintenance Engineer, Regional Administrator and the Regional Public Information Officer be notified as soon as possible.
- Keep the State Maintenance Engineer informed of all closures that are expected to last for four hours or more and of all actions taken to reopen the roads.

## **Emergency Assistance**

During winter maintenance operations, limit emergency assistance to actions that safeguard life and property. Time spent helping motorists with minor problems could result in road conditions that would cause more serious problems for other motorists.

Employees may render emergency assistance to motorists, at the motorist's request. Stranded vehicles may be pulled onto the highway, provided the vehicle is drive-able. The motorist must make his/her own tow chain or cable hookup and disconnect. This kind of assistance is typically permissible only when snow or ice conditions are reasonably under control and when private towing trucks are not available.

It may be necessary occasionally for an employee to exercise judgment as to whether a motorist is capable of driving his vehicle. Sometimes it appears that the motorist is inebriated or otherwise unsuited to drive. In these situations notify law enforcement agencies by radio or other available means as soon as possible. Employees are required to notify the State Patrol about any accidents that occur on the highway.

Never tow any vehicle that may be unable to proceed because of lack of power or traction, except when the vehicle blocks the traveled way. In this instance, the stalled vehicle may be towed a sufficient distance to clear the normally traveled portion of the roadway to allow the safe passage of other vehicles.

Department employees may not accept compensation of any kind for this or any other type of assistance.

WSDOT desires to avoid situations that can cause the department or its employees to be sued. This has resulted in a general policy that non-employees do not ride in state-owned vehicles. However, employees may provide transportation in state-owned vehicles to stranded motorists under emergency conditions. Employees are advised to consider the particular circumstances and exercise careful judgment.

## **Precautions**

Take precautions to prevent damage to signs, mail box posts, sign posts, and other roadside appurtenances. Rotary snowplow operators are to reduce speed when in an area where adjacent buildings or facilities might be damaged from the flying snow. Redirecting the chutes helps minimize this danger. Utility lines and transformers can also be damaged by rotary plows.

Trucks must be operated at moderate speeds when removing snow, especially when slush exists. When plowing shoulders or when meeting traffic, operators need to be aware of what is going on around them. Stop or slow down occasionally to allow traffic from the rear to pass. Plowing slush at high speeds deposits the slush on signs and other vehicles and thereby obliterates warning signs. Plowing snow at high speeds causes excessive snow clouds, making the highway less safe for the traveling public.

Be especially careful when passing or being overtaken by other traffic. Avoid throwing snow onto windshields and obstructing the vision of other drivers.

Take care while removing snow in the vicinity of cars parked adjacent to the highway. Even though the cars may be illegally parked on the traveled way, take reasonable care consistent with the necessity of accomplishing the work.

Raised traffic buttons are often used in western Washington for lane stripe delineation. Care must be taken to minimize damage to the raised traffic buttons. Snowplows with rubber bits are used for this purpose—they are effective in slushy snow or in snow that has not been compacted by traffic.

## **Service Level Quality Measurement**

The Headquarters Maintenance Office has developed quality performance measurements for snow and ice control. These performance measurements have been established to assess how well maintenance offices are able to control snow and ice. The purpose is to find the best ways to do our jobs with reduced funding and personnel. These measures focus on providing targeted levels of service for snow and ice control based on the highway category and local maintenance area priority. For more details on how this process affects you, check with your supervisor.



## Chapter 8

## Traffic Services

	Page
General	8-2
Reconstruction Principles	8-2
Signing	8-3
Signing Responsibility	8-3
Sign Installation	8-3
Maintenance	8-4
Inspection	8-4
Field Repair	8-4
Sign Visibility	8-5
Sign Storage and Transportation	8-5
Delineation	8-5
Pavement Markings	8-5
Materials	8-7
Application	8-7
Marking Renewal or Replacement Frequency	8-7
Removal of Markings	8-8
Guideposts	8-8
Traffic Barriers and Impact Attenuators	8-8
Maintenance	8-8
Inspection	8-9
Repair	8-9
Standard Run of Barrier	8-9
Terminals and Anchors	8-10
Transitions	8-10
Impact Attenuators	8-11
Maintenance	8-11
Islands	8-11
Transit Vehicle Stop Zones	8-12
Maintenance	8-12





### General

Traffic services are maintenance functions necessary for the safe and efficient movement of traffic. These include maintaining highway signs, delineators, pavement markings, traffic islands, curbs, impact attenuators, barriers, guardrail, traffic signals, and highway illumination. Each serves a definite function in the control and guidance of traffic. Functions that utilize electricity, including traffic signals, ramp meters, data accumulator systems, changeable message sign systems and highway illumination systems are discussed in Chapter 10.

The application, installation, and maintenance of all traffic service functions must conform to the accepted practice and standards set forth in the FHWA Manual on Uniform Traffic Control Devices (MUTCD), the WSDOT Design Manual, the WSDOT Maintenance Time Standards Manual, and the WSDOT Standard Plans for Road, Bridge, and Municipal Construction.

### Reconstruction Principles

The following are samples of items that are subject to reconstruction to meet current design standards. The list is not all-inclusive but serves to illustrate the updating that can be accomplished.

- Breakaway bases on all sign supports and luminaire poles.
- Guardrail terminals and transitions.
- Guardrail post spacing

Use the “K Job Estimating Program” to estimate the cost of repairing damaged highway hardware in kind. When upgrading damaged hardware to current standards, attach a sheet to the Repair Cost Estimate to document why the original installation does not conform. This sheet will also show estimated additional materials, labor, and costs to bring the installation up to present design standards. Where possible, take photographs before and after repair and updating and include in the job file.

The Maintenance Program is intended to fund the repair or replacement of damaged or broken highway appurtenances to current standards.

Use federal aid interstate participation to fund the total cost of updating on interstate highways. If there are any recovered funds from responsible motorists, subtract these from the amount used to match federal aid interstate participation.

Repair and updating is accomplished by state forces or by contract. On state force work, include the work order number to be charged against on employee time sheets. A standby contract will be used to provide early contractor mobilization to assure fast repair of critical highway hardware damage.

In a region level contract, the Regional Administrator awards a contract in accordance with the delegated authority for contracts of \$50,000 or less and the provisions of M 27-02, Highway Projects of \$50,000 or less (State Funds Only), and M 27-20, Federal Aid Processing Procedures for Minor and for Standard Projects and State Force Work. WSDOT Headquarters contracts will normally be administered by either the Northwest Region or the Eastern Region in the case of western/eastern multi-region contracts.

## Signing

Highway signs are erected to convey specific messages to the traveling public. They provide regulatory, warning, and guidance information.

### Signing Responsibility

The Regional Traffic Engineer has the authority for the design, location, height, and other features associated with the installation of new signs, and for any revisions that may become necessary.

Region maintenance personnel are responsible for maintaining signs once they are in place, in consultation with the Regional Traffic Engineer.

### Sign Installation

Most signs are mounted at approximately right angles to approaching traffic. Parking signs may be installed at an angle 30 degrees or 45 degrees or even parallel to approaching traffic in order to provide visibility to vehicles adjacent to the sign.

Orientation. Normally, signs should be vertically-mounted at right angles to the direction of, and facing, the traffic that they are intended to serve. Where mirror reflection from the sign face is encountered to such a degree as to reduce legibility, the sign should be turned slightly away from the road. Signs that are placed 30 feet or more from the pavement edge should be turned toward the road. On curved alignments, the angle of placement should be determined by the direction of approaching traffic rather than by the roadway edge at the point where the sign is located.

Sign Clearance. Erect signs and their supports with maximum practical lateral and vertical clearance in accordance with the MUTCD or chapter 820 of the *Design Manual*. This will provide the most safety for motorists who may accidentally leave the roadway.

The near edge of signs is normally located more than 6 feet outside the edge of shoulder or 12 feet from the edge of the traveled lane. Where curb exists, locate the near edge of the sign no less than 2 feet from the face of the curb.

Take care when installing signs and their supports behind roadside barriers. Many barriers are designed to deflect upon impact. An inappropriately located sign or support within that area could prevent proper functioning of the barrier and may result in a potentially hazardous situation. Do not locate signs or supports within the deflection areas listed below:

<u>Barrier Type</u>	<u>System Type</u>	<u>Deflection</u>
Cable barrier	Flexible	11.5 ft
Beam guardrail		
Type 1, 1a, and 10	Semi-rigid	3 ft
Double sided beam guardrail	Type 3 and 4 Semi-rigid	2 ft

<u>Barrier Type</u>	<u>System Type</u>	<u>Deflection</u>
Concrete Barrier-Unanchored	Unrestrained-rigid	2 ft
Concrete Barrier- Anchored	Rigid	No Deflection

Use two checks when determining the height of post-mounted signs.

1. Assure the vertical clearance from the bottom of the sign to the roadway surface meets MUTCD specifications. This ensures good visibility.
2. Install signs as shown in the standard plans. This ensures that the safety mechanism (i.e., breakaway, slip base, load concentrating coupling, etc.) of the support system will function properly.

## Maintenance

Keep all signs in proper position, clean, and legible. Conduct periodic day and night inspections for position, damage, legibility, and general condition. In addition, check sign structures and sign-to-structure connections for structural integrity.

**Inspection.** In snowy areas, signs may be damaged by plows or by thrown snow or ice. Inspections are most effective after the winter weather has ended. Another inspection is recommended in the fall to ensure readiness for winter driving. In areas where weather is less severe, inspections may be correlated with other maintenance work.

Periodically check sign bridge and cantilever structure end post and metal sign post base connections. In addition, inspect sign mounting bolts and beam clips for proper tightness. Replace or secure missing or loose hand hole covers on overhead sign structure supports. Give special attention to steel sign post base and fuse plate connections. To properly function as a breakaway support while resisting wind loading, the bolt torque specified in the standard plans must be maintained.

**Field Repair.** Good judgment and sound economics dictate when to perform field repairs. Field repair minor sign damage whenever possible. More extensive damage normally requires sign replacement. Signs such as STOP and YIELD, whose absence can be life threatening, must receive priority replacement.

Signs that are repeatedly knocked down by vehicles may be reinstalled farther away from the roadway or at a different location along the roadway. Care must be taken to ensure that the new location meets MUTCD requirements.

Sign supports within the “clear zone” described in Chapter 2 must meet functional requirements of current safety standards. Sign support design elements are shown in the standard plans.

Never weld the steel sign post web to prevent wind blow-down. Proper fuse plate bolts and bolt torque will prevent blow-down.

Along with proper bolt torque, the area around the sign post base must be clear of obstructions that may prevent the post from slipping free of the base. Ensure that the base stub-post does not project more than 2 ½ inches above the ground. Projections above that height may snag the under-carriage of a vehicle.

## **Sign Visibility**

Promptly remove obstructions that prevent adequate sign visibility. Vegetation trimming is sometimes necessary to ensure adequate sign visibility. Maintenance crews must be particularly careful to avoid parking equipment in front of traffic signs.

At times, highway sign faces are obscured as a result of roadway snow removal. Clear all signs as soon as possible. Regulatory and warning signs have first priority.

## **Sign Storage and Transportation**

Store signs indoors whenever possible to prevent sign sheeting failure. The signs may be packaged if dry. If packaged signs become wet, immediately unpack and separate them to allow drying.

At times, it is necessary to store signs outside. In this situation, remove the packing materials so that nothing is against the sign face. Never lay signs flat. Water accumulating between signs laying flat will cause sign sheeting failure.

Store signs upright on edge on blocks or other material to keep the signs off the ground. Install spacers, along the sign edges to allow air circulation and normal moisture evaporation from the sign face. Avoid sign sheeting contact with treated wood. Avoid storage where dirt or water may splash on the sign face.

Transport signs on edge, face to face or back to back, to prevent sign face damage.

## **Delineation**

Delineation is defined as one, or a combination of devices, (excluding signing), that warn or provide guidance to the roadway user. These devices include pavement markings, guideposts, guardrail delineators and barrier delineators. Delineation of environmentally sensitive areas are identified with specifically marked green guideposts.

## **Pavement Markings**

Pavement markings are divided into two categories, long line and transverse. Long line markings are the markings that are applied parallel to the roadway. Typically long line markings are renewed with a spray application of new material applied from a striping truck. Typically transverse markings are renewed by hand by spray application of new material.

Long line markings include the following: Skip center stripe, no-pass stripe, double no-pass stripe, lane stripe, edge stripe, dotted extension stripe, gore stripe, dotted gore stripe, skip gore stripe, drop lane stripe, barrier stripe, two way left turn stripe and reversible lane stripe.

Transverse markings include the following: Crosswalk stripe, traffic arrows, traffic letters, handicapped parking stall symbols, high occupancy vehicle symbols, railroad crossing symbols, cycle detector symbols, drainage markings and aerial surveillance markers.

Raised pavement markers (RPMs) are installed either as positioning guides along with longitudinal markings or they are installed as a complete substitute for long line markings. Surface mounted RPMs are installed on roadways where snow removal operations use rubber blades. Recessed RPM applications consist of the installation of an RPM in a groove that has been cut into the pavement. Recessed

M applications are allowed in areas where snow removal operations use steel blades. Various markings are identified by color code as follows:

<u>RPM Type</u>	<u>Color</u>
Type 1W	White-non reflective
Type 1Y	Yellow-non reflective
Type 2W	White-one side only
Type 2WR	White and Red
Type 2Y	Yellow-one side only
Type 2YY	Yellow both sides
Type 2YR	Yellow and Red

Descriptions and dimensions of markings are shown in the Standard Specifications, Section 8-22 PAVEMENT MARKINGS. Application requirements for various markings are shown on the Standard Plans, noted by type as follows:

<u>Marking Application</u>	<u>Standard Plan</u>
Skip Center Stripe	H-3
Skip Center Stripe with RPMs	H-3
Lane Stripe	H-3
Lane Stripe with RPMs	H-3
Left Turn Channelization	H-3a
Left Turn Channelization with RPMs	H-3a
Two Way Left Turn Lane	H-3a
Single Lane On and Off Ramps	H-5
Drop Lane Stripe	H-5
Two Lane On and Off Ramps	H-5a
Collector Roads	H-5b
Traffic Arrows	H-5c
Crosswalk	H-5c
HOV Lane Symbol	H-5c
Handicapped Parking Symbol	H-5c
Aerial Surveillance Marking	H-5c
Railroad Crossing Symbol	H-5c

RPMs installed as positioning guides along with longitudinal markings are shown on Standard Plans H-3 and H-3a. RPMs installed as substitute applications for longitudinal markings are shown on Standard Plan H-5d.

## Materials

Pavement markings are renewed with a material that is compatible with the original application material. Painted markings are renewed at a thickness of 0.015 inches or 15 mils. The application guns should be adjusted to a lower millage if tracking occurs. The paint is applied at a rate of seven pounds per gallon. Thermoplastic markings are renewed at a thickness of 45 mils for long line markings and 90 mils for transverse markings. Methylmethacrylate markings are renewed at a thickness of 45 mils for long line markings and 90 mils for transverse markings. RPMs are replaced in kind.

## Application

Apply all pavement marking materials in accordance with the material manufacturer's recommendation. Apply all materials when the pavement is clean and dry. Moisture in the pavement is the major cause of most marking failures. Apply paint and thermoplastic materials when the pavement temperature is 50 degrees and rising. Methylmethacrylate material can be applied when the pavement temperature is 40 degrees and rising, provided the pavement is dry.

Paint and methylmethacrylate material is purchased by the liquid gallon. Thermoplastic material is purchased by the pound, then heated and applied as liquid. Material requirements for pavement marking materials for a continuous 4 inch line are as follows:

<u>Millage</u>	<u>Gallons/Mile (Liquid)</u>	<u>Pounds/Mile (Dry)</u>
15	16.4	-
45	49.2	875
90	98.3	1750

The Striping Supervisor is advised to contact the area Maintenance Supervisor in advance of any long line marking applications to coordinate maintenance activities and arrange for sweeping of the roadways.

## Marking Renewal or Replacement Frequency

Pavement markings are renewed when they no longer provide guidance during daytime and night-time conditions. Markings that may appear adequate in the daytime may have no reflectivity at night. Typically markings fail by loss of reflectivity long before they fail by daytime appearance.

Renew applications on the following schedule:

<b>Marking Type</b>	<b>Frequency</b>
Long line painted markings	At least once a year
Heavy wear long line painted markings	At least twice a year

Marking Type	Frequency
Thermoplastic applications	At least once every two years
Methylmethacrylate applications	Every five years
Reflective RPMs (except yellow)	By group every two years
Reflective yellow RPMs supplementing the yellow edge lines on divided highways	Every four years
Non reflective RPMs	Replaced as needed when the associated reflective RPMs are replaced

## Removal of Markings

Removed pavement markings can sometimes reappear and confuse motorists. All removed pavement markings must be unidentifiable as pavement markings under day or night, wet or dry conditions.

Do not over-paint markings with black paint or bituminous solutions. This treatment has proven unsatisfactory because the original lines eventually reappear as the overlying material wears away. In addition, lines covered in this manner may still be visible under wet conditions or low angle illumination (headlights) conditions.

## Guideposts

Guideposts are classified as guide markings rather than required warning devices. Guidepost type designations are noted on Standard Plan H-1. Guidepost placement guidelines are noted in Figure 1.

Barrier delineation is used in areas with guardrail or concrete barrier where guideposts are required by other roadway conditions. The spacing of barrier delineators for these applications is the same as the spacing noted for guideposts. Promptly replace damaged or missing guideposts and barrier delineators.

## Traffic Barriers and Impact Attenuators

Traffic barriers such as beam guardrail, cable barrier, and concrete barrier are used to protect vehicles from hazards within the Design Clear Zone (as defined in Chapter 2) that cannot be removed or otherwise relocated. Hazards may be a single point, such as a bridge pier, or an extensive area, such as steep embankments. Elements of traffic barriers include the standard run of barrier, terminals or anchors for the treatment of the ends, and transitions for connecting to stiffer barriers.

Maintain records with descriptions of observations and repairs.

## Maintenance

Barriers must be properly maintained to ensure that they will perform properly when struck by errant vehicles. Keep the area under and around barriers clean and free of vegetation and debris. Do not allow objects that could become projectiles to be placed on top of barriers.

## Inspection

Inspect barriers periodically, either by visual drive-by or by physical inspections.

### Inspect for:

- The overall condition of the barrier.
- Proper interconnection of units.
- Proper installation of anchor cables and connecting pins.
- Tightness of blocks and fasteners.
- Proper overlapping of beam guardrail.
- Secure attachment of beam guardrail.

## Repair

Repair damaged roadside barriers promptly. A response within two weeks is desired unless higher priorities preempt action. Once a damaged barrier has been identified, determine if the barriers will be repaired, replaced, or removed.

Removal of a barrier may be the best solution but this requires an evaluation of the requirement for a barrier. In some instances the need for the barrier can be eliminated (by flattening slopes or removal of a fixed object for example). Contact the Region Traffic Engineer for guidance on evaluating the requirement for a barrier. The following guidance is provided for evaluating the requirement to upgrade a barrier:

### Standard Run of Barrier

The standard run of barrier is the majority of the barrier run. It includes all of the barrier except the terminals and transition sections. Barriers have evolved over many years and as a result there are systems on Washington state highways that no longer meet current design standards.

#### Examples of non-standard barriers include:

- W-beam guardrail with 12'-6" post spacing and no block outs.
- W-beam guardrail on concrete posts.
- Cable barrier on wood or concrete posts.
- Half moon or C shape rail element.

If damage to these barriers requires the reconstruction of a significant portion of the run, consider upgrading the entire run to current standards. For minor repairs, upgrade the damaged portion of w-beam barriers to current standards (post spacing, block outs, etc.). Minor repairs to non-standard cable, half moon, or C shaped rails can be repaired in kind as upgrading may not be practical.



## Terminals and Anchors

A guardrail anchor is required at the ends of a standard run of guardrail to develop its tensile strength throughout its length. In addition, when the end of any barrier is subject to head-on impacts, a crash worthy terminal is required. Guardrail anchorage may be provided as part of the terminal, as a connection to a rigid structure, or by an anchor whose only purpose is to strengthen the run (Type 4 and 7 anchors).

Many different terminal designs have been used on Washington state highways. Upgrade damaged guardrail ends that do not have a crash worthy design.

Common features of non-crash worthy designs are as follows:

- No cable anchor.
- A cable anchored into concrete in front of the first post.
- Second post not breakaway (CRT).
- Design A end section (Design C end sections are acceptable to be left in place).
- Beam guardrail on both sides of the posts (two sided).

A common terminal that was used on Washington state highways is the Breakaway Cable Terminal (BCT). These terminals included a Type 1 anchor and a parabolic flare that offset the end 4 feet from the tangent run of guardrail. BCTs that have at least a four foot offset may be repaired in kind unless total reconstruction (replacement of the anchor) is required. Upgrade damaged BCTs with less than a 3 feet offset.

If a BCT is to be repaired, no washers can be permitted on posts 2 through 7.

When upgrading to current standards it may be possible to extend the run to a location where the end is less likely to be struck or where it can be buried in a back slope. When burying the end is not possible, consider a flared terminal as shown on Standard Plan C-4b or a non-flared terminal as shown on Standard Plan C-4e. These terminals are proprietary devices (they can only be manufactured by a licensed company) and the specific details are not shown on the standard plan. The manufacturers drawings that are used in Washington can be obtained from the manufacturer or downloaded from the Internet ([HTTP://www.wsdot.wa.gov/EESC/Design/Policy&Standards/RoadsideSafety/Chapter%20710/Chapter%20710.htm](http://www.wsdot.wa.gov/EESC/Design/Policy&Standards/RoadsideSafety/Chapter%20710/Chapter%20710.htm)).

## Transitions

Transitions are used to stiffen a system such as w-beam guardrail before a more rigid barrier such as a bridge rail. Stiffening is accomplished by nesting the rail elements, using bigger posts and reducing the post spacing. The transitions that are currently used are shown in the Standard Plans.

If no transition is in place, upgrade a damaged rail by installing a transition as follows:

Connection	Transition Type Installation
Safety shaped bridge rail	Type 1 transition with a B connection
Connection to a bridge rail with a parapet that is less than 20 inches	Type 2 transition with a B or C connection (depending on the width of the curb)
Connecting to unrestrained pre-cast concrete barrier	Type 3 transition with an A connection
Unsure of the proper transition	Contact the regional Traffic Office

Sometimes damage to a transition is minor, not requiring the replacement of all of the posts. In these situations, existing transitions that have a w-beam rail element can be upgraded by adding an additional (nested) rail element. Upgrading the connection is not required for minor repairs.

### Impact Attenuators

Impact attenuators can be used as an end treatment for barriers or to prevent errant vehicles from impacting other fixed objects. Keep records of impact attenuators in use: brand, an illustrated layout showing parts order numbers, module locations and weights, and a photograph of the installation.

### Maintenance

Replace and repair impact attenuators in accordance with the manufacturer's recommendations. Check for proper restraining cable tightness, anchor bolt tightness, diaphragm and hardware in good condition, and fender panels securely in place.

Inspect sand-filled barrels to ensure lids are firmly in place and not dented. Make sure there is no moisture inside the modules, no damage or visible cracks in the outer shell. Check that each barrel is filled with the correct amount of dry sand or dry pea gravel. (See manufacturer's specifications.)

If the sand is found to contain moisture, mix salt with the sand at a rate of 10 percent to 20 percent (by volume) to prevent freezing. Some sand may need to be discarded before adding the salt to prevent overfilling the barrel.

Replace damaged water cell units. If one is to be left in place, check for leakage.

### Islands

Islands must be properly maintained to provide protection of motorists and pedestrians. Keep island passageways clear of debris. Periodically repaint outlines of islands at least once a year. Replace missing or damaged raised pavement markers when more than three consecutive markers are missing.

Displaced or missing raised curb must be repositioned or replaced. Paint raised curb as directed by the Regional Traffic Engineer.

## **Transit Vehicle Stop Zones**

### **Maintenance**

Transit stops along state highways outside cities are maintained by the state. These locations should be kept free of debris, potholes and other obstacles that could cause tripping. The responsibility for maintaining transit stops on state highways inside cities is covered in the agreement discussed in the Traffic Manual's transit vehicle stop zone guidelines. An inventory of transit stops is available at the Regional Traffic Office.



## Chapter 9

## Electrical System Maintenance

---

	Page
General	9-2
Wiring and Connection Maintenance	9-2
Enclosure Maintenance	9-2
Documentation	9-2
Changeable Message Sign Systems	9-2
Drain Pump Systems	9-3
Gate and Barrier Systems	9-3
Minor	9-3
Major	9-3
Intersection Control Beacons (Includes Hazard Beacons)	9-3
Illumination Systems	9-3
Roadway Illumination Systems	9-3
Sign Lighting Systems	9-4
Services	9-4
Signal Systems	9-4
Vehicle Detection Systems	9-4
Pedestrian Detection and Display System	9-4
Vehicle Display Systems	9-4
Signal Control Systems	9-5
Sprinkler Systems	9-5
Television Systems	9-5



## Chapter 9

## Electrical System Maintenance

---

### General

All electrical systems require periodic maintenance in addition to non-scheduled maintenance caused by unpredictable events such as storms, accidents, and equipment failure. The intent of periodic maintenance is to keep the system operating at an acceptable level of service to the public.

Certain maintenance activities are common to all systems, regardless of type. These activities should always be performed on the cycle applicable for the system. These activities are defined as follows:

### Wiring and Connection Maintenance

- Clean conductors, terminals, and connectors of all corrosion.
- Tighten terminals and connectors including breaker, transformer, and contactor connectors.
- Check the equipment grounding system including conduit end bushing connections, bonds, equipment grounding conductors, enclosure grounding connections, and pole grounding connections.
- Check the grounding electrode, grounding electrode conductor, and associated connections.
- Check conductor insulation for damage, and repair if necessary.
- Replace deteriorated or missing conductor and terminal identification markings.
- Reference Standard Specification 8-20.3(5), 8-20.3(8), 8-20.3(9), and Standard Plan J-9a.

### Enclosure Maintenance

- Clean enclosure inside and out.
- Repair corroded surfaces, fasteners, and anchor bolts.
- Lubricate lock, latch assembly, and hinges.
- Check door gaskets and base seals.
- Clean vent filter and replace if necessary.
- Clean drain hole.

### Documentation

- Note all checks and repairs that are performed.
- Note major repairs that are required.

### Changeable Message Sign Systems

- Observe operation.
- Lubricate hinges on varicom signs and check springs.
- Relamp bulb matrix signs.
- Spot-paint changeable message sign lamp visors, sunscreen, and back ground, where necessary.
- Clean legend on disk signs.

## **Drain Pump Systems**

- Check pump pit for water.
- Check water pipes for corrosion.
- Clean sump.
- Check high water alarm.
- Test pump and lubricate.
- Check heater and thermostat.

## **Gate and Barrier Systems**

### **Minor**

- Check relays, test switch, and limit switches.
- Operate per instructions and check all moving parts.

### **Major**

- Check relays, test switch, and limit switches.
- Operate per instructions and check all moving parts.
- Clean gate surface.
- Tighten all mechanical connections.
- Lubricate shear pins, bull gear, and shaft.
- Check transmission level.
- Check collars.
- Check brake.
- Check heater.
- Remove flash guards and inspect.

## **Intersection Control Beacons (Includes Hazard Beacons)**

- Check flasher assembly.
- Relamp. (Reference Standard Specification 9-29.16(2)A.)
- Clean lens and reflector.
- Spot-paint deteriorated areas of visor and head.
- Check signal mounting.
- Check signal supports.
- Check vertical clearance (16'6" minimum for overhead locations).

## **Illumination Systems**

### **Roadway Illumination Systems**

- Relamp.
- Clean reflector and refractor.
- Check fusing in pole base (Standard Specification 9-29.10).
- Check bolt torque on slip bases.



- Check if conductors are secured on breakaway base installations at adjacent junction boxes (Standard Plan 1e).
- Replace damaged or missing pole identification markings.
- Check junction boxes, adjust if necessary.

## **Sign Lighting Systems**

- Relamp.
- Clean reflector and refractor.
- Check support mountings.
- Check fusing.

## **Services**

- Check photocell.
- Check timers.
- Check contactors.
- Megger test any illumination circuits.
- Replace deteriorated or missing service identification markings.
- Check control transformer on 480 volt services.
- Check test switch.
- Check heater and thermostat.

## **Signal Systems**

(Includes traffic signal systems, reverse lane signals, emergency vehicle signals, data accumulator stations, and ramp meter signals.)

## **Vehicle Detection Systems**

- Check amplifier operation by observing traffic and display panel indicators.
- Check loops and repair if required (Standard Plan 8a).
- Megger test loop circuits and record.

## **Pedestrian Detection and Display System**

- Check all buttons for operation.
- Replace damaged buttons and/or signs (Standard Plan J-5a).
- Clean lens and reflector.
- Relamp incandescent heads (Standard Specification 9-29.20).
- Repair neon grid assemblies as required.
- Spot-paint mounting brackets as required.

## **Vehicle Display Systems**

- Relamp displays. (Standard Specifications 9-29.16(1)A and 9-29.16(2)A.)
- Clean lens and reflector.
- Spot-paint steel mounting brackets. Aluminum or bronze mountings will not require painting.

- Check mountings for wear and tightness.
- Check tether cable assemblies.
- Check seals on aerial junction boxes.
- Check vertical clearance (16'6" minimum for overhead displays).
- Check signal supports, messenger cable connections, and back guys.
- Replace missing cable ties on span wire systems.
- Adjust junction boxes, replace missing or damaged lids.

### **Signal Control Systems**

- Observe controller timing functions.
- Check load switches.
- Check display panel, replace burned out indicator lights.
- Check coordination and communication equipment.

### **Sprinkler Systems**

- Cycle controller on 5 minute cycle.
- Check solenoids.
- Adjust junction boxes.

### **Television Systems**

- Lubricate mounting assembly.
- Check operation.
- Remove camera and shop-test.

	Page
Right of Way Fences	10-2
Road Approaches-General	10-2
Typical Maintenance Responsibilities in Cities	10-2
Maintenance Yards	10-6
Stockpile Sites	10-7
Materials from State Quarries or Pits	10-7
Procurement of Materials	10-8
Material Specifications - General	10-8
Disposal of Surplus Items	10-8
Equipment	10-8
Inventoried Items	10-8
Non-Inventoried Items	10-8
Instructions for Radio Operation	10-8
General Technique	10-8
Helpful Reminders	10-9
Work Scheduling and Reporting	10-9
Budget	10-9
Scheduling	10-10
Reporting	10-10
Environmental Sensitivity	10-10



## Chapter 10

## Miscellaneous

### Right of Way Fences

Fencing is provided to discourage encroachment onto highway rights of way. Fencing on a controlled access highway is usually owned and maintained by the state while fencing on non-controlled access highways is normally owned and maintained by the abutting property owner. Questions regarding maintenance responsibilities of a given section of fence should be resolved by the Area Superintendent.

### Road Approches- General

No road approaches are allowed without WSDOT authorization. A road approach for private access requires a permit, available at region and area offices, which stipulate the conditions under which it is granted. Such conditions often include allowed width, turn radii, paving and culvert requirements, and specific location to ensure adequate sight distance. The permit holder is normally responsible for maintenance of the approach between the edge of pavement and the property line. If permit violations are identified, the Area Superintendent should be notified. There is a fee charged by WSDOT for new road approach permits. This is to cover the administrative cost of investigating, writing and reviewing the permit. The charge is \$50.00 for an individual single family approach and an additional \$50.00 for each added user of the same approach.

### Typical Maintenance Responsibilities in Cities

Maintenance on streets may become complicated, depending on the type of installation. In accordance with RCW 47.24 and WAC 468-18-050, cities with a population greater than 22,500 have different requirements for some types of maintenance than do cities with a population less than 22,500. In general, the city or town is responsible for any portion of the facility beyond the curbs. If no curb is installed, the city or town's responsibility begins at the shoulder edge.

The following guidelines are designed to clearly identify typical maintenance responsibilities, as determined by statute, agreement, or policy, on city streets that are certified as part of a non-controlled access state highway route. They are general in nature and do not preclude WSDOT and individual cities from entering into agreements to address particular circumstances.

**Table 1**

#### **City/State Maintenance Responsibilities for City Streets as Part of the State Highway System**

<u>MAINTENANCE ITEM</u>	Population of Cities	
	<u>Over</u> 22,500	<u>Under</u> 22,500
Roadway Surface	State	State
Roadway Shoulders	State	State
Stability of Cut and Fill Slopes	City	State
Sidewalks	City	City
Curbs	State	State
Parallel Roadside Ditches	City	City

Road Approach Culverts	City	City
Cross Culvert	City[3]	City[3]
Snow Plowing	See Note[4]	See Note[4]
Sanding & De-icing	City	City
Snow Removal	City	City
Sand Removal	City	City
Channelization	City[1]	City
Crosswalks	City[1]	State
Striping	City[1]	State
Directional Signs/ Route Markers	State	State
Parking Signs	City	City
Regulatory Signs	City	State
Stop Signs - (Intersecting Streets)	City	State[7]
Signals	City	State
Guardrail, Concrete Barrier, Impact attenuators, etc.	State/City[2]	State/City[2]
Illumination	City[6]	City[6]
Street Cleaning	City	City
Street Sweeping	City	City
Vegetation	City	City
Noxious Weeds	City[5]	City[5]
R/W Encroachments	City	City
R/W Cleanup	City	City
Utility Franchises	City	City
Underground Facilities	City	City

## NOTES

- [1] As a part of state reconstruction/resurfacing projects the state will replace in kind at no cost to the local agency only pavement markings that are damaged or removed as a result of the reconstruction or resurfacing project. This does not apply to durable markings that have exceeded their useful life. Installation of higher quality pavement markings will be at the expense of the city. Early communication and plan reviews between WSDOT and the city is essential to enable local agencies to avoid installation of pavement markings, especially the more durable markings prior to construction.
- [2] Traffic barriers installed on state highways in areas without curbs shall be maintained by WSDOT. Traffic barriers installed beyond the curb shall be maintained by the cities. Curb in the context of RCW 47.24.020(2) refers to a standard curb and gutter and not to be extruded curb such as those placed on fill sections for erosion control. Guardrail, concrete barriers,

impact attenuators and similar devices are all considered to be traffic barriers.

- [3] Within all cities, regardless of population, the state shall solely maintain the structural integrity of box culverts, multiplates and individual culverts greater than 60 inches in width that are within rights of way and are not part of an enclosed drainage system. These are the size appropriate to identify natural stream flows. Those structures that are less than 60 inches in width will be maintained by the cities. Cities shall maintain all other parallel roadside ditches and road approach culverts. Grass-lined swales constructed by the state solely for state highway runoff will be maintained by WSDOT.
- [4] RCW 47.24.020(6) provides that the cities have responsibility for snow and ice removal within their jurisdiction and that the state shall, when necessary, plow the snow on the roadway. The meaning of "when necessary" is that the state will plow snow, with city concurrence, on the traveled lane of the state highway on the way through the cities not having adequate snow plowing equipment.
- [5] RCW 47.24.020(2) states that the city or town shall exercise full responsibility for and control over any such street beyond the curbs and if no curb is installed, beyond that portion of the highway used for highway purposes and, thus, are responsible for noxious weed control.
- [6] The state has responsibility for maintenance of illumination systems within fully access controlled areas. In addition, the state may, with city concurrence, maintain and operate luminaires at locations where the electrical service powerselectrical equipment under both state and city responsibility.
- [7] WSDOT, with city concurrence, may install stop signs and posts to the city's standards or may contract with the city to have them perform these installations.

**Table 2**

**City/State Maintenance Responsibilities For Bridges That Convey Non-Limited Access State Highways That Are Also City Streets (Unless Otherwise Covered Under A Separate Agreement)**

<u>MAINTENANCE ITEM</u>	<u>Population of Cities</u>	
	<u>Over</u> 22,500	<u>Under</u> 22,500
Structural Related Bridge Maintenance	State	State
Bridge Condition Inspections	State	State
L/C Overlays on Structures	State	State
Bridge Deck Membranes	State	State
Structural Asphalt Overlay on Bridge	State	State

Non-Structural Asphalt Overlay on Bridge	State	State
Approach Slab	State	State
Bridge Deck Joints	State	State
Bridge Railing	State	State
Graffiti	City	City
Deck Sweeping	City	City
Bridge Drains/Drainage	City	State
Striping	City	State
Illumination	City[2]	City[2]
Snow Plowing	See Note[1]	See Note[1]
Snow Removal	City	City

**NOTES**

[1] RCW 47.24.020(6) provides that the cities have responsibility for snow and ice removal within their jurisdiction and that the state shall, when necessary, plow the snow on the roadway. The meaning of “when necessary” is that the state will plow snow, with city concurrence, on the traveled lane of the state highway on the way through the cities not having adequate snow plowing equipment.

[2] The state has responsibility for maintenance of illumination systems within fully access controlled areas. In addition, the state may, with city concurrence, maintain and operate luminaires at locations where the electrical service powers electrical equipment under both state and city responsibility.

**Table 3**

**State Owned Bridges That Convey City or County Traffic Over a Limited or Non-Limited Access Highway Corridor**

(Unless Otherwise Covered Under A Separate Agreement)

MAINTENANCE ITEM

	<u>City/state</u>	<u>County/State</u>
Structural Related Bridge Maintenance	State	State
Bridge Condition Inspections	State	State
LMC Overlays on Structures	State	State
Bridge Deck Membranes	State	State
Structural Asphalt Overlay on Bridge	State	State



Non-Structural Asphalt Overlay on Bridge	City[1]	County[1]
Approach Slab	City[2]	County[2]
Bridge Deck Joints	See Note[3]	See Note[3]
Bridge Railing	State	State
Graffiti	City	County
Deck Sweeping	City	County
Bridge Drains/Drainage	City	County
Striping	City	County
Illumination	City	County
Snow Plowing	City	County
Snow Removal	City	County

## NOTES

- [1] Cities/counties should obtain the states concurrence prior to performing non-structural asphalt deck overlays on state owned structures.
- [2] Approach slab maintenance is the primary responsibility of the city/county. In the case where the state performs a structural overlay on the bridge deck, the state may extend the overlay onto the approach slab to provide for a smooth transition on or off the bridge.
- [3] Joints located on the bridge deck are the responsibility of the state. Back of pavement seat joint repairs are the responsibility of the city/county unless they affect the structural integrity of the bridge.

**The State has full maintenance responsibility for bridges conveying a State Route or Interstate traffic in a limited access corridor (unless otherwise covered under a separate agreement).**

## Maintenance Yards

All maintenance yards are to be kept in a neat, clean, and orderly condition. All buildings are to be kept in good repair, inside and out, and are to be repainted when necessary.

Truck sheds are to be kept clean of debris and free from fire hazards. Gasoline and other highly flammable materials should not be stored in buildings where trucks or equipment are stored. Oily rags should be kept in metal containers.

Materials and supplies are to be stored in an orderly manner and an inventory is to be kept of all materials and supplies on hand. All buildings and yards are to be kept locked when not occupied by responsible personnel.

Hazardous wastes i.e. (solvent contaminated rags, methyl methacrylate wastes, and paint residues) are to be placed in proper containers, labeled with a yellow hazardous waste label and disposed of properly within (90) days.

### **Stockpile Sites**

Stockpile sites are to be cleared of all vegetation, trees, brush, rocks, or other debris, and a uniform ground surface is prepared prior to depositing stockpile material. The site chosen should attempt to minimize visual impact, especially in urban areas. Stockpiles are to be constructed in a neat and regular shape, occupying as small an area as practical, and accessible for loading material onto trucks without obstructing the highway. Stockpiles are built up in layers. Plank runways are required for operating trucks on stockpiles where there is danger of tracking dirt or other foreign matter onto the material.

Signs that identify the material as state property should be placed at each stockpile.

Sites where materials are stockpiled year-round or for a considerable period of time should be fenced with signs placed along the fence line identifying the site as state property and the gates kept locked.

Stockpiles should periodically be inspected for vegetation growth, which should be removed.

Maintenance personnel should inspect stockpiles regularly and be on the alert against any removal of materials by unauthorized persons. The inspection should also note potential storm water impacts off-site and corrections should be made as appropriate.

Material used by state forces is to be promptly charged out and reported to the area office. Excessive amounts of materials should not be allowed to accumulate in stockpile sites. If use of stockpiled materials is not anticipated, the area office should be notified so the material can be declared surplus.

### **Materials from State Quarries or Pits**

Materials produced or manufactured in state-owned or leased pits or quarries may not be sold, or otherwise disposed of, to private individuals or concerns.

Counties and cities or other governmental agencies may participate by having their requirements included in the state's crushing contract, with proper financial arrangements. It is the state's policy to assist other governmental agencies in need of small quantities of crushed rock by selling them material from existing stockpiles at current inventory prices if the material can be spared.

When quarry or pit sites are obtained from the Department of Natural Resources, the material is to be used for state highway construction or maintenance, or by other approved public agencies. Notify the area office when material from such pits and quarries is used.

Ecology storm water permits are required at pits and quarries where aggregate is being mined or crushing operations are taking place. Contact the regional Environmental Office for information.

## **Procurement of Materials**

Materials necessary for highway maintenance are generally available from the inventory of materials in stores. Stores should be checked well in advance of need, if possible, to help ensure that materials will be available when required. Materials not available must be purchased by personnel in the area or region office. This purchasing process can take weeks or even months for certain materials. Therefore, it is imperative to plan ahead whenever possible.

## **Material Specifications-General**

It is WSDOT policy that all materials used by state forces to repair or reconstruct highway facilities and buildings conform within reason to the specifications adopted for like material in new construction.

Specifications are necessary to ensure that the department receives the quality of material required for the intended use, and to permit vendors to quote prices on an equal basis. It is difficult to dispute the quality of any material received if the original order did not explicitly define what was expected. It is imperative that maintenance personnel recognize the importance of specifications. There is a reason for a particular design, mix, formula, type, or dimension being specified. Good workmanship will not counteract the effects of the use of inferior material, material intended for another purpose, or material that would be adequate only under different conditions.

## **Disposal of Surplus Items**

### **Equipment**

If a crew determines that a piece of equipment is no longer needed or is no longer functional they should advise the superintendent or supervisor, providing information on needed repairs, problems, and future needs. This should be done to facilitate the decision on whether to transfer the equipment or dispose of it. A crew is charged for equipment even if it is not being used; therefore, it is important to be sure the equipment is necessary and operable.

### **Inventoried Items**

If it is determined to scrap an article that is carried on an inventory, the region office should be provided with a description of the article, its inventory number, and a statement of its condition. Generally, requests for replacements, with any necessary justification, should accompany the recommendation for disposal.

### **Non-Inventoried Items**

Non-inventoried items with potential trade-in or resale value may be declared surplus and turned in to the area office. Disposal of all items will be in accordance with the Disposal Manual, M 72-91.

## **Instructions for Radio Operation**

### **General Technique**

A standard radio operating procedure has been adopted by WSDOT to promote efficient use of radio facilities. All personnel have been assigned identifying numbers that are used when calling or referring to

these units. The first digit identifies the district in which the unit is located, the second digit identifies the division, and the third and fourth digits identify the person. The name of the location of the base station in lieu of the base station number is preferred.

When the channel is clear, a calling operator may initiate a call by stating which number the operator is calling and identifying who is calling. Example: 1755 wishes to contact 175, 1755 would transmit - "175 from 1755." 1755 then waits for a reply. Don't repeat a call more than twice if you are not answered. If you are not acknowledged after two calls, sign off by transmitting your call number and wait at least two minutes before repeating a call. A called person should acknowledge a call by answering his own number. As in earlier stated example, 175 would acknowledge by transmitting simply - "175." If you are unsure of your call number or of the number of the person that you are calling, it is acceptable to use names.

### **Helpful Reminders**

1. Emergency or urgent calls take priority over routine traffic. Therefore, all messages should be broken occasionally to permit another station to interrupt if there is an emergency.
2. At all times keep messages as brief, professional, and simple as possible.
3. Speak into the microphone in a normal tone of voice. Speak as clearly as possible. This is especially important when relaying technical information that the receiver may be unfamiliar with.
4. When receiving numbers in a transmission, the unit receiving should confirm the numbers with the transmitting unit.
5. Before beginning a transmission, listen for radio transmissions already in progress to avoid interrupting any other traffic.
6. Before beginning a transmission, hold the "talk switch" down for a short period (approximately a second).
7. You cannot receive radio traffic while the "talk switch" is down. Be sure to release it after completing your traffic and waiting for the reply.

For more complete instructions, refer to the WSDOT/ Highway Division Standard Operating Procedure Manual, M 58-01 Revised 1984. Reference: Directive D 58-03.

### **Work Scheduling and Reporting**

The previous sections of this manual were directed at specific maintenance activities. This section briefly covers the need to budget, plan, and report those activities. Since procedures change and various district policies vary, details for these processes are not included. The basic principles, however, will remain the same.

### **Budget**

A new budgetary biennium begins on July 1 of every odd-numbered year. At this time the department begins to spend an appropriation of money that has been established by the legislature. A portion of these funds goes to Maintenance and Operations. In exchange for the biennial appropriation, the department commits to providing a certain, statewide level of service (LOS) for each

of the forty activities identified in the Maintenance Accountability Process (MAP). Each region receives its share of these funds. The Regional Maintenance Engineer is responsible for seeing that each Area and Section office receives the appropriate share of the Region's allocation in order to meet the LOS commitments made to the legislature. Specific planning is necessary to determine anticipated work activities and their fund requirements. The key word in this budget plan is "anticipated." It is expected that actual work will not exactly match "anticipated" work. However, most work is expected and the budget plan is the basis for changes in the number of employees, equipment, and materials to accomplish the work.

By state law, units within the department may not overrun their budgets. Supervisors should be notified if budget problems begin to arise.

### **Scheduling**

Throughout the biennium, supervisory personnel must have one eye on the work to be done and one eye on the budget. To ensure that the most important jobs are accomplished within the budget limits, the biennial budget plan must be refined into a work plan for each month's activities. This enables coordination of materials and equipment availability with the work having the greatest priority for that month. Consistent with that monthly plan, Supervisors prepare a daily plan of specific work assignments for the upcoming week. This daily plan will not only recognize the priority items addressed in the monthly plan, but will also be adapted to fit current weather conditions, unexpected events, employee absences, equipment breakdowns, etc. This is the backbone of good management and alerts all employees of the following day's activity so they can make proper preparation and wear proper clothing.

### **Reporting**

The requirement to report what was accomplished in a day, by whom, and with what equipment and materials is often viewed in the field as relatively unimportant. But even though this reporting may seem excessive, it is the basis for budgeting and planning. Without accurate data on what work is actually done, it is impossible to properly prepare the next budget. And if the budget is unrealistic, planning will suffer and employees, equipment, or materials may be sent to the wrong location. Supervisory personnel should always encourage accurate reporting.

### **Environmental Sensitivity**

Maintenance is WSDOT's most visible activity with respect to environmental consequences. Painting, sanding, anti-icing, herbicide application, mowing and brush control, landscaping, and maintaining drainage are activities that can raise environmental objections. All material handling can have environmental safety implications for our employees and the general public. Environmental, health and safety issues are being addressed through an education and training program provided by the Olympia Service Center.



## ***Appendices***

---

	<b>Page</b>
City Streets As Part of State Highways	Ai-1
Traffic Control Plans	
Lane Closure on Divided Roadway	A1
Multiple Lane Closure	A2
Lane Closure on 2 Lane Roadway- Short Duration	A3
Lane Closure on 2 Lane Roadway- Flagging Provided	A4
Pedestrian Control	A5
Emergency Procedures Manual	
Work Zone Traffic Control Guidelines	
Highway Field Formulas	
Acronyms & Abbreviations	
Index	





# ***CITY STREETS AS PART OF STATE HIGHWAYS***

**GUIDELINES REACHED BY THE WASHINGTON STATE DEPARTMENT OF  
TRANSPORTATION AND THE ASSOCIATION OF WASHINGTON CITIES  
ON THE INTERPRETATION OF SELECTED TOPICS OF RCW 47.24 AND  
FIGURES OF WAC 486-18-050 FOR THE CONSTRUCTION, OPERATIONS AND  
MAINTENANCE RESPONSIBILITIES OF WSDOT AND CITIES FOR SUCH  
STREETS**

**April 30, 1997**

## **CITY STREETS AS PART OF STATE HIGHWAYS**

The jurisdiction, control, and duty of the state and city or town for city streets that are a part of state highways is specified in RCW 47.24.020; however, the implementing WAC's, directives and manuals have been subject to interpretation. This report documents agreed upon guidelines that have been reached by the Washington State Department of Transportation (WSDOT) and the Association of Washington Cities (AWC) on the interpretation of construction, operations and maintenance responsibilities of WSDOT and cities for such city streets.

These agreed upon guidelines are derived from:

- The draft Task Force Report on City Streets As Part Of State Highway.
- Response to the legislative change that increased the 15,000 city population threshold to a 22,500 population threshold for state versus city responsibilities for certain maintenance responsibilities contained in RCW 47.24.
- Additional discussions by the Department, AWC and several cities on the interpretation of state versus local agency maintenance responsibilities that are illustrated in figures contained in WAC 468-18-050 and on other maintenance responsibilities for city streets that are part of state highways.

These guidelines are designed to facilitate the allocation of maintenance responsibilities between the WSDOT and Washington Cities pursuant to RCW 47.24. The guidelines of this report are not intended to reflect past practices but to apply to future practices. They are general in nature and do not preclude the WSDOT and individual cities from entering into agreements to address particular circumstances.

These agreed upon guidelines will be incorporated in WSDOT manuals and related guidance for maintenance, operations, and construction activities. AWC will distribute copies of this report to their members.

## **AGREED UPON GUIDELINES**

The agreed upon guidelines of State and city responsibilities for city streets that are part of state highways are contained in the following tables:

- Table 1, City/State Maintenance Responsibilities For City Streets As Part Of The State Highway System
- Table 2, City/State Maintenance Responsibilities Of Bridges That Convey Non-Limited Access State Highways That Are Also City Streets (Unless Otherwise Covered Under A Separate Agreement)

- Table 3, State Owned Bridges That Convey City Or County Traffic Over A Limited Access Or Non-Limited Access Highway Corridor (Does Not Apply To City Or County Owned Bridges)

The following is an explanation of selected items of the above tables that are related to specific sections of RCW 47.24 and to WAC 468-18-050:

### 1. Guardrail (Barriers) Maintenance

**Background:** RCW 47.24.020(2) states that “The city or town shall exercise full responsibility for and control over any such street beyond the curbs and if no curb is installed, beyond that portion of the highway used for highway purposes.” The statement “...used for highway purposes...” has led to differing interpretations of WSDOT and local agency responsibilities for the maintenance of guardrail.

**Agreed Upon Guideline:** Traffic barriers installed on state highways in areas without curbs shall be maintained by the WSDOT. Traffic barriers installed beyond the curb shall be maintained by the cities. Curb in the context of RCW 47.24.020(2) refers to a standard curb and gutter and not to extruded curb such as those placed on fill sections for erosion control. Guardrail, concrete barriers, impact attenuators and similar devices are all considered to be traffic barriers.

### 2. Parallel Ditches and Cross Culverts

**Background:** The issue is clarification of what is meant by the RCW 47.24.020(2) statement “...for highway purposes...” for use in interpreting responsibilities of WSDOT and local agencies for maintenance of parallel ditches and cross culverts. Also at issue is responsibility for grass lined swale construction for water treatment purposes as compared to a ditch solely for drainage purpose. In addition a distinction needs to be made between cross culverts related to streams and maintaining natural flows as opposed to those constructed for storm drainage.

**Agreed Upon Guideline:** Within all cities, regardless of population, the state shall solely maintain the structural integrity of box culverts, multiplates and individual culverts greater than 60 inches in width that are within rights of way and are not part of an enclosed drainage system. These are the size appropriate to identify natural stream flows. These structures that are less than 60 inches in width will be maintained by the cities. Cities shall maintain all other parallel roadside ditches and road approach culverts. Grass-lined swales constructed by the state solely for state highway runoff will be maintained by the WSDOT.

### 3. Betterments - Pavement Markings

**Background:** RCW 47.24.020(13) provides that cities and towns having a population greater than 22,500 are responsible to install, maintain, operate and control all traffic control devices. This has been interpreted to mean that the city or town must replace pavement markings and similar devices when a street is resurfaced (i.e., these markings are not included in the project costs). The issue is that a WSDOT project may destroy very

recently installed pavement markings that, especially if they are durable markings (e.g., thermoplastic, raised pavement markers, etc.), involve expense to the city. The cities recommend that in-kind replacement of these markings be a part of the project costs.

**Agreed Upon Guideline:** As a part of State reconstruction/resurfacing projects the State will replace in-kind at no cost to the local agency only pavement markings that are damaged or removed as a result of the reconstruction or resurfacing project. This does not apply to durable pavement markings that have exceeded their useful life. Installation of higher quality pavement markings will be at the expense of the city.

Early communication and plan reviews between WSDOT and the city is essential to enable local agencies to avoid installation of pavement markings, especially the more durable markings, shortly before the construction activity takes place.

#### 4. Snow Plowing

**Background:** At issue is the meaning of the phrase in RCW 47.24.020(6) that states "...except that the state shall when necessary plow the snow on the roadway." This statute states that the city or town, at its expense, is responsible for snow removal. The meaning of "when necessary" and responsibility of snow plowing versus snow removal needed clarification.

**Agreed Upon Guideline:** RCW 47.24.020(6) provides that the cities have responsibility for snow removal within their jurisdiction and that the State shall, when necessary, plow the snow on the roadway. The meaning of "when necessary" is that the State will plow snow, with city concurrence, on the traveled lane of the state highway on the way through the cities not having adequate snow plowing equipment.

**Table 1**  
**City/State Maintenance Responsibilities For City Streets As Part Of The State Highway System**

<u>Maintenance Item</u>	<u>Cities Over 22,500</u>	<u>Cities Under 22,500</u>
Roadway Surface	State	State
Roadway Shoulders	State	State
Stability of Cut & Fill Slopes	City	State
Sidewalks	City	City
Curbs	State	State
Parallel Roadside Ditches	City	City
Road Approach Culverts	City	City
Cross Culverts	City [3]	City [3]
Snow Plowing	See Note [4]	See Note [4]
Sanding & De-icing	City	City
Snow Removal	City	City
Sand Removal	City	City

Channelization	City [1]	State
Crosswalks	City [1]	State
Striping	City [1]	State
Directional Signs/ Route Markers	State	State
Parking Signs	City	City
Regulatory Signs	City	State
Stop Signs		
(Intersecting Streets)	City	State [7]
Signals	City	State
Guardrail, Concrete Barrier, Impact Attenuators, etc.	State/City [2]	State/City [2]
Illumination	City [6]	City [6]
Street Cleaning	City	City
Street Sweeping	City	City
Vegetation	City	City
Noxious Weeds	City [5]	City [5]
R/W Encroachments	City	City
R/W Cleanup	City	City
Utility Franchises	City	City
Underground Facilities	City	City

- [1] As a part of State reconstruction/resurfacing projects the State will replace in-kind at no cost to the local agency only pavement markings that are damaged or removed as a result of the reconstruction or resurfacing project. This does not apply to durable markings that have exceeded their useful life. Installation of higher quality pavement markings will be at the expense of the city. Early communication and plan reviews between WSDOT and the city is essential to enable local agencies to avoid installation of pavement markings, especially the more durable markings, shortly before the construction activity takes place.
- [2] Traffic barriers installed on state highways in areas without curbs shall be maintained by the WSDOT. Traffic barriers installed beyond the curb shall be maintained by the cities. Curb in the context of RCW 47.24.020(2) refers to a standard curb and gutter and not to extruded curb such as those placed on fill sections for erosion control. Guardrail, concrete barriers, impact attenuators and similar devices are all considered to be traffic barriers.
- [3] Within all cities, regardless of population, the state shall solely maintain the structural integrity of box culverts, multiplates and individual culverts greater than 60 inches in width that are within rights of way and are not part of an enclosed drainage system. These are the size appropriate to identify natural stream flows. These structures that are less than 60 inches in width will be maintained by the cities. Cities shall maintain all other parallel roadside ditches and road approach culverts. Grass-lined swales constructed by the state solely for state highway runoff will be maintained by the WSDOT.

- [4] RCW 47.24.020 (6) provides that the cities have responsibility for snow removal within their jurisdiction and that the State shall, when necessary, plow the snow on the roadway. The meaning of “when necessary” is that the State will plow snow, with city concurrence, on the traveled lane of the state highway on the way through the cities not having adequate snow plowing equipment.
  
- [5] RCW 47.24.020(2) states the city or town shall exercise full responsibility for and control over any such street beyond the curbs and, if no curb is installed, beyond that portion of the highway used for highway purposes and, thus, are responsible for noxious weed control.
  
- [6] The state has responsibility for maintenance of illumination systems within fully access controlled areas. In addition, the State may, with city concurrence, maintain and operate luminaries at locations where the electrical service powers electrical equipment under both State and City responsibility.
  
- [7] WSDOT, with city concurrence, may install stop signs and posts to the city’s standards or may contract with the city to have them perform these installations.

**Table 2**  
**City/State Maintenance Responsibilities Of Bridges That Convey Non-Limited Access State Highways That Are Also City Streets (Unless Otherwise Covered Under A Separate Agreement)**

(This table provides an interpretation of the figures of WAC 468-18-050)

<u>Maintenance Item</u>	<u>Cities Over 22,500</u>	<u>Cities Under 22,500</u>
Structural Related Bridge Maintenance	State	State
Bridge Condition Inspections	State	State
L/C Overlays on Structures	State	State
Bridge Deck Membranes	State	State
Structural Asphalt Overlay on Bridge	State	State
Non-Structural Asphalt Overlay on Bridge	State	State
Approach Slab	State	State
Bridge Deck Joints	State	State
Bridge Railing	State	State
Graffiti	City	City
Deck Sweeping	City	City
Bridge Drains/Drainage	City	State
Striping	City	State
Illumination	City [2]	City [2]
Snow Plowing	See Note [1]	See Note [1]
Snow Removal	City	City

- [1] RCW 47.24.020(6) provides that the cities have responsibility for snow removal within their jurisdiction and that the State shall, when necessary, plow the snow on the roadway. The meaning of “when necessary” is that the State will plow snow, with city concurrence, on the roadway. The meaning of “when necessary” is that the State will plow snow, with city concurrence, on the traveled lane of the state highway on the way through the cities not having adequate snow plowing equipment.
- [2] The state has responsibility for maintenance of illumination systems within fully access controlled areas. In addition, the State may, with city concurrence, maintain and operate luminaires at locations where the electrical service powers electrical equipment under both State and City responsibility.

**Table 3**  
**State Owned Bridges That Convey City Or County Traffic Over A Limited Access**  
**Or Non-Limited Access Highway Corridor (Does Not Apply To City Or County**  
**Owned Bridges)**

(This table provides an interpretation of the figures of WAC 468-18-050)

<u>Maintenance Item</u>	<u>City / State</u>	<u>County / State</u>
Structural Related Bridge Maintenance	State	State
Bridge Condition Inspections	State	State
LMC Overlays on Structures	State	State
Bridge Deck Membranes	State	State
Structural Asphalt Overlay on Bridge	State	State
Non-Structural Asphalt Overlay on Bridge	City [1]	County [1]
Approach Slab	City [2]	County [2]
Bridge Deck Joints	See Note [3]	See Note [3]
Bridge Railing	State	State
Graffiti	City	County
Deck Sweeping	City	County
Bridge Drains/Drainage	City	County
Striping	City	County
Illumination	City	County
Snow Plowing	City	County
Snow Removal	City	County

- [1] Cities/counties should obtain the states concurrence prior to performing non-structural asphalt deck overlays on state owned structures.
- [2] Approach slab maintenance is the primary responsibility of the city/county. In the case where the state performs a structural overlay on the bridge deck, the state may extend the overlay onto the approach slab to smooth traffic flow.
- [3] Joints located on the bridge deck are the responsibility of the state. Back of pavement seat joint repairs are the responsibility of the city/county unless they affect the structural integrity of the bridge.

**The State has full maintenance responsibility for bridges conveying a State Route or Interstate traffic in a limited access corridor (unless otherwise covered under a separate agreement).**

Attachments - Intersection Diagrams from WAC 468-18-050

**CONCURRENCES:**

With the concurrence of WSDOT Executive Management, this report will be transmitted to WSDOT Assistant Secretaries and Regional Administrators and to the Association of Washington Cities for implementation of the agreed upon guidelines.

Respectfully submitted for acceptance,

_____ Dave Dye	_____ Date	_____ Dennis B. Ingham	_____ Date	_____ Craig Olson	_____ Date
Maintenance Engineer Field Operations Support Service Center		Assistant Secretary TransAid Service Center		Transportation Coord. Assoc. of Washington Cities	

**CONCURRENCES WITH RECOMMENDATIONS FOR ACCEPTANCE:**

_____ John Conrad	_____ Date	_____ E. R. "Skip" Burch	_____ Date
Assistant Secretary Field Operations Support Service Center		Assistant Secretary Environmental & Engineering Service Center	

**RECOMMENDATIONS ACCEPTED:**

_____ Stan Finkelstein	_____ Date	_____ S. A. Moon	_____ Date
Executive Director Assoc. of Washington Cities		Deputy Secretary for Operations Department of Transportation	



# GENERAL NOTES


		MINIMUM TAPER LENGTH (L) IN FEET						
		Posted Speed (mph)						
Lane Width (feet)	10	105	150	205	270	450	500	550
	11	115	165	225	295	495	550	605
	12	125	180	245	320	540	600	660

The maximum spacing between channelizing devices in a taper should be nearly equal in feet to the speed limit; the maximum spacing between channelizing devices used to separate traffic should be 2 times the speed limit.


All sign placement distances are  $\pm$ .

## KEY:


■ ■ Channelizing devices



Typical application—daytime maintenance operations of short duration on a 4-lane divided roadway where half of roadway is closed.




Typical application-closing multiple lanes of a multilane highway



Typical application—daytime maintenance operations of short duration on a 2-lane roadway and flagging is provided.





Typical applications—two methods for controlling pedestrian traffic by either directing pedestrians to another route or providing a walkway



# Emergency Procedures Manual

M 3014  
April 1999



**Washington State Department of Transportation**





# Emergency Procedures Manual


M 3014  
April 1999



**Washington State Department of Transportation**  
WSDOT and FHWA



Persons with disabilities may request this information be prepared and supplied in alternate forms by calling the WSDOT ADA Accommodation Hotline collect (206) 389-2839. Persons with hearing impairments may access WA State Telecommunications Relay Service at TT 1-800-833-6388, Tele-Braille 1-800-833-6385, or Voice 1-800-833-6384, and ask to be connected to (360) 705-7097.



**Engineering Publications**

Washington State Department of Transportation  
PO Box 47408  
Olympia, WA 98504-7408  
E-mail: [lovem@wsdot.wa.gov](mailto:lovem@wsdot.wa.gov)

Phone: (360) 705-7430  
Fax: (360) 705-6861

<http://www.wsdot.wa.gov/fasc/EngineeringPublications/>

## **Purpose**

The purpose of this manual is to establish emergency operating procedures for Washington State Department of Transportation (WSDOT) employees to respond to, and recover from, emergencies/disasters that effect the operations of the department.

## **Supersession**

This supersedes IL 4010.00 issued April 20, 1998.

## **RCW, WAC, and Directives**

### **RCWs**

RCW 47.28.030 — “Contracts-State Forces-Monetary Limits-Prequalification Rules”

RCW 47.28.035 — “Cost of Project, defined”

RCW 41.06.380 — “Purchasing services by contract not prohibited-Limitations”

RCW 47.28.050 — “Call for Bids”

RCW 47.28.70 — “Form of Bid-Data Required-Requirements-Refusal to Furnish Form-Appeal”

RCW 47.28.170 — “Emergency Protection and Restoration of Highways”

RCW 60.28.011 — “Retained Percentage”

### **Local Permits**

#### **Floodplain Development Permits**

RCW 86.16 — “Floodplain Management Act”

#### **Shoreline Management Permits**

RCW 90.58 — “Shoreline Management Act of 1971”

WAC 173-26 — “State Master Program Approval/Amendment Procedures”

#### **Critical Area Ordinances (CAO)**

RCW 36.70A.172 — “Growth Management Act — Critical Areas — Designation and Protection — Best Available Science to be Used”

### **State Permits**

Department of Ecology — Short Term Modifications to Water Quality Standards under RCW 90.48 are no longer issued. You must meet WQ standards.

Department of Ecology — Section 401 Water Quality Certification under 33 USC 1341

Federal Clean Water Act Section 401

RCW 90.48 — “Water Pollution Control”

WAC 173-225 — “Federal Water Pollution Control Act — Establishment of Implementation Procedures of Application for Certification”

## **Introduction**

Department of Ecology — Coastal Zone Management Certification

U.S. Coastal Zone Management Act, 16 U.S.C. 1451, et seq., and 15 CFR,  
Parts 923-930

Department of Ecology — NPDES Construction Site

National Pollutant Discharge Elimination System (NPDES) Permit

RCW 90.48 — “Water Pollution Control”

WAC 173-224 — “Wastewater Discharge Permit Fees”

WAC 173-226 — “Waste Discharge General Permit Program”

Department of Ecology — NPDES Municipal Stormwater (SW) Discharge State  
Waste Discharge Permit

RCW 90.48 — “Water Pollution Control”

RCW 90.52 — “Pollution Disclosure Act of 1971”

RCW 90.54 — “Water Resources Act of 1971”

WAC 173-216 — “State Waste Discharge Permit Program”

Department of Fish and Wildlife — Hydraulic Project Approval (HPA)

RCW 75.20 — “Construction Projects in State Waters”

WAC 220-110 — “Hydraulic Code Rules”

### **Federal Permits**

US Army Corps of Engineers — Section 10 of the Rivers and Harbors Act of 1899  
under 33 USC 403. Work or structures in or over navigable waters of the US will  
require a Section 10 permit from the Corps of Engineers.

US Army Corps of Engineers — Section 404 Permit of the Clean Water Act under  
33 USC 1344. The discharge of dredged or fill material into water of the US,  
including wetlands requires a Section 404 permit from the Corps of Engineers. This  
requirement covers the placement of material excavated or dredged from waters of  
the US, mechanized landclearing, and the discharge of any material used for the  
primary purpose of replacing an aquatic areas with dry land or of changing the  
bottom elevation of the waterbody.

Endangered Species Act (ESA)

Section 7 and 9 of the Endangered Species Act of 1973, as amended

### **WACs**

WAC 173-14 — “Permits for Developments on Shorelines of the State”

WAC 197-11 — “State Environmental Policy Act (SEPA) Rules”

### **Directives/Instructional Letters**

IL 07-45 — “Emergency Declarations”

IL 27-02 — “Region Ad and Award . . . Construction Projects”

D 27-60 — “Federally Funded Highway Construction Project Closure Process”

M 72-80 — “Purchasing Manual”

1:P:DP/EPM

# ***Emergency Declarations***

---

## **Introduction**

When an emergency occurs the region needs to determine if the emergency requires an “Emergency Declaration.”

An “Emergency Declaration” is required whenever it is necessary to utilize emergency contracting procedures” for work related to transportation facilities and to increase the limit for State Force repair work from \$50,000 to \$80,000.

If the event is large enough that federal “Emergency Relief” funding will be pursued the Region needs to contact FHWA in Olympia so that a Detailed Damage Assessment Form (DDIR) can be prepared.

The following is applicable to all divisions of the Department of Transportation.

## ***Declaration of Emergency***

The Declaration of Emergency authority is hereby delegated from the Secretary of Transportation to the Regional Administrators and the Assistant Secretaries of Aviation and Ferries for all work directly or indirectly related to transportation facilities. This also includes all work affecting property owned or used by their headquarters organization.

The Declaration of Emergency authority can be further delegated to the Maintenance Superintendent by the Regional Administrator or a designee of the Assistant Secretaries of Aviation and Ferries, when the preliminary repair estimate to provide the work does not exceed \$80,000 including sales tax, this also applies to property owned or used by a headquarters organization.

The Regional Administrators and/or the Assistant Secretaries for Aviation and Ferries are required to inform the Secretary of Transportation of all declared emergency projects. The Secretary of Transportation or designee is responsible for reporting all projects over \$200,000 to the Commission at the next regularly scheduled meeting or as soon as practical.

Each declared emergency will be recorded on DOT Form 540-021X (see Appendix 1). The form is to be signed by the declarer and sent to OSC Emergency Management by the next working day. For each declared emergency, a project title will be given and work order(s) will be established. The same project title should be utilized wherever possible throughout all subsequent work phases and communications concerning the emergency.

## **Procedures**

<i>Action By</i>	<i>Action</i>
Maintenance Superintendent and Designee(s) for the Assistant Secretaries for Aviation and Ferries	<ol style="list-style-type: none"><li>1. Prepare declaration of emergency using DOT Form 540-021X, emergency work under \$80,000 and related to transportation facilities</li><li>2. Send Form to OSC Emergency Management Office by the next working day</li></ol>
Regional Administrator and Assistant Secretaries for Aviation and Ferries	<ol style="list-style-type: none"><li>1. Prepare declaration of emergency using DOT Form 540-021X, emergency work over \$80,000 and related to transportation facilities</li><li>2. Send Form to OSC Emergency Management Office by the next working day</li></ol>

**Note:** OSC Emergency Management Office will make distribution of the Emergency Declaration Form to the Transportation Commission Administration, Secretary of Transportation, OSC Communications and Public Involvement Office, Assistant Secretary for Finance and Administration, Assistant Secretary for TransAid, OSC Program Management, OSC Records Control, OSC State Maintenance Engineer, and to State Emergency Management (Military Department).

2:P:DP/EPM

# ***Maintenance-Construction Work Definition***

---

## **Ordinary Maintenance**

There are two types of Maintenance work activities classified as “ordinary maintenance” — Normal Maintenance and Emergency Maintenance.

Accordingly, if the work is considered to be “ordinary maintenance” state forces may accomplish the work without being subject to the dollar limitations outlined in RCW 47.28.030 and 47.28.035. “Ordinary maintenance” is also exempt from the competitive bidding process.

### ***Definition of the Two Types of Maintenance Activities***

1. **Normal maintenance** — budgeted work, performed routinely on a scheduled basis. It is intended to maintain the highway facility/element so that it substantially retains its original intended use and function.

#### **Examples include:**

Sweeping and debris removal	Maintaining access control
Clean ditches, culverts, and catch basins	Drainage restoration
Correcting moderate slides and slope failures	Placing riprap
Vegetation management and litter pickup	Snow and ice control
Moderate bridge maintenance	Traffic control
Rest Area operation and maintenance	
Pavement patching, crack sealing, and moderate surface treatment	
Bridge maintenance such as debris removal, scour	
Restoration/replacement of traffic control devices	

2. **Emergency maintenance** — work activities are the same or similar to normal maintenance activities except that they are greater in magnitude and scope depending upon the nature and intensity of the emergency. This work is not budgeted and/or scheduled and is done on a routine basis. This includes work accomplished on a damaged highway facility/element that has substantially retained the intended functionality of its original design. It does not include construction of new roadway elements.

#### **Examples include:**

Erection, dismantling, and maintenance of a Bailey bridge  
Establishment of detours and temporary minor structures  
Emergency traffic control  
Any work needed to protect and maintain the area affected by the emergency, pending the letting of a contract under RCW 47.28.170.

## ***Funding***

1. **Normal maintenance** is not eligible for federal reimbursement because it is routinely scheduled or budgeted to historical levels. This work is funded out of the state-funded M2 maintenance budget. Normal work orders, charge numbers, and coding are used to track accomplishments and costs.

2. **Emergency maintenance** work may be eligible for federal reimbursement when properly approved by FHWA if the work at a defined site exceeds the threshold amount, currently \$5,000. This work is initially funded out of the maintenance budget and later reimbursed with federal funds. Disaster Maintenance (DM) work orders are established to ensure the department properly accounts for and documents expenditures.

As a footnote, there are other federal agencies which provide emergency funding, including the Federal Emergency Management Agency (FEMA) and the Corps of Engineers (COE). Each agency has different eligibility requirements. These are not discussed in this document.

### ***Limitations on Contracting Out Maintenance Work***

The department may contract out ordinary maintenance work instead of using state forces if:

- Such work was regularly done by a valid contract prior to April 23, 1979; and,
- The contract does not have the effect of terminating classified employees or eliminating classified employee positions existing at the time of the execution or renewal of the contract (see RCW 41.06.380).

If the proposed work activity has been **traditionally** or **historically** performed by state maintenance forces, it would be considered “ordinary maintenance.” Conversely, if the proposed work has been considered by the department as an “alteration, repair, or improvement” activity, as those terms are defined below, the proposed work is not considered “ordinary maintenance” and is subject to RCW 47.28.030.

If there is any question as to whether the activity can be considered “ordinary maintenance,” a good faith decision should be reached based upon the facts of each particular situation, keeping in mind the purpose of RCW 47.28.030. Support for this decision needs to be documented at the time it is made and submitted on the Work Order.

### ***Emergency Projects in the Highway Construction Program***

The project magnitude and scope should be reviewed to determine if the work is in maintenance (can be done with state forces or requires a contract) or it should be in the Highway Construction Program.

If upon reviewing the magnitude and scope of the work, Maintenance believes this project should be in the Highway Construction Program, they should immediately begin discussions with the Regional Program Manager giving that person all the available information they have about the project and why they feel the project should be in the construction program.

The Regional Program Manager will immediately contact the OSC Program Management Engineer or his office for concurrence that the project is construction program work and to establish a work order.

OSC Program Management, with help from Regional Program Management, will obtain approval and programming of the unprogrammed project and approval of the Work Order.



If the proposed work activity is not considered ordinary maintenance as defined above, the work may be accomplished by state forces only to the extent permitted in RCW 47.28.030 and RCW 47.28.035. This rule applies whether the work involves an emergency or not.

This work typically requires the use of preliminary engineering services and personnel and contract plans, specifications and estimates. When the work is not programmed, it follows the department's screening board unprogrammed project process.

### ***Definition of Construction Type Activities***

1. **Alteration** — Work that results in a substantial change in the form or nature of an existing highway facility/element without destroying its identity.

**Examples include:**

Realignment of the roadway  
Widening the roadway  
Raising the grade  
Replace span wire with mast arms

2. **Repair** — Work required to restore the intended functionality of a highway facility/element when damage results in a substantial loss of the intended design functionality.

**Examples include:**

Major slide (may require soils analysis and walls)  
Repair of large culverts  
Replacement of major sections of riprap  
Roadway paving  
Replacement of bridges, bridge approaches, or bridge piers  
Work needed to repair a section of washed out road that is not passable

3. **Improvements** — Work that results in the enhanced, expanded, or improved functionality of a highway facility/element over that of the original design. This work includes new roadway elements and improves the original function and design.

**Examples include:**

Culvert replacement to improve drainage  
Constructing all weather highway  
Constructing left turn lane or climbing lane  
Hydraulic enhancements  
Correction of unstable slopes through the use of horizontal drains, new wall, or other methods

### **Funding for Construction Work**

Emergency work considered to be “alteration, repair, or improvement” when properly approved, is eligible for federal reimbursement, either from normal highway construction funds or Emergency Relief funds. Work is initially funded out of the highway construction program with state funds and later reimbursed with federal funds. Appropriate work order numbers are established to ensure the department can properly account for and document expenditures (see Section V. Maintenance Work Order Process).

### **Limitations on State Force Forces Accomplishing Construction Work**

If the work involves “alteration, repair, or improvement” as defined above, the statutory requirements set forth in RCW 47.28.030 and RCW 47.28.035 apply as follows:

- The work may be done by state forces when the **estimated** cost of the work is **less** than \$50,000.
- When delay of the work would jeopardize a state highway or constitute a danger to the traveling public, the work may be done by state forces as long as the **estimated** cost of the work is **less** than \$80,000.
- If the estimated cost of a project is **more** than the \$50,000/80,000 limitations, state forces **may** still be used to perform work up to those limits. The cost of the remaining project work over the \$50,000/\$80,000 limits would have to be contracted out by competitive bidding.

RCW 47.28.035 sets out two rules that must be followed in estimating the cost of using state forces.

- First, the costs must include the aggregate of all amounts to be paid for **labor, material, and equipment** (see below).
- Second, the aggregate costs are those costs that will be incurred on **one continuous or interrelated project** where work is to be performed **simultaneously**.

*Note:* To better understand this second requirement, one must go beyond the actual statute language and the difficulty of defining the key term “project,” and focus on the objective of the statute. Its purpose is to ensure that a project is not artificially divided into smaller projects for the sole purpose of using state forces instead of contracting out the work.

The estimate must be reasonable based on the best information known at the time it was made. To support the reasonableness of the estimate, written documentation on how it was ascertained is necessary (RCW 47.28.030). The purpose of the dollar limitation is to ensure that the majority of non-maintenance emergency work is done by outside contractors. Therefore, the estimate should be reasonable in view of the facts that are known at the time and consistent with the purpose of the limitation. Any questions on what should be included in the estimate should be directed to the department so that the estimates are consistent.

The following examples are provided to help understand how the estimate should be made:

**To be included:**

1. **Labor costs** would be included when state personnel are being used on the project to do the following:
  - a. Operate equipment
  - b. Place material
  - c. Any activity done on site that would have been done by the contractor's labor force if the work had been contracted out.
2. **Material costs** that would be included are:
  - a. Material obtained from a WSDOT stockpile.
  - b. Material purchased, hauled, and placed by state forces.
3. **Equipment costs** to be included are:
  - a. Use of state-owned equipment.
  - b. Cost of rental equipment if the equipment is being operated by a state employee.

**Not to be included:**

1. In estimating labor costs, the following are not to be included:
  - a. Preliminary engineering costs (PE)
  - b. Construction engineering costs (CE)
2. **Material costs** that are not to be included are:
  - a. Material purchased from a contractor and contractor delivered to the site for the particular project. (If placed by state forces, the labor costs would be included, but not the material costs.)
  - b. Materials delivered to the site by the contractor and placed by the contractor's labor force. (Neither the labor costs or material costs are included because the work is being done by the contractor.)
  - c. Consumable items not incorporated in the project (e.g., traffic control devices, signs, etc.).
3. If the rental equipment is not being operated by a state employee, the cost of the rental is not to be included.
4. Overhead costs are not to be included.

3:P:DP/EPM



## ***Definition of a Project***

---

In order to meet the intent of RCW 47.28.030 and RCW 47.28.035, a project is defined as one continuous or interrelated project where work is to be performed simultaneously.

RCW 47.28.035 indirectly defines a project as the aggregate of all amounts to be paid for labor, materials, and equipment on one continuous or interrelated project where work is to be performed simultaneously.

### **Definition of Continuous and Interrelated**

With the statute's objective in mind, one must remember that a project consists of a series of activities or events that must be accomplished to produce an intended result. The project is generally "continuous" in nature (both length and depth) until each required activity is completed to produce the desired outcome. Also, each activity cannot alone create the final result. They must be "interrelated" with other activities to establish the final goal and objective. The activities are part of the overall project and logically could not be considered as separate and independent projects. The statute simply says that the individual activities or units of work will not be considered as separate projects for the purpose of using state forces to do work.

### ***Definition of Simultaneously***

The statute also refers to work being performed "simultaneously." This term must be interpreted in view of what actually happens on a project. It's obvious not all of the activities can be done at the exact same time. However, they must be accomplished before the entire project is completed. For example, if the road is washed out, the end result is to replace the road. To accomplish this, the activities would include replacement of fill, riprap, crushed surfacing, paving, striping and guardrail. The work activities are not being phased because of future funding or other reasons; but simply continuing on until the work is completed and the new road is in place. As long as the activities are being carried in a logical sequence to produce the end result, the work is being done "simultaneously" for purposes of the statute.

### ***Other Considerations***

If several activities, each of which could be considered separate projects under RCW 47.28.035, have been combined for accounting and/or contracting convenience, the reason for the combination should be documented. This prevents an appearance that the dollar limitations have been exceeded.

In defining what a project is for purposes of estimating the cost of state forces, the following should be kept in mind:

1. The purpose of the statute is to preclude the department from dividing a proposed project into units of work or classes of work in order to avoid the dollar limitations set forth in RCW 47.28.030. If the project is being divided into artificially smaller elements, the statute is being violated.

## **Definition of a Project**

2. There should be a reasonable basis for determining what a project is when estimating costs. Is it logical to group these activities into separate projects instead of one? Has the department done it before and what were the reasons for doing it that way? Does it make common sense? These questions need to be answered before we decide, in good faith, to divide the work into more than one project.
3. The definition of a project for purposes of RCW 47.28.030 and RCW 47.28.035 should be uniformly applied by the department.

The following examples explain how a project is determined for purposes of complying with RCW 47.28.030 and RCW 47.28.035. The examples are of situations where the work would be considered as a single project as well as examples where the department in good faith could consider the work as independent projects.

**Example 1:** Assume two major slides occur causing extensive damage to the roadway. The damaged areas are separated on the roadway by only a few feet. Technically, the work to clear and repair the two areas is not continuous because of the separation. However, since the distance is so minimal, the work in both areas would be considered as one continuous project. Also, RCW 47.28.035 refers to “. . . one continuous or interrelated project.” In the example, all of the work is interrelated because both areas would have to be repaired before that section of roadway could be used by the traveling public. Thus, for purposes of the statute, the work activities at both locations would be treated as one single project.

**Example 2:** Two major slides occur on the same highway but are located several miles apart. Unlike, Example 1, the distance between the slides is substantial so work at the two locations would not be considered as one continuous project. Also, the repair work at location one can be completed to open that section of the roadway independent of the repair work at location two. Thus, the work at the two sites is not interrelated. As a consequence, the work at the slide areas would be considered two separate projects.

**Example 3:** A slide covers one mile of road. In order to restore the road for traffic use, the following work activities must be done: (1) removal of debris; (2) replacement of fill material; (3) repair of the shoulders; (4) repaving; and (5) placement of new guardrail. Each of these activities are interrelated in order to put the road back into service. The work is also being done in a logical sequence so it is being performed “simultaneously.” Therefore, the sum total of the work would be considered as one project instead of five separate jobs for purposes of estimating the cost of using state forces.

**Example 4:** Three slides occur on the same highway. Two are located ten feet apart and the third one is located five miles to the north. The only work activities involved to open the roadway in all three locations is to remove the debris and clean the ditches. The issue of what is considered a project for

purposes of RCW 47.28.035 only applies where the activity involves either “construction, repair, alteration, or improvement work. Unlike examples, 1, 2, and 3, the work activities in this example would be considered emergency maintenance work. Therefore, state forces can be used to do all of the work regardless of costs and regardless of whether the three work areas are classified as one or more projects.

**Example 5:** A storm does damage to a bridge structure and two culverts in the same area. Work is done immediately to repair the culverts. However, because of lack of funding or other legitimate reasons, a decision is made to delay repair work to the bridge. Since the repair work on the culverts can be accomplished without repairing the bridge, the two activities are not interrelated. Also, the bridge work will occur at a later date so the work is not continuous. Therefore, the repair of the culverts and the subsequent bridge repair work can be treated as two separate projects.

**Example 6:** Work is done to correct unstable slopes in multiple locations. Each site can be corrected independent of the improvement work at the other sites. Also, the work is not continuous because of the separate locations. Therefore, the improvement work at each location would be considered a separate project.

**Example 7:** One rest area is damaged. The repairs include removal of debris, replacing sections of the sidewalk, and repaving. The work is continuous because all of the repairs are being made at one location. These activities are also interrelated because the repairs must be done in order to put the rest stop in the condition it was prior to the damage. The individual repair activities cannot be considered as separate projects but must be treated as one project for purposes of estimating the cost of using state forces.

4:P:DP/EPM





## ***Maintenance Work Order Process (DM)***

---

### **General**

When an emergency/disaster occurs a method for capturing expenditures for the work both within the region as well as for federal emergency (ER) work is needed. The Work Order Authorization (WOA) is the method used to capture these expenditures. A separate WOA is normally set-up for each individual disaster site and has a unique identifying number. For a Disaster Maintenance (DM) WOA this number has a "DM" prefix.

The WOA is also used for budgeting purposes and in obligating federal funds; thus it is important that the WO is as current as possible and accurately reflects current and future expenditure needs.

Approval of the DM work order and assigning the "DM number" has been delegated to the regions. The specifics of this new process are listed below.

Disaster Maintenance (DM) work orders are initially set up with state funds since early on it is not known whether they will be eligible for federal participation or not. In many cases, part or all of the emergency work may be done prior to knowing if the project will receive federal participation. Once the magnitude of the disaster and the funding requirements are known and before OSC Accounting Services can bill FHWA for reimbursement, it may be necessary for OSC Maintenance to obtain a federal appropriation from the Office of Financial Management (OFM).

As a general rule (except for specific nonparticipating items), emergency work and/or incidental permanent work within 180 days of the disaster is eligible for 100 percent federal participation. Permanent work and emergency work after 180 days is eligible for federal participation at a federal pro-rata share for the route the work is on, in most cases 86.5 percent.

When requesting information from OSC on the status of a WOA, reference the work order number and the federal aid number if known.

In setting up DM work orders, region management and field personnel will also consider:

1. The need to prepare Detailed Damage Inspection Reports (DDIR) for FHWA review/approval that clearly define scope of work, type of work, location, and estimated costs of the emergency and/or permanent work.
2. The need to manage the DM setups and be accountable for the costs incurred under the DM setup.
3. That the region be able to ascertain, through inspection, that the work performed was accomplished in accordance with the scope and/or approved change orders to the DDIR.
4. The estimated cost associated with a work order setup. Because of the complexity of some emergency work it may be necessary to have some work orders for an estimated amount greater than the \$50,000/\$80,000 limit.

**Procedures for Setting Up DM WOA**

The current process is as follows:

<b><i>Action By</i></b>	<b><i>Action</i></b>
Region Maintenance Analyst or Designee	Assign DM Work Order Number and log required data.  Prepare Work Order Authorization (WOA), get required signatures and FAX to OSC Accounting Services — Project Support Service Section (PSS) prior to noon of the first working day after the number is assigned.
OSC Accounting Office, Project Support Services Section	Set up the work order in TRAINS.  Send a copy of approved work order to OSC Maintenance.
OSC Program Management	Send a copy of approved work order to OSC Program Management.  Send the project to FHWA for obligation/ authorization (Form 120-006).  Send a copy of the approved form to Region Program Management and the Maintenance Analyst.
Region	Ensure that charges are made to the appropriate group depending on the eligibility of the charges and the time frame in which they were incurred.
OSC Accounting Office, Project Support Services Section	Upon notification that federal funds have been approved, set up the federal funds on federal eligible groups per the federal agreement.  Transfer the eligible expenditures which have accumulated from the state appropriation to the federal appropriation.  Forward a copy of the journal voucher transferring the expenditures to the Region Accounting Office.

In order to minimize confusion, the following groups will be reserved for state force work:

- Group 01 — Emergency and Incidental Permanent Work within 180 days
- Group 02 — Emergency and Incidental Permanent Work after 180 days
- Group 03 — Permanent Work
- Group 04 — Non-Participating Work

It is **essential** that the group title be used with each group so that the appropriate expenditures can be moved if federal participation is received.

At the time of the initial DM set up, PSS will set up only the groups which have been requested by the region.

The groups on DM Work Orders are not limited to Group Category 04. As long as all other requirements have been met, other group categories may be used. For example, it is permissible to set up groups which are in Group Category 01 (Work Done Contract) or Group Category 02 (Work Done agreement). Other groups can be added later (by E-Mail) as long as the authorized dollars are not being increased.

Payments for Emergency and Incidental Permanent Work done after 180 days **must** be charged to the appropriate group. The key is when the work is done or goods received, not when the bill was paid. (If work was actually done **within** the 180 days it remains in Group 01 even though the bills may be paid **AFTER** the 180 day limit.) The 180 days is measured from the declared **first day** of the emergency, which may be prior to the date that the damage occurred.

### **Assignment of DM Work Order Numbers**

Each region will assign their own DM Work Order numbers. The first two characters of the work order number will be DM (Disaster Maintenance) to indicate the type of work order. The third character of the work order will be used to define the region (DMAxxx for the Northwest Region, DMBxxx for the North Central Region, DMCxxx for the Olympic Region, DMDxxx for the Southwest Region, DMExxx for the South Central Region, DMGxxx for the Eastern Region). The next three characters are numeric and will be assigned sequentially by the region. The block of DM numbers will **not** be further subdivided.

In order to expedite work order set up, minimize confusion, and ensure that regions, OSC Maintenance, OSC Program Management, and OSC Accounting each has the information they need, the following rules will be observed.

1. Responsibility for assigning DM numbers will be assigned to an individual.
2. The individual (or designee) responsible for assigning DM numbers will be available to assign numbers whenever they are needed.
3. The individual responsible for assigning DM numbers will prepare the Work Order Authorizations for the DM Work Orders, acquire required signatures, and fax them to OSC Accounting Services, PSS Section prior to noon of the first working day following the assignment of the number.
4. DM numbers will not be reserved for potential work but only set up for actual projects.
5. Each region will maintain a log of DM numbers which carries the data elements that they require plus any other elements which may have been requested by OSC Maintenance, Program Management, and Accounting.

### **Work Order Authorization Form**

A sample Work Order Authorization (WOA) form, 120-021 EF is included in Appendix. This form is available in electronic format. For consistency and to speed processing of work orders within OSC, we are requesting that all regions submit work order authorizations on this version of the form. It is not required that each region use the electronic format, only that the work order have the same information in the same format as the sample provided.

When preparing a WOA request, whether it is for a new setup or an adjustment to an existing setup, complete, accurate information must be provided.

It is important for federal emergency work that the region monitor the work order closely and at the end of the 180 time limit, when appropriate, switch from the Group for Emergency Work and/or incidental Permanent Work within 180 days to the Group for Emergency Work after 180 days.

### **Review by Region Prior to Submitting WOA**

To aid processing within OSC, to reduce processing time and to minimize the number of errors, the regions need to completely and accurately fill in the areas identified on the sample WOA.

Prior to submitting an increase for a work order authorization to OSC an effort should be made to check TRAINS to ensure that all GROUP CATEGORIES will have sufficient authorization after the WOA is processed.

If a group is going to be set up on the work order which references a payable agreement, the agreement needs to be complete, through the OSC review process and ready for set up in TRAINS prior to submittal of the work order authorization to OSC Accounting. If the agreement is not completed prior to the WOA being submitted for approval, the group set up will be delayed until the reviewed agreement is received in OSC Accounting.

Work order authorization for a federal Aid Emergency Relief (ER) project containing **Permanent Work** must have the environmental documentation complete, the Right of Way certified and the design completed prior to receiving federal approval (this includes state force construction). When submitting a WOA for construction please include, along with the request, a copy of the estimate, design approval date (if applicable), the RW certification and the NEPA dates indicating the environmental classification of the project, (NEPA, CE, EA, EIS, etc.). Failure to have any of these items complete prior to submitting the funding request FHWA will result in delays of the funding approval and may delay the start of the project.

### **When to Submit a Work Order Authorization Increase**

The Work Order Manager should periodically check the status of the work order. If TRAINS shows a WO is overrun, or it will soon overrun, and work is ongoing, a WO increase should be prepared and submitted to OSC. The increase should provide adequate funds to cover the overrun and estimated future expenditures. The

estimate should be reasonable and should be based on the best information available at the time. Significant increases/decreases to existing work orders need to be submitted prior to overrunning the WO whenever possible.

When reducing existing work orders prior to closure, consideration must be given to estimating expenditures that will occur prior to the work order actually closing. Submitting a request to reduce a work order to actual expenditures when the groups are still open will almost always result in the work order overrunning or the actual expenditures changing prior to the work order being processed through OSC.

### **Examples of Emergency Maintenance Work Orders**

Parameters for this type of work activity are flexible to the extent that they are required to meet only one criteria, i.e., the cost of the activity described under the DM work order setup must be at least \$5,000 to meet FHWA eligibility requirements.

Parameters for a DM work order will be that they may be identified by Maintenance Section, Sign Route (in its entirety) or specific locations, so long as the type of activity being performed is functionally related or continuous in nature. Given these parameters, the following examples can be used by field personnel in reviewing and setting up Emergency Maintenance DM work orders:

#### **Example 1:**

High winds caused extensive damage to trees and signs along an entire maintenance area/sign route; in this case one DM work order may be used for the entire section. A similar example would be damage to signals in several locations where the work would be accomplished by the region-wide signal crew.

#### **Example 2:**

Bridge scouring and related erosion occurred at MP 79-Mill Cr. Br., MP 89-Twin Canyon Br., MP 108-Rainey Cr. Br., MP 116-Silver Cr. Br., and MP 123-Cora Br. In this example there are three options. Bridge scouring and related erosion may be considered one project since the work is similar in nature and repairs will be accomplished by one organization — the regions' Bridge Crew — and can all be placed on one work order. The second option is for the region to establish an individual work order for each location. This is desirable if there is a need to track the individual bridge repair costs. Or third, separate groups can be set up for each bridge on one work order.

In instances where repair activities on a single sign route are diverse in nature and/or widely separated in terms of miles of roadway field personnel may set up individual work orders (or they could be set up on one WO with a separate group for each type of work) for example:

#### **Example 3:**

SR 12, MP 71 to 75 slide clean up, ditch cleaning, culvert cleaning, and traffic control might be one work order.

**Example 4:**

SR 12, MP 143 to 148, roadway settlements in several locations may be a separate work order for the emergency/incidental permanent work performed by maintenance state forces.

**Example 5:**

SR 12, MP 154.5, loss of roadway. A DM work order would be set up to cover only the traffic control and emergency incidental/permanent work, with any permanent work to be handled either through the emergency bidding authority or as an unprogrammed project under the Preservation Program under a separate work order.

**Example 6:**

SR 12, MP 143 to 148 has emergency/incidental permanent work. Within that section at MP 145 to 146 there is a section of lost roadway that will require permanent work by contract using the unprogrammed project process. When setting up work orders, one work order is set up for the emergency/incidental work for the whole section while another would be set up to capture the permanent work for that part of the section.

5:P:DP/EPM

# ***Emergency/Incidental Permanent/ Permanent Work***

---

## **Introduction**

Emergency work is that work done during or immediately following a disaster to restore essential traffic, to minimize the extent of the damage, or to protect the remaining facilities.

Emergency Relief work (including emergency work, incidental permanent work, and permanent work) at a site is eligible for ER funds if the damage was caused by the event and the cost of the work exceeds \$5,000/site. Since debris removal costs may be widespread rather than site-specific, FHWA will determine if the costs exceed heavy maintenance.

The Detailed Damage Inspection Report (DDIR), WSDOT Form 300-001EF, Appendix 3, and its approval is used to document the scope and eligibility of the work. Normally the Region Maintenance Analyst is responsible for preparing the DDIR along with FHWA. The DDIR must be prepared (normally by the region) and reviewed for eligibility by FHWA within 90 days after the ER event is approved by the FHWA Administrator. The DDIR divides the work on the project into three categories "Emergency, Incidental Permanent, and Permanent" work. The following is a further definition of these three categories.

## ***Emergency Work***

The intent of temporary operations, including emergency work, is to restore essential traffic which cannot wait for a finding of eligibility and programming of a project. Emergency work should be accomplished in a manner which will reduce additional work required for permanent work. The department will need to coordinate with resource agencies for permit requirements.

Emergency work may be eligible for 100 percent federal aid as long as the work is within the first 180 days after the emergency begins. The 180 days is calculated from the first date of the incident as determined with FHWA. The 180-day ending date will be shown on the FHWA Form 120-006.

The use of Emergency Relief (ER) funds for emergency work on roadways will normally be limited to the amount necessary to bring the washed-out fills and slip-outs back to grade with a gravel surface. In most cases the emergency work will not construct the roadway to a true line and grade but rather follow the terrain and be constructed in the easiest and fastest manner. Work on the roadway, nevertheless, should be adequate so that traffic can travel over it safely at a speed reasonable for the site conditions. Where routes handle heavy traffic, an appropriate type of bituminous surface as a emergency work will be eligible for short sections of roadway.

## ***Incidental Permanent Work***

FHWA's concurrence in the need for repair does not in itself authorize the agency to proceed with permanent restoration work on damaged roadways. However, there may be situations in which immediate completion of the permanent restoration portion of the work is the most economical and feasible way to quickly restore

essential traffic. In these situations the permanent restoration work is considered to be incidental permanent restoration work and can be performed with the emergency work, provided it is properly documented in the DDIR. If such work has been accomplished prior to the site damage review, retroactive approval may be given when circumstances warrant.

### **Documentation of this Determination is Essential**

#### **Example 1**

An example would be a bridge and approaches being washed out, construction of a detour being both costly and time consuming, and the agency having precast concrete girders readily available that could be used at the site. In such a case, immediate construction of the permanent structure and approaches could be accomplished at the discretion of the agency and FHWA would consider the work to be incidental permanent restoration and would be documented and reimbursed in the same way as the emergency work.

#### **Example 2**

The placement of the final surfacing is normally considered to be permanent work. But, it may be considered incidental permanent restoration work in some cases. Such paving must have FHWA concurrence, on the DDIR or subsequent to the DDIR, to be eligible for federal participation. FHWA will consider traffic characteristics, remoteness of the site, traffic control requirements and socioeconomic factors before approval.

### **Permanent Work**

Permanent repairs are those repairs undertaken, normally after emergency work has been completed, to restore the highway to pre-disaster conditions. Permanent repairs require a separate FHWA Form 120-006 **before** starting construction or going to bid if the work is contracted out. Any work performed prior to approval and authorization of the 120-006 **is not** eligible for federal reimbursement. (This is in addition to the 120-006 form required for the emergency or incidental permanent work.)

A work order authorization for “**Permanent Work**” needs to be submitted to OSC at least **three weeks** ahead of the planned start date to allow adequate time for processing in OSC (Program Management and Accounting) and with FHWA.

Permanent restoration is funded at the normal match rate for the route **regardless of when the work is done**. Permanent restoration shall be administered using normal federal-aid procedures that include written authorization, NEPA clearance, design approval, permits, right of way certification, PS&E, advertisement period, etc. Permanent restoration work must begin within two years after the event.

Permanent restoration may involve one or more of the following categories of work:

1. *Restoration-in-Kind*. The ER program provides for repair and restoration of highway facilities to predisaster conditions. Restoration-in-kind is the expected predominant type of repair to be accomplished with ER funds. Any additional features or changes in character from that of the predisaster facility are



considered to be betterments and are generally not eligible for ER funding unless they can be justified because of construction, economy, prevention of future recurring damage, or technical feasibility.

2. *Replacement Facilities.* Where a facility has been damaged to the extent that restoration to its predisaster condition is not technically or economically feasible, a replacement facility is appropriate. Replacement facilities should be constructed to current design standards. ER participation in a replacement roadway will be limited to the costs of current design standards of comparable capacity (i.e., number of lanes), and character (i.e., surfacing type, access control, rural/urban section). Replacement of a bridge will be the cost of a new bridge to current design standards for the type and volume of traffic it will carry during its design life.

ER participation may be prorated at the costs of a comparable facility when the proposed replacement project exceeds the capacity and character of the destroyed facility.

3. *Betterments.* A betterment is defined as any additional feature, upgrading or change in capacity, or character of the facility from its predisaster condition. Betterments are generally not eligible for ER funding unless justified on the basis of economy, suitability and engineering feasibility, and reasonable assurance of preventing future similar damage. Betterments should be obvious and quickly justified without extensive public hearing, environmental, historical, right-of-way or other encumbrances. The justification must weigh the costs of the betterment against the probability of future recurring eligible damage and repair costs.

Upgrading that results from construction of replacement facilities to current standards as defined above is not considered a betterment requiring further justification. However, with respect to roadways, increases in capacity or a change in character of the facility would be considered betterments and are not justified for ER participation.

Betterments which have been approved in the past with proper justification include:

- Installation of riprap
- Installation of hydraulic enhancements
- Relocation
- Increased waterway opening
- Slope/bank stabilization
- Slide stabilization
- Dike construction
- Raise grade of roadway

Betterments resulting from environmental or permit requirements beyond the control of the agency are eligible for ER funds, if these betterments are normally required when the agency makes repairs of a similar nature in its own work.

Minor relocations and alignment shifts are frequently advisable and are generally eligible for ER participation. However, any design changes made to avoid damage which could be expected to occur infrequently is questionable. Added features of appropriate protection, such as slope stabilization, slope protection, and slide prevention measures wherever practicable, must have proper support. Slide stabilization work has been declared ineligible in problem areas where slides recur regularly. The cost of monitoring slide stabilization measures after completion of the initial stabilization is not eligible. ER participation in the initial construction does not create a continuing ER responsibility for future additional work.

Betterments which are eligible for reimbursement will be addressed, agreed to and documented on the DDIR or approved separately by WSDOT and FHWA in response to a local agency request justifying the proposed betterment.

4. *Replacement-in-Kind.* Where extensive damage has occurred, ER funds may be used for replacement-in-kind as the proper solution but with current standard safety features. Where relocation is necessary, each case is considered carefully to determine what part of the relocation is justified for construction with ER funds.
5. *Wayside Areas.* Wayside areas include rest areas and truck weighing stations. Access and parking facilities at a wayside area can be cleared and protected as part of an ER project. Local agency and WSDOT maintenance facilities are not included.
6. *Replacement of Culverts.* Upgrading culverts to current standards must be specifically related to eligible disaster damage repair. Damaged culverts are eligible for repair in kind. Destroyed culverts are eligible for replacement to current standards. Area-wide upgrading of deficient culverts on an area or route basis is not eligible.
7. *Deficient Bridges.* This includes bridges unsafe in structural condition only and does not consider waterway opening, functional obsolescence or serviceability. A structurally deficient bridge which was not under construction or scheduled for replacement with other federal funds may be eligible. ER funds do not replace other federal funds nor will they fund permanent repairs if the bridge is scheduled for replacement. The following represent two common situations:
  - a. Bridge is damaged and is repairable. ER funds may participate in:
    - (1) Reasonable emergency work to restore travel.
    - (2) Repair of disaster damage to restore a bridge to a structurally safe condition
    - (3) Repair of disaster damage if other funds are used to simultaneously correct the structural deficiencies (ER funds cannot be used to correct structural deficiencies).
  - b. Bridge is destroyed or repair is not feasible. ER funds may participate in:
    - (1) Reasonable emergency work to restore traffic.
    - (2) New comparable replacement structure to current standards if bridge was not scheduled for replacement.

8. *Bridge Betterments.* Two common bridge betterment situations are:
- a. Bridge is destroyed. A new comparable replacement structure would be eligible. Betterments are generally not a consideration except:
    - (1) Extensive relocation of a replacement bridge is an ineligible betterment and ER participation will normally be limited to the cost of the structure and a reasonable approach length.
    - (2) Replacement of a current non navigable structure or movable bridge with a high level navigable structure is beyond the intent of a comparable facility and is an ineligible betterment.
  - b. Bridge is seriously damaged, but repair is feasible. Repair-in-kind is eligible for ER funds.

Added protection features such as riprap, spur dikes or additional channel work if justified as a betterment would be eligible (i.e., there is reasonable assurance that similar future damage would be prevented and the cost of the betterment does not unreasonably exceed anticipated future ER costs).

9. *Control Features.* Stream channels outside the agency's right-of-way are generally not eligible. Work involved in channel changes, hydraulic enhancements, riprap, bank protection, clearance of debris and wreckage from the channels and stream beds, and other associated permanent work is not eligible. However, if the agency can establish it has jurisdiction and responsibility for the maintenance and proper operation of this section of the stream the work may be eligible. Normally, projects associated with channel work (riprap, bank protection, etc.) that require right-of-way purchases and/or easements outside the right-of-way are not eligible. The fact the agency responsible for channel maintenance does not have funds to finance the repair and protection work, is not an acceptable reason for ER fund assistance. In situations involving requests for participation in erosion control and bank protection outside the agency right-of-way, the following items must be verified by the agency to obtain eligibility:

- The work is directly related to protection of the highway facility.
- The work is not eligible for funds from another agency.
- No other agency has the responsibility for such work.
- The applicant agrees to accept the future maintenance of all work performed.

When work of this type is proposed, the project documents should include a letter from the local agency covering all four of the above features including acceptance of the responsibility for maintenance. Other supporting data should include copies of correspondence with the Corps of Engineers or other appropriate agency to verify that no other eligibility or responsibility exists.

- Increased bridge width or other geometric improvements and correction of non disaster-related structural or surfacing improvements such as deteriorated pilings or decks are not eligible.

10. *Protective Work.* When permanent and emergency work cost considerably less than proposed protective measures such as riprap, eligibility of protective measures is questionable. For example, if repairs consisting of replacement-in-kind cost only \$5,500 and the estimated cost to provide sufficient protection to prevent damage under similar unusual conditions is \$9,000, participation beyond that necessary for replacement-in-kind would not be economically justified.
11. *“Convenient” Damage.* To eliminate a recurring annual maintenance problem based on the occurrence of a disaster is questionable. For instance, the department proposes to replace a damaged triple box culvert and roadway fill with a bridge. This is a betterment to alleviate an annual maintenance problem which was accelerated by a disaster. ER participation in the construction cost of a bridge is limited to the amount necessary to restore the triple box culvert.
12. *Rock and Mud Slides.* The removal of rock and mud slides is eligible unless determined to be a pre-existing condition. Such a slide, unless justified on their own as a catastrophic failure, must be associated with the overall natural disaster and must have occurred during the event period as determined by FHWA and/or FEMA.  
  
When an old slide has been activated during a natural disaster, its correction to provide a safe roadway is eligible. Should the agency propose to relocate a road instead of correcting the old slide, the cost of the relocation to predisaster capacity and character may be eligible if justified as a betterment.  
  
Slide stabilization is also a betterment. ER participation must be based on detailed analysis of the slide and reasonable assurance of preventing similar future damage, showing stabilization costs do not unreasonably exceed anticipated ER costs. Such analysis must include road relocation, do-nothing alternatives and consideration of previous testing recommendations for the area.
13. *Plugged Culverts.* Cleaning out plugged culverts is an eligible activity as long as it is considered beyond heavy maintenance and is associated with other eligible damage. Replacement of plugged culverts should be considered eligible only when justified as a betterment or when cleaning is not cost effective.

### **Additional Examples of Emergency/Incidental Permanent/Permanent Work**

#### **Example 1**

- a. The fill section of a road failed, leaving a two-lane road impassable. WSDOT Maintenance Crew blocked traffic and proceeded to bring in fill material. Once the material was in place, the crew opened the road to traffic on gravel. At this point essential traffic had been restored, therefore the emergency work was complete. Paving the surface was accomplished a month later due to other reasons. Therefore, the paving and striping is considered permanent work. The emergency work would be eligible for 100 percent ER and the permanent work would be eligible for the standard pro-rata share for that highway.
- b. Same example, except, the paving is immediately accomplished. Since the crew had most of the equipment already at the site while doing the fill work, it was decided that it would be more cost effective to complete the project while doing the emergency work. Because it was more cost effective to complete

along with the emergency work, this permanent restoration would then be considered incidental permanent and funded at 100 percent level by FHWA. In this example the emergency work and incidental permanent restoration would both qualify for 100 percent ER funds.

**Example 2**

- a. A bridge washed out making the highway impassable. A temporary bridge was constructed until the main bridge was replaced. The temporary structure restores essential traffic and is therefore eligible for 100 percent ER funding. The replacement of the bridge would be permanent restoration eligible for the standard pro-rata share for that highway.
- b. Same example, except due to the location, no temporary detour can be constructed, therefore, the bridge replacement becomes incidental permanent replacement and if accomplished within 180 days is eligible for 100 percent ER funding because it is required to restore essential traffic.
- c. Same example, a detour is constructed, the old bridge is removed, and a year later a new bridge is constructed and detour is removed. The detour construction would be emergency work at 100 percent ER funding, since it serves to restore essential traffic and prevent damage to the remaining facility. The removal of the old bridge, construction of the new bridge, and the detour removal would be permanent restoration eligible for reimbursement at the prorata share.

**Example 3**

- a. A large slide covered the highway making it impassable and due to the threat of continued activity, the department made the decision for safety reasons not to allow any work on the slide. The department constructed a detour around the slide. This detour is emergency work required to restore essential traffic and is eligible for 100 percent ER funding. The removal of the slide material is considered permanent restoration and is eligible for the standard pro-rata share for that highway.
- b. Same example, except the department has determined that the slide material is too expensive to remove and due to the size of the slide would not be a safe work environment, therefore, the decision was made to make the detour alignment a permanent structure. Since the detour is required to restore essential traffic, it would be considered emergency work/incidental permanent restoration and would be eligible for 100 percent ER funding, if completed within the first 180 days.

**Example 4**

- a. A section of roadway sinks. Maintenance fills up the hole, and opens the road to traffic. A short time later roadway sinks again, requiring the same fix. The roadway sinks a third time a little later requiring the same fix. Finally, the roadway stabilizes. Because all of the work described was required to restore essential traffic and preserve the existing roadway, all of the work would be 100 percent federal funding emergency work, if completed within the first 180 days.

6:P:DP/EPM



## Purpose and Scope

To provide guidance in contracting out emergency work in accordance with the applicable statutory laws and in the administration of the resulting contract.

## Rules

**If an outside contractor is to perform work during a declared emergency, the rules set forth below apply regardless of whether the work is considered a maintenance activity, construction activity, or a combination of both.**

1. Regardless of the estimated dollar amount of the contract, the contractor must be prequalified. If the estimate is \$50,000 or less, D-27 60 may be used to expedite the qualification process.
2. If the work involves the emergency protection and restoration of highways, RCW 47.28.170 allows alternative contracting methods regardless of the size of the contract. The department may solicit written bids (at least three bids) for the work without publishing a call for bids and then award the contract to the lowest responsible bidder.

The department may also contract without bids for emergency work under the same statute for a period not to exceed 30 working days. The price of the work would be negotiated but could not exceed the cost of doing the work by force account. The 30-day time frame cannot be extended. However, at the end of the 30-day period, the department may have the remaining emergency work done by obtaining at least three written bids and awarding the contract work to the lowest responsible bidder.

3. If the emergency contract work will not exceed \$50,000, the department need not require a bid deposit nor a performance bond. If a performance bond is not required, however, progress payments to the contractor may, at the discretion of the Region Administrator, be conditioned on submittal of paid invoices to substantiate proof that disbursements have been made to laborers, materialmen, mechanics, and subcontractors from the previous partial payment. If the contract will exceed \$50,000, a performance bond is required.
4. RCW 60.28.011 requires that 5 percent of the moneys earned by the Contractor be withheld by the public agency as a trust fund for the protection and payment of (a) the claims of any person arising under the contract and (b) state taxes which may be due from the Contractor. This requirement applies to all public improvements or work, other than for professional services. If the Department does not properly withhold the money, or if the money is refunded to the Contractor without the appropriate clearances from Claimants, the Department will be obligated to pay legitimate claims and/or taxes up to 5 percent of the contract amount as a substitute for the retainage fund. This obligation cannot be avoided, however, where the cost of withholding the money exceeds the amount withheld, it may be a prudent business decision to accept the risk of the obligation.

## Contracting

5. Since the work is being contracted out, the department must follow all rules regarding the payment of prevailing wages. In addition, if federal reimbursement will be sought for the project, it will be necessary to include the required federal aid contract provisions.
6. Regardless of the dollar amount of the work, the department shall prepare a written contract setting forth the terms, conditions, and responsibilities of the contractor, including reference to the applicable *Standard Specifications*. A contract form is attached for this purpose.

## Contracting Procedures

Once the decision is made to enter a contract with an outside entity:

1. Prequalification (Required in all cases)
  - a. Less than \$50,000?      Use Abbreviated Process (Form DOT 272-063)
  - b. More than \$50,000?      Use a firm already prequalified or call Pre-contract
2. Wages
  - a. No federal dollars involved?      State Wage Laws Apply  
Statement of Intent and Affidavit of Wages Paid
  - b. Federal dollars involved?      Davis-Bacon Act applies  
Required Federal Aid Provisions  
Payrolls and Interviews Required  
Statement of Intent and Affidavit of Wages Paid  
Exception for Owner-Operators
3. Bond
  - a. Under \$50,000?      Not required (Consider Invoice Verification)
  - b. Over \$50,000?      Performance Bond is required
4. Retainage
  - a. Always required
  - b. Pay taxes and claims/verify and release
  - c. Obligation if not retained
  - d. Could require a bond in lieu of retainage
5. Written Contract is Required
6. Type of Contract
  - a. Negotiated, single contractor, no bids
    - (1) Can't exceed 30 working days      (2) Getting close? What to do.



- b. Solicited Bids
  - (1) Three required
  - (2) Needs bid documents — description of work and quantities
- c. Conventional Published Call for Bids
  - (1) Plan preparation
  - (2) Review process
  - (3) Policy inclusions? Training? Disadvantaged Business?

### **Contract Administration Procedures**

#### **1. Layout**

The responsibility for layout (defining the work on the ground — surveying, staking, etc.) of the work is the state's, unless the contract provisions say otherwise.

#### **2. Materials**

If standard items are used, they must meet the *Standard Specifications* requirements and they must be sampled and tested as required by the *Construction Manual*. Regions may insert special provisions that call out other specs. These should be approved by Roadway (after-the-fact approvals are possible, but there is a risk).

#### **3. Inspection**

A state employee must either be present, or must be able to see the work done since the last visit.

#### **4. Payment**

Using Contract Administration and Payment System (CAPS), estimates are prepared. If CAPS is not used, payments may be made by voucher. If the work is being funded under the construction programs, CAPS and Construction Contract Information System (CCIS) must be used. The use of CAPS leads to the assignment of a “00” contract number. CCIS entries are needed and are made by the region.

#### **5. Subcontracting**

Subs can do up to 70 percent of the work. Subs must be approved by the state and must follow all of the same requirements as the Prime Contractor.

#### **6. Retainage**

Retainage is done automatically by CAPS and all reviews, clearances, and claims are automatically tracked by CAPS. If the work is being paid by voucher, the originating office will need to withhold 5 percent and, at the end of the job, ascertain that taxes and claims have been satisfied before releasing

the funds. If retainage is not withheld, WSDOT would be responsible for claims and taxes up to 5 percent of the amount paid. This might be a risk worth taking when the cost of retaining exceeds the amount retained.

7. Wages

On all jobs, the Prime and all subs must submit a Statement of Intent to Pay Prevailing Wages, obtained from Labor and Industries, and provide an Affidavit of Wages Paid at completion. On federal-funded jobs, the state must collect certified payrolls from the Prime and all subs. The state must also conduct field interviews of employees to confirm the amounts shown on the payrolls.

8. Changes

Any changes to the work must be in writing and must be approved by the Region Representative, the Region Construction Engineer, or the OSC Construction Office, depending on the nature of the change (see the *Construction Manual* for guidance).

9. Closure

The region is responsible for determining the final payment amount, preparing final records, and as-built plans.

## Project Closure

Once the work is complete, and if the project is federally funded, two separate actions must take place.

1. All work orders associated with the federal aid project must be closed.
2. The federal aid project must be closed. This requires the region to prepare the following form and submit it to OSC Project Support Services with a copy to OSC Program Management and FHWA.

The closure and the form to be used depends on which program the project is in.

1. **Projects in M2** — Closure of “DM” projects by Maintenance Administration — Form 422-100A
2. **Projects in the Highway Construction Program** — Closure of “00” and “MS” projects by Construction Administration — Form 422-100EF

When required, a Final Acceptance Form is prepared by OSC Construction Office and submitted to OSC Project Support Services with a copy to OSC Program Management and FHWA. **Ninety days after final acceptance of the project by the Assistant Secretary for Field Operations, the OSC Accounting Services Office will change all construction work orders to state funds and the federal project will be closed.**

7:P:DP/EPM

## ***Betterments Per FHWA Memorandum***

---

The ER program is intended to assist the states in repairing damaged highway facilities to their predisaster condition. In-kind restoration is the predominate type of repair. However, on occasion, a state may decide to incorporate additional features into the repair work that help protect the highway facility from future disaster damage, or to make changes that modify the function or character of a highway facility from what existed prior to the disaster. These added protective features or changes to the function or character of the facility are viewed as betterments for the purposes of the ER program. Betterments involving added protective features are not eligible for ER funding unless found to be cost-effective in terms of reducing probable future recurring repair costs to the ER program. Betterments that change the function or character of the facility are generally not eligible for ER funding.

***The first category of betterments includes those that help protect highway facilities from possible future damage.***

***Examples are:***

- Raising roadway grades,
- Relocating roadways to higher ground or away from slide prone areas,
- Stabilizing slide areas,
- Stabilizing slopes,
- Installing riprap,
- Lengthening or raising bridges to increase waterway openings,
- Deepening channels,
- Increasing the size or number of drainage structures,
- Replacing culverts with bridges,
- Installing seismic retrofits on bridges,
- Adding scour protection at bridges, and
- Adding spur dikes.

If a betterment involving an added protective feature is included in an ER repair project, the betterment may be considered eligible for ER funding under 23 CFR 668.109(b)(6) if it can be economically justified based on an analysis of the cost of the betterment versus projected savings in costs to the ER program should future disasters occur. This cost/benefit analysis must focus solely on benefits resulting from estimated savings in future recurring repair costs under the ER program. The analysis **cannot** include other factors typically included in highway benefit/cost evaluations, such as traffic delays costs, added user costs, motorist safety, economic impacts, etc.

It is recognized that in many instances betterments will fail to meet the test of being economically justified for use of ER funding. If ER funding cannot be provided for a betterment, this does not mean that the betterment should necessarily be excluded from the ER repair project. If a betterment provides considerable benefit when other factors are considered, the state is encouraged to use regular apportioned federal-aid highway funds, as appropriate, to fund a betterment.

One exception to the above discussion on betterments associated with added protective features involves grade raises associated with basin flooding. The FHWA has determined that raising the grades of critical federal-aid highways faced with long-term loss of use due to basin flooding is eligible for ER funding (see 23 CFR 668.109(b)(8)). In these instances, if the FHWA Administrator finds that a basin flooding event is eligible for ER funding, reasonable grade raises require no further economic justification as betterments.

Another exception involves repairs of features, such as bridges, that may require permits or approvals from other entities. If these other entities are routinely requiring added features as standard industry practice on other projects of similar nature to the ER project, then these added features can be included on the ER project without further justification as a betterment.

***The second category of betterments includes changes to the function or character of the facility.***

***Examples are:***

- Adding lanes,
- Upgrading surfaces, such as from gravel to paved,
- Improving access control,
- Adding grade separations, and
- Changing from rural to urban cross-section.

In general, betterments that change the function or character of a facility are not eligible for ER funding. One exception is established under 23 U.S.C. 120(e) that allows ER funding participation in replacement bridge facilities that can accommodate traffic volumes over the design life of the bridge, thus potentially allowing ER funding for added lanes on bridges.

***Examples:***

Situations where use of ER funding for repair activities is **not** considered a betterment are:

- Replacement of older features or facilities with new ones — the mere fact that a damaged highway feature or facility is replaced with something new that may extend the service life of the facility, in and of itself is **not** a betterment.

Incorporation of current design standards — repaired facilities may be built to current design standards, which could result in improved or added features that do not change the function or character of the facility. For example, a repaired length of roadway may have wider lanes or shoulders and additional roadside safety hardware that result from following current design standards. This is **not** a betterment.

Replacement in-kind on existing location not practical or feasible — on rare occasions, when it is neither practical nor feasible to replace a damaged highway facility in-kind on its existing location, an alternative selected through the environmental/public involvement process, if of comparable function and character to the destroyed facility, is eligible for ER funding. This is **not** a betterment. (See the following discussion on replacement facilities for more information on this special situation.)

Additional required features resulting from the environmental process — ER projects may include additional required features as an outcome of the project being developed in accordance with the NEPA process. These features are eligible for ER funding. This is **not** a betterment. (See the following discussion on environmental considerations for more information.)

8:P:DP/EPM



## ***Replacement Facilities***

---

A state may decide to replace a damaged highway facility with a new replacement facility. The extent of ER participation varies depending on the circumstances involved. Various scenarios, with examples, are discussed below.

In the first scenario, a highway facility has been seriously damaged; however, inspection verifies that it is possible to repair and restore the existing facility. Although the facility is repairable, the state decides it wants to replace the existing facility with a new or alternative facility. In this case, ER funding can be applied towards a new or alternative replacement facility; however, ER funding is limited to the ER program share of the estimated cost to repair the existing facility. Regular apportioned federal-aid highway funds may be used to fund project costs above the amount eligible for ER funding.

### **Example 1:**

An elevated structure serving as a portion of a non-Interstate route in an urban area, although seriously damaged by an earthquake, does not collapse. It is determined the structure is repairable at an estimated cost of \$50 million. The state does not want to repair the elevated structure, but instead wants to replace it with an alternate facility at-grade or depressed. If the alternate facility provides comparable traffic service and will accommodate the known corridor traffic demands of the predisaster facility, then ER funds may participate in the federal share of the replacement facility up to an amount of \$40 million in ER funds (\$50 million estimated cost of repair multiplied by the 80 percent federal share for non-Interstate ER repair work). This is commonly referred to as capping the amount of eligible ER funds.

In a second scenario, a highway facility has been seriously damaged and inspection confirms that it is not repairable. The state decides it wants to replace the existing facility with an in-kind replacement facility (of comparable function and character to the damaged facility) on the existing location. In this case, ER funding may participate in the total cost of the replacement facility.

### **Example 2:**

A bridge on a non-Interstate route crossing a river is heavily damaged and collapses during flooding. It is determined the bridge cannot be repaired, but must be replaced. The state decides to replace the bridge at the existing site and the replacement structure costs \$5 million to build. Emergency relief funding may participate in 80 percent of the incurred costs, which in this example amount to \$4 million.

In a third scenario, a highway facility has been seriously damaged and inspection confirms that it is not repairable. Although it is feasible to build a replacement facility at the location of the existing facility, the state chooses to replace the existing facility with an in-kind replacement on a new location. In this case, ER funding for the replacement facility is limited (capped) to the ER program share of the estimated cost to replace the facility in-kind at its existing location. Regular apportioned federal-aid highway funds may be used to fund project costs above the amount eligible for ER funding.

**Example 3:**

In the same example used in the second scenario above, instead of replacing the bridge at the existing site, the state chooses to replace the bridge at a new site a half mile downstream, using this as an opportunity to improve the overall alignment of this section of roadway. Because of stream characteristics at the new downstream bridge site, a longer structure is required. Also, the new site requires a mile of additional approach work. The result is that a bridge at the new site costs an additional \$2 million (to a total of \$7 million) above the estimated cost to replace the bridge at the existing site. For this \$7 million project, ER funding may participate in the federal share of costs up to an amount of \$4 million (\$5 million estimated cost of replacement at the existing site multiplied by the 80 percent federal share for non-Interstate ER repair work).

In a fourth scenario, a highway facility has been seriously damaged and inspection confirms that it is not repairable. Additionally, because of the very unique circumstances involved, it is also determined that it is neither practical nor feasible to replace the facility in-kind at its existing location. Consequently, an alternative replacement facility is developed through the NEPA process that is on new location. Provided this alternative is of comparable function and character to the destroyed facility, it is eligible for ER funding. It is noted this scenario rarely arises under the ER program. In almost all cases, it is practical or feasible to replace a damaged facility in-kind on its existing location, and the determination that the facility must be built on a new location is intended to be an extremely stringent test.

**Example 4:**

A rural non-Interstate highway, located in a valley area, is blocked by a massive landslide that also dams up a river in the valley. The landslide forms an earthen dam, backing up the river and forming a lake. Two miles of roadway are submerged under a significant depth of water. A decision is made by authorities that the landslide formed dam will remain in place along with the lake it has created. It is determined it is neither practical nor feasible to replace the highway at the existing location. As a result, the highway must be relocated and the appropriate replacement facility, developed through the environmental/public involvement process, becomes a relocated facility, 4 miles in length, bypassing the submerged section of roadway. The relocated facility costs \$20 million to build and ER funding may participate in 80 percent (\$16 million) of this total cost.

9:P:DP/EPM



## ***Environmental Considerations***

---

Repair projects under the ER program must comply with NEPA requirements. Emergency repairs restoring essential travel, minimizing the extent of damage, or protecting remaining facilities have been classified as categorical exclusions under 23 CFR 771.117. Likewise, ER projects that involve permanent repair work to restore the existing facility in-kind at the existing location are likely to be viewed as categorical exclusions.

For ER projects that include betterments, even if the betterments are not eligible for ER funding, careful environmental review is needed. Although on the surface it may appear that a project qualifies as a categorical exclusion, certain betterments may be of enough significance that an environmental assessment or environmental impact statement is appropriate. For ER projects that involve constructing replacement facilities, environmental assessments or environmental impact statements may be required, particularly where a replacement facility on new location is being proposed.

As a result of an ER project being developed in accordance with the NEPA process, it may be necessary for the project to incorporate added features to mitigate impacts associated with items such as wetlands, noise, endangered species, etc.

In the case of an ER project incorporating such added features, if these added features are associated with a betterment determined eligible for ER funding, in turn the added features are also eligible for ER funding. If the added features are associated with betterments not eligible for ER funding, funds other than ER funding are to be used to construct the added features.

In the case of ER replacements projects, where ER funding may fully participate in the replacement facility (the second and fourth scenarios described above), any required added features are eligible for ER funding. These are not viewed as betterments, but rather as integral parts of the replacement project needed to comply with NEPA.

For alternative facilities where ER funding participation has been capped (the first and third scenarios described above), ER funding will participate in the replacement facility, including any added features, only up to the capped amount established for ER funding.

10:P:DP/EPM





**Washington State  
Department of Transportation**

## Declaration of Emergency

For the purpose of documenting the use of alternative bidding procedures under RCW 27.28.170 and estimating the costs of using State Forces for emergency work under RCW 47.28.170.

1. Date of Emergency	2. SR	3. MP Location/Limits	4. County
5. Preliminary Estimate: <input type="checkbox"/> Up to \$80,000 <input type="checkbox"/> \$80,000 to \$200,000 <input type="checkbox"/> \$200,000 and Greater			6. Work Order No. (if known)

7. Cause and Description:

8. <input type="checkbox"/> Maintenance Superintendent* <input type="checkbox"/> Director, Regional Administrator or Designee** <input type="checkbox"/> Secretary of Transportation or Designee***	9. Signature
	10. Date

\* Projects for \$80,000 or less can be authorized by the Maintenance Superintendent.

\*\* Over \$80,000 requires authorization by the Regional Administrator.

\*\*\* \$200,000 and over requires review with the Transportation Commission by the Secretary of Transportation or designee.

- Record the beginning date of the project.
- Record the State Route (SR) number affected.
- Record the mile post location.
- Record the county the damage occurred in.
- Check the appropriate box based on the preliminary estimate.
- Record the work order number (DM, MS, etc..) if known.
- In brief narrative, explain the cause of the event, describe the damage and the need to use emergency procedures.
- Check the appropriate box for the level of signature authority.
- Signature of appropriate authority.
- Date the declaration is signed.

Distribution: Original - Retained by Region; Copy - Olympia Service Center Office of Emergency Management

DOT Form 540-021 EF  
Revised 4/99

◆ Supersedes Previous Editions ◆





**Washington State  
Department of Transportation**

## Disaster Maintenance Work Order Authorization

Work Order Number <b>DM</b>	Supplement No.	Sub Program <b>M2</b>	Manager	Organization Code
SR(s)	MP From	To	County(s)	
Work Order Title			Control Section(s)	
Work Description			Source of Funds <input type="checkbox"/> State <input type="checkbox"/> FEMA <input type="checkbox"/> ER (FHWA) <input type="checkbox"/> Other	

Group	Group Category					Subtotals
	01 Work Done Contract	02 Work Done Agreement	03 Construction Engineering	04 State Force Work	Other (Specify)	
<b>Previous Authorization Totals</b>	0.00					\$0
Emerg./Incid. Perm. Work Within 180 Days						
Emerg./Incid. Perm. Work After 180 Days						
Permanent Work						
Non-Participating Work						
<b>This Request Amount</b>						
<b>New Authorization Totals</b>	0.00					\$0
<b>Total Emergency &amp; Incident Perm. Work</b>		<b>Total Permanent Work</b>		<b>Total Non-Part.</b>	<b>Total Authorization</b>	

Additional Project Information

Notes to Accounting

Copy Distribution:  
☐ OSC Maintenance    ☐ OSC Program Management  
☐ \_\_\_\_\_

DOT Form 120-021 EF  
1/99

For Federal Aid Projects Only			
FA Number	FA %	FA Appropriation	FHWA Auth. Date
_____	_____	_____	_____
NEPA Approval Date _____		Right of Way Required	
Design Approval Date _____		<input type="checkbox"/> Yes <input type="checkbox"/> No	
Initiated By _____		Date _____	
Expenditure Authorization By _____		Date _____	





**Washington State  
Department of Transportation**

## Detailed Damage Inspection Report FHWA Emergency Relief

Applicant	County(s)	FHWA Disaster No.
Location of Damage (Name of Road or Street)	Milepost	Inspection Date
	From _____	Federal-Aid Route
	To _____	
Description of Damage (Include Bridge Number(s) if Applicable)		Local /State Project No(s).

### Cost Estimate (Including Preliminary and Construction Engineering)

Temporary/Emergency Repair and Incidental Permanent Restoration work are eligible for 100% Federal participation until

<b>Temporary/Emergency Repair</b> ( <i>Work required to restore essential travel and protect the remaining facility from immediate threat.</i> )	Temp./Emerg. Repair
Method of Work: <input type="checkbox"/> Local/State Force Account <input type="checkbox"/> Emergency Contract <b>Total Temporary Repair</b>	\$
<b>Incidental Permanent Restoration</b> ( <i>That portion of the permanent work which has been determined to be more economical to be constructed along with the Temporary/Emergency work.</i> )	Incid. Perm. Restoration
Method of Work: <input type="checkbox"/> Local/State Force Account <input type="checkbox"/> Emergency Contract <b>Total Incidental Perm.</b>	\$
<b>Permanent Restoration</b> ( <i>This work is eligible for Federal participation at the standard matching ratio. This work must receive additional FHWA authorization before advertisement.</i> ) Describe any proposed betterments and their eligibility.	Permanent Restoration
<div style="text-align: right; margin-right: 50px;">           Preliminary Engineering _____            Right of Way _____            Construction _____         </div> Method of Work: <input type="checkbox"/> Local/State Force Account <input type="checkbox"/> Contract <b>Total Perm. Restoration</b>	\$
NEPA Environmental Classification <input type="checkbox"/> Categorical Exclusion <input type="checkbox"/> EA/EIS	<b>Total Estimated Cost</b> \$
Recommendation <input type="checkbox"/> Eligible <input type="checkbox"/> Ineligible	FHWA Engineer
Concurrence <input type="checkbox"/> Yes <input type="checkbox"/> No	State Representative
Concurrence <input type="checkbox"/> Yes <input type="checkbox"/> No	Local Agency Representative

☐ At the time of this inspection, all work was complete; therefore, this report constitutes the final field inspection.

DOT Form 300-001EF  
1/87







**Washington State  
Department of Transportation**

## Inspection of Federal-Aid Projects

Washington Division		Report Number	Date of Inspection	Federal-Aid No.	
Cont. No.		Project Title			
Type of Inspection <input type="checkbox"/> Interim <input type="checkbox"/> Final	Inspected By <input type="checkbox"/> Region <input type="checkbox"/> Construction Office	Quality of Work <input type="checkbox"/> Satisfactory <input type="checkbox"/> Unsatisfactory	Progress of Work <input type="checkbox"/> Satisfactory <input type="checkbox"/> Unsatisfactory	Time Elapsed %	Work Completed %
Inspection Made By			In Company With		
Remarks:					

DOT Form 422-100 EF  
10/94





Washington State  
Department of Transportation

## Inspection of Federal-Aid Projects in Maintenance Program

Project Number		Program <b>M2</b>		Region		Federal-Aid No. <b>ER-</b>	
County(s)				Project Title			
Type of Inspection <input type="checkbox"/> Interim <input type="checkbox"/> Final	Inspected By <input type="checkbox"/> Region <input type="checkbox"/> Construction Office		Quality of Work <input type="checkbox"/> Satisfactory <input type="checkbox"/> Unsatisfactory		Progress of Work <input type="checkbox"/> Satisfactory <input type="checkbox"/> Unsatisfactory		From MP  To MP
Date Work Started: _____				Date Work Completed: _____			
<b>Project Cost</b>		Temporary/Incidental Permanent Work		Permanent Work			
State Force Work:		_____		_____			
Contract / Agreement Work:		_____		_____			
Sub Total:		_____		_____			
Ineligible Work:		_____		_____			
<b>Total Cost:</b>		_____		_____			
Description of Work:							
Remarks:							
Inspector's Signature		Inspector's Title		Date of Inspection		In Company With	

DOT Form 422-100A EF  
596

cc: Funds Mgmt. Engr., MS47325; Project Support Supvr., MS 47420; FHWA Olympia, MS 0943





# Work Zone Traffic Control Guidelines


May 2000  
M54-44



**Washington State Department of Transportation**  
Field Operations Service Support Center



Persons with disabilities may request this information be prepared and supplied in alternate forms by calling the WSDOT ADA Accommodation Hotline collect (206) 389-2839. Persons with hearing impairments may access WA State Telecommunications Relay Service at TT 1-800-833-6388, Tele-Braille 1-800-833-6385, or Voice 1-800-833-6384, and ask to be connected to (360) 705-7097.



**Engineering Publications**

Washington State Department of Transportation  
PO Box 47408  
Olympia, WA 98504-7408  
E-mail: [lovem@wsdot.wa.gov](mailto:lovem@wsdot.wa.gov)

Phone: (360) 705-7430  
Fax: (360) 705-6861

<http://www.wsdot.wa.gov/fasc/EngineeringPublications/>

## Forward

---

While this booklet provides interpretive guidance, it does not change the intent of Part VI of the Manual on Uniform Traffic Control Devices (MUTCD). The traffic control devices and distances shown in this booklet reflect desired minimums for WSDOT use.

Good traffic control is essential, not only for the safety of the traveling public, but also for WSDOT employees and those construction workers whose jobs often require them to be in close proximity to high speed traffic. The traffic control guidelines in this booklet are intended to reduce field personnel's exposure to the hazards of traffic and offer the driving public consistent and positive guidance through work zone areas. Safety of crews and the driving public must be an integral part of WSDOT field operations.

We emphasize that these are guidelines and not absolute standards. The traffic control plans in this booklet are to be used along with sound judgment. Proper planning, a good safety conscious attitude and full participation from the persons involved in the work zone are all prerequisites to good traffic control. Aspects of the roadway environment such as weather, time of day, traffic volumes, traffic speed, roadway geometry, roadside conditions, and your inventory of traffic control devices should all be considered when implementing the guidelines of this booklet. If you have any questions or needs not addressed here, please consult your Regional Traffic Office staff.

Be assured that the Work Zone Safety Task Force and I are committed to securing increased funding for better and safer work zones through the legislative process to meet your workforce and equipment needs.

John Conrad



Assistant Secretary  
for Field Operations

☐ Other



## Contents

---

	<i>Page Number</i>
<b>Introduction</b>	1
<b>Instructions</b>	1
Procedures	1
Personal Attributes	2
Equipment	3
Flagging	10
<b>Checklist for Establishing a Temporary Traffic Control Zone</b>	12
<b>Taper and Buffer Space Details</b>	13
<b>Taper / Channelizing Device Table</b>	14
<b>Stationary and Short Duration Work Zones</b>	15
TCP 1    Alternating One Way Traffic, Flagger Controlled / Pilot Car Controlled	16
TCP 2    Single Lane Closure for Multi-Lane Roadways	17
TCP 3    Double Lane Closure for Multi-lane Freeways	18
TCP 4    Shoulder Closure - Low Speed (35 MPH or Less)	19
TCP 5    Shoulder Closure - High Speed (40 MPH or Higher)	20
TCP 6    Temporary Off - Ramp for Multi-Lane Freeways	21
TCP 7    Temporary On - Ramp (Right Lane Closed)	22
TCP 8    Temporary On - Ramp (Right Lane Closed)	23
TCP 9    Right Lane Closure with Shift - (5 Lane Roadway)	24
TCP 10   Left Lane and Center Turn Lane Closure - (5 Lane Roadway)	25
TCP 11   Lane Shift / Three Lane Roadway	26
<b>Rolling Slowdown</b>	27
TCP 12   Typical (Emergency) Rolling Slowdown	28

## Contents

---

	<i>Page Number</i>
<b>Mobile Work Zones</b>	29
TCP 13 Mobile Freeway Operation - Left Shoulder Closed	30
TCP 14 Mobile Freeway Operation - Left Lane Closure	31
TCP 15 Mobile Freeway Operation - Middle Lane Work Area	32
TCP 16 Mobile Operation - Lane Closure	33
TCP 17 Mobile Operation - Shoulder Closure	34
TCP 18 Mobile Shoulder Operation with Lane Encroachment (Recommended for Rural Roads with Less Than 10,000 ADT)	35
TCP 19 Tandem Snow Plow Operations - Multi-Lane Facilities	36
TCP 20 Avalanche Control Operation - Total Road Closure	37
<b>Intersection Operations</b>	38
TCP 21 Intersection Lane Closure	39
TCP 22 Intersection Lane Closure	40
TCP 23 Intersection Pedestrian Traffic Control	41
<b>Emergency Operations</b>	42
TCP 24 Flood / Slide Emergency	43
<b>Special Details and TCP Reference Chart</b>	44
TCD 1 Temporary Pavement Marking Details	45
TCD 2 Shoulder Work Area Protection - Non Working Hours	46
TCD 3 TCP Reference Chart	47
TCD 4 Typical Speedzone Detail - Chip Seal Projects	48

## Introduction

The primary function of work zone traffic control is to allow vehicles and pedestrians to move safely and easily through or around work areas. Effective temporary traffic control enhances traffic safety and efficiency. Drivers and pedestrians need to be guided in a clear and positive manner while approaching and traversing temporary traffic control zones.

The traffic control plans contained in this booklet are furnished as a guide to be used along with good judgment. Minor modifications may be made, as necessary, to accommodate site conditions; however, a plan's original intent must be maintained. An alternate plan should be considered if substantial revisions are needed. Consult the Region Traffic Office Staff for additional guidance.

No single set of traffic control plans can satisfy all conditions for all work zones. The Manual on Uniform Traffic Control Devices (MUTCD) was adopted by WSDOT as the legal standard. Principles set forth in Part VI of the MUTCD titled "Standards and Guides for Traffic Controls for Street and Highway Construction, Maintenance, Utility and Incident Management Operations" are represented in this booklet to provide traffic control guidance for common work operations.

## Instructions

### *Procedures*

1. Provide substantial protection and minimize worker exposure to traffic by applying barriers and devices in practical ways. Long term projects may warrant the use of concrete barrier while short term projects can be better served by a truck mounted attenuator (TMA). Always consider the use of a protective barrier.
2. Prior to the beginning of work operations, evaluate all aspects of the work area, including sight distance, traffic speed, volume, road approaches and the type of work activity, before deciding on a traffic control plan.
3. After the traffic control plan is implemented, the supervisor (i.e. the person(s) supervising the actual work task(s) for which the TCP was implemented – e.g. Maintenance Lead Tech, Construction Project TCS(s) – both WSDOT and contractor, survey party chief) should drive through the work area, at the anticipated speed of the motorists, to determine the effectiveness of the plan. Additional reviews throughout the day are recommended to insure that traffic control devices remain in place.
4. Traffic control devices must be moved ahead whenever work advances to more than 2 miles from the advance warning signs. **In a mobile flagging operation the “flagger ahead (symbol or text message)” sign is recommended to be within 1,000 feet of the flagger, any time a flagger is deployed.**

5. Plan ahead for manpower, equipment, and materials, (such as signs, channelization devices, pavement marking materials, etc.) needed for traffic control.
6. The distances shown on the traffic control plans are desirable minimums. Device spacing, buffer space, and sign spacing might require adjustments to provide for site conditions. Reductions in taper length distances are not recommended. Reductions in roll-ahead distances are allowed, see Equipment, 6. Truck Mounted Attenuators page 5.
7. The Washington State Patrol is available to assist WSDOT by enforcing excessive speed and drinking driver laws in critical work zone traffic control situations. These may include nighttime lane closures on high volume/high speed freeways or road closures. Contact the Region Traffic Office Staff for specific information regarding procedures to utilize the WSP.
8. Traffic control devices are used to visually guide drivers through work zones. Signing, channelizing devices, arrow boards and warning beacons all display a message to the driver. Work zone credibility is established through the proper use of these devices to send correct messages to drivers. Poor work zone credibility has a direct, negative, impact on work zone safety by causing driver confusion, frustration and disrespect which results in a high potential for accidents.
9. During paving operations, temporary pavement markings shall be maintained throughout the project. Temporary pavement markings shall be installed on the roadway that was paved that day. Temporary pavement markings shall be in accordance TCD1(Temporary Pavement Marking Details), on page 45.

## ***Personal Attributes***

1. **Awareness:**  
Routinely working near traffic for extended periods of time can cause workers to become complacent to the danger around them. Therefore, it is necessary to continually remind ourselves and others of the dangers to which we are exposed.
2. **Alertness:**  
There is no place on a “*traffic exposed*” work crew for a daydreamer or distracter. Each individual, for their own protection and that of the crew, must stay constantly alert and watchful.
3. **Attitude:**  
A positive, safety-conscious, attitude on the part of each crew member will contribute greatly to the overall safety of crew operations.

## ***Equipment***

### **1. Personal Protective Wear:**

**The wearing of soft caps is permitted, except when required by state safety regulations WAC 296-155-205, WAC 296-155-305 and WAC 296-24-084 and when working on or around the following:**

- Asphalt Plant, Crushers, Blasting Area, Asphalt grinding operations.
- Construction of bridges, structures, retaining walls, etc.
- Overhead work such as working in a trench, rock-fall areas, sign installation, installing poles, work under bridges, electrical conductors, etc.
- Working near operating equipment with arms, booms, buckets, etc.
- Work around cranes, pile driving, drilling.
- During work as a flagger.
- Brush cutter work, danger tree work, other logging operations.
- Any designated hard hat area.

Supervisors have the authority to require employees to wear hard hats for other activities where there is a danger from impact and/or penetration of falling and flying objects. Employees must have a hard hat on site and readily available for use when work conditions require their use.

### ***Traffic Vest, Coveralls, Rain Gear and T-Shirts***

**While working on foot in a highway right of way (fence line to fence line) all WSDOT workers must:**

- Wear reflective vests, except that during daylight hours, clothing of orange, yellow, strong yellow green or fluorescent versions of these colors may be worn in lieu of reflective vests. Flaggers must wear reflective vests and hard hats at all times.
- During hours of darkness, wear vests, white coveralls or either high visibility reflective strong yellow green pants with red-orange strip or red-orange pants with lime yellow strip.
- When rain gear is worn during the hours of darkness, it shall be white or yellow.
- The reflective vests shall always be the outermost garment.

**Exceptions to these requirements are:** (1) when personnel are out of view of, or not exposed to, traffic, (2) when personnel are inside a vehicle, or (3) where it is obvious that such apparel is not needed for employee safety from traffic.

The standard WSDOT vest is either high visibility strong yellow green in base color with orange-red trim or 3M silver Scotchlite reflective material (or equivalent), **or** a red-orange base color with strong yellow green trim and either 3M silver Scotchlite or 3M type, 2" wide, 6187 (or equivalent) strong yellow green reflective strip.

A WSDOT specified, high visibility, T-shirt may be purchased by WSDOT employees and worn in lieu of the WSDOT Safety Vest by employees during daylight hours and when not working as a flagger. T-shirts shall not have any words or "ads" affixed to them. The WSDOT T-shirt standard requires a crew neck, base color orange, minimum 2 each 2" horizontal yellow bars on front and back with at least 2" apart vertically. The supervisor and/or Region Safety Officer shall have final approval authority over both the T-shirt itself and its use.

2. **Traffic Control Crash Test Requirements:**

After October 1, 2000, all new purchases of Category II traffic control devices (portable sign stands with signs, type 1, 2, & 3 barricades, vertical panels, intrusion alarms, and other work zone devices under 100 lbs.) shall be compliant with the federal NCHRP 350 crash test requirements. WSDOT will phase out existing devices as they complete their normal service life. All Category II devices will be "350" compliant by December 31, 2007.

3. **Condition and Care of Equipment:**

All personal equipment and traffic control devices shall be kept clean to provide protection for the crew through better visibility to the motorist.

4. **Signs:**

Old signs that are no longer reflective (visible and legible at night) or in poor condition are to be replaced. Standard 48" x 48" temporary warning signs are diamond shape with black letters or symbols on an orange background. Some work areas might require the use of special or regulatory signs. Roll-up reflective signs can also be used. Sign supports must be in good condition and be capable of withstanding normal wind stresses along the highway.

5. **Vehicles:**

- **Work Zone Vehicle** - All vehicles used within the work zone must be equipped with an approved flashing warning beacon. Consideration must be given to the location of workers in relation to the work vehicles. Worker safety can be jeopardized if the motorists' attention is focused on the work vehicle and beacon when the workers are at an unexpected location. Workers should be in close proximity to work vehicles, on the same side of the roadway.
- **Protective Vehicle** - Usually a stationary vehicle (in stationary work zones) strategically placed in advance of the work area, between the buffer space and the roll ahead space, to protect workers from oncoming traffic. The use of a Truck Mounted Attenuator (TMA) on this vehicle is recommended (see the chart on

page 6). Allow for roll ahead distance resulting from an impact. Refer to the data block on the TCPs for specific information. The Protective vehicle can be a work vehicle if no other vehicles are available.

- **Shadow Vehicle** - Very similar to the protective vehicle but usually a moving vehicle (mobile work zones). All of the above guidelines for the protective vehicle apply to the shadow vehicle. A sequential arrow panel or truck mounted Portable Changeable Message Sign(PCMS) may also be used on the shadow vehicle.

6. **Truck Mounted Attenuators (TMA):**

Recommended for high speed work zone protection. If a TMA is not available, the use of a protective or shadow vehicle is still highly recommended.

**Consider the following for determining TMA use:**

- **Speed of Traffic** - Higher operating speeds leave less response time and impacts generally result in more severe injuries and damage. Therefore, the higher the operating speed the more probability that a TMA is necessary.
- **Type of activity** - Mobile, intermittent or stationary.
- **Duration of project.**
- **Roadway environment** - Access controlled vs. non-access controlled, urban vs. rural, and roadway geometrics. Access controlled facilities frequently give drivers a false sense of security since interruptions are not expected. Therefore, activities on freeways may be more susceptible to incidents than are activities on non-access controlled facilities, where drivers are generally more alert.
- **Traffic volumes** - More traffic means more worker exposure.
- **Exposure to special hazards** - Operations involving personnel on foot or located in exposed positions (for example, on the platform of a pickup truck placing cones or in a lift-bucket performing overhead operations) are particularly susceptible to high severity incidents.
- **Location of work area** - Locations of primary concern are those within the traveled lanes or within frequently used, all-weather, shoulders. Activities taking place within the traveled lanes are more likely to become involved in an incident than are shoulder activities.
- **Roll Ahead Distance** - The roll ahead distances shown in the BUFFER DATA blocks on the TCPs are conservative values, based upon a 24,000 lb. vehicle impacting the TMA. These distances may be reduced, after consideration of all the above factors, including the mix of vehicle type traveling past the work site. The Region Traffic Office should be contacted for concurrence with reductions in the R distances.

## Priorities for the Application of Truck Mounted Attenuators (TMA)

Closure / Exposure Condition	Priority			
	Freeway	Non-Freeway with Speed Limit		
		> 50 mph	40-45 mph	< 35 mph
<b>No Formal Lane Closure</b>				
Shadow Vehicle for Operation Involving Exposed Personnel	*1	2	3	4
Shadow Vehicle for Operation Not Involving Exposed Personnel	1	2	3	4
<b>No Formal Shoulder Closure</b>				
Shadow Vehicle for Operation Involving Exposed Personnel	2	3	3	3
Shadow Vehicle for Operation Not Involving Exposed Personnel	2	3	4	5
<b>Formal Lane Closure</b>				
Protective vehicle for Operation Involving Exposed Personnel	2	3	4	5
Protective vehicle for Condition Involving Significant Hazard	2	3	4	5
<b>Formal Shoulder Closure</b>				
Protective vehicle for Operation Involving Exposed Personnel	3	4	5	5
Protective vehicle for Condition Involving Significant Hazard	3	4	5	5

\* The numerical rank indicates the level of priority assigned to the use of a TMA on an assigned shadow/protective vehicle. The use of a TMA under the defined condition is:

1. very highly recommended
2. highly recommended
3. recommended
4. desirable
5. may be justified on the basis of special conditions encountered on an individual project.



7. **Portable Changeable Message Signs (PCMS):**

- Recommended for high speed, high volume roadways, or work operations that require a highly visible message.
- Shall **not** be used to replace required signs
- Place in advance of other temporary traffic control zone signing.
- Should be visible for ½ mile minimum (both day and night).
- Should be legible for at least 650 ft. (all lanes).
- Should be able to be read twice at the posted speed.
- Each individual display should convey a single thought.
- A complete message cycle should consist of **no more than two** displays in sequence.
- Bottom of sign panel shall be a minimum of 7' above roadway.
- PCMS shall automatically adjust its light source relative to surrounding conditions.
- Messages shall not scroll horizontally or vertically across the sign face.
- Consider truck mounted PCMS for shadow vehicles.

8. **Sequential Arrow Panel (Flashing Arrow Board):**

- Required for all lane closures on multi-lane roads, except during emergencies.
- An arrow shall not be used on a multi-lane roadway to laterally shift traffic.
- An arrow display shall not be used on a two lane, two way roadway.
- Do not use arrow display for shoulder closures.
- Use caution mode for shoulder closures.
- Only the four corner flash shall be used to indicate caution.
- Use **only one** arrow display per lane being closed (unless used in mobile operations).
- Arrow should be used in combination with other appropriate traffic control devices.

- Arrow display shall be capable of a minimum 50 percent dimming.
- For stationary lane closure, the arrow should be located on the shoulder at the beginning of the taper.
- The arrow shall be located behind channelizing devices (unless used in mobile operations).
- Arrow panels should be visible for ½ mile minimum, depending upon arrow type and conditions.
- An arrow display with a shadow (early warning) vehicle is allowed on mobile lane closure operations.

9. **Temporary Traffic Control / Channelizing Devices:**

Traffic safety cones are the most common device used to separate and guide traffic past a work area. Cones and tubular markers must be 18" tall, except for high speed, high volume, or night-time operations, where they must be 28" tall, and reflectorized. Traffic safety drums must be 36" tall, and are recommended for use on freeways due to their greater visibility and imposing size. Maximum spacing requirements are shown on the TCP's. The Table on page 14 is provided to help select the proper taper lengths and number of devices needed. Tighter spacing may be desirable, under some conditions, to enhance motorists' guidance.

10. **Water Filled Barrier:**

Water filled barriers are longitudinal barrier systems that use light weight modules pinned together and filled with water to form a barrier. They are **not intended** as a replacement for concrete barrier. In emergency maintenance situations, they may be considered for short-term use as a substitute for concrete barrier. Two different systems (Triton and Guardian) have been crash tested and approved for WSDOT use.

**Caution:** **Depending upon** vehicle speeds and potential angle of impact, a lateral deflection space of **up to** 23 feet **can be** required behind the barrier.

Evaluate risk and site conditions, and **if** used, follow the manufacturer's specifications and recommendations. Contact the Region Traffic Office, or OSC Design Office, for advise on use of this device and assistance in determining the deflection space requirement behind the barrier.

Do not use in lane transitions unless the situation meets with manufacturer's specifications, **and** ensure approach ends are crashworthy, or are protected with a TMA."

#### 11. **Concrete Barrier:**

A semi-rigid barrier designed to prevent intrusion of errant vehicles into work areas. Recommended for long term stationary work areas with high exposure to traffic. Contact the Region Traffic Office Staff for site specific placement information.

##### **Consider the following for use of concrete barriers:**

- Areas where there is a high potential for injury to workers or "no escape" areas such as internal lane work, work zones in tunnels, bridges, lane expansion work, etc.
- Long term, stationary jobs
- Areas of high exposure to workers and motorists such as high speed and high volume of traffic.

##### **Consider the following for use of movable barrier such as Transfer/Transport Vehicle (TM) (barrier and special vehicle):**

- High volume traffic conditions with very short-term lane closures.
- Continuous operation over an extended period of time, where there is a need to get the lane back in operation at some point in the day. (Could be used in lieu of reduced lane widths or lane reduction, i.e. HOV lane additions; wall next to roadway.)

#### 12. **Barricades:**

Generally used to protect spot hazards but can also be used to close roadways and sidewalks with appropriate signing. Barricades can also be used to provide additional protection to work areas. *Lights used to channelize traffic must be steady burning (Type C).*

#### 13. **Flares:**

All work vehicles should carry a supply of flares. Use flares only to alert drivers to emergencies and not as routine traffic control device. Emergencies are defined as unexpected events where life threatening conditions, injuries or property damage may occur unless immediate action is taken. Use caution at accident sites where flammable materials, such as fuel spills, are suspected.

##### **Consider the following for use of flares:**

- Primarily used in high hazard conditions only (i.e. accidents, spills, equipment breakdowns, dangerous snow and ice conditions, etc.)
- Use electronic flares or orange/red-glow sticks instead of burning flares where flammable materials are suspected.

## **FLAGGING**

- Flagging should be employed only when all other methods of traffic control are inadequate to direct, or control, traffic.
- Locate the flagger off the traveled portion of the roadway. More than one flagger may be necessary to achieve traffic control in both directions. A means of communication between flaggers must be considered in these situations. Communication can be visual, or by hand held radio.
- Only persons who have successfully completed an approved flagging course and who possess current flagging certification recognized in Washington State can be used as flaggers.
- Freeway characteristics do not lend themselves to effective flagging. High speed multiple lanes and normal driver expectancy do not provide an opportunity for the flagger to actually warn or direct traffic, therefore flagging on freeways is not normally recommended. However, using a “spotter” may be helpful to protect the work crew.
- In a mobile flagging operation, all signs associated with the flagger must be moved ahead whenever work advances to more than 2 miles from the advance warning signs; also, **the “flagger ahead (symbol or text message)” sign is recommended to be within 1,000 feet of the flagger, any time a flagger is deployed.**
- During hours of darkness flagger stations shall be illuminated without causing glare to the traveling public.

### **Flagger’s Rules of Conduct**


1. Be clearly visible to approaching traffic at all times. Motorists should be able to see you from 500 feet away.
2. Do not stand in front of parked/stopped cars.
3. Always be aware of oncoming traffic.
4. Do not step into, or turn your back on the traffic.
5. Stand on the shoulder of the road observing traffic and the work zone. Sometimes you may have to stand on the opposite side of the road to effectively direct traffic around the work area.
6. Choose the best flagging position that will provide the greatest color contrast between you and the background.

7. If at all possible, do not stand in the shade.
8. Never flag from inside a vehicle.
9. Do not lean, sit or lie on a vehicle.
10. Stand alone. Do not permit a group of workers to congregate around you.
11. Familiarize yourself with the nature of the work being performed. Be able to answer motorists' questions.
12. Establish a warning signal with the work crew in case of an emergency.
13. Plan an escape route in case of an emergency.
14. Stay alert! Be ready to respond to an emergency.
15. Record the license number and description of any vehicle whose driver disobeys your instructions and threatens the safety of the work area. Report information to authorities.
16. Be courteous and professional.
17. Keep your mind on your job. Be aware of the work in progress.
18. Do not do any other work when flagging.
19. Do not involve yourself in unnecessary conversation with workers, pedestrians, or motorists.
20. Do not leave your position until you are appropriately relieved.
21. Cover, turn or remove the "FLAGGER AHEAD" sign when a flagger is no longer on duty.
22. Always carry your flagger certification card while on the job.

## **CHECKLIST FOR ESTABLISHING A TEMPORARY TRAFFIC CONTROL ZONE\***

COMPLETED	ITEM
<input type="checkbox"/>	Determine the duration of work, ( Mobile, Short-Term, Intermediate Term/Night)*
<input type="checkbox"/>	Select hours of work to avoid peak periods (refer to work hour chart when applicable).*
<input type="checkbox"/>	Select the appropriate layout(s), using duration, type of roadway, volume, and speed, from guidelines.
<input type="checkbox"/>	Determine any modifications to typical layout(s). <ul style="list-style-type: none"><li>• Check decision sight distance</li><li>• Intersection/driveways</li><li>• Allow for buffer space free of obstructions</li></ul>
<input type="checkbox"/>	Check the condition of devices (Refer to Quality Standards Booklet).
<input type="checkbox"/>	Install devices beginning with the first device the driver will see. Device spacing as per chart on TCP.
<input type="checkbox"/>	Conduct a drive through to check for problems.
<input type="checkbox"/>	Document temporary traffic control zone, problems and major modifications to the layouts.
<input type="checkbox"/>	Maintain devices while in place.
<input type="checkbox"/>	Complete work.
<input type="checkbox"/>	Remove the devices as soon as work is completed, beginning with the last device placed.

\*Utilize the Region Traffic Office Staff to address concerns and questions.



TAPER & BUFFER SPACE DETAILS

BUFFER DATA										
BUFFER SPACE = B										
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70
LENGTH (feet)	55	85	120	170	220	280	335	415	485	585
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*										
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)		POSTED SPEED (mph)		STATIONARY OPERATION (feet)		<b>* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.</b>			
4 YARD DUMP TRUCK	24,000		60-70		100					
			50-55		75					
			45		50					
2 TON CARGO TRUCK	15,000		60-70		150					
			50-55		100					
			45		75					
1 TON CARGO TRUCK	10,000		60-70		200					
			50-55		150					
			45		100					
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT										
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.										

CHANNELIZING DEVICE SPACING (FEET)		
MPH	TAPER	TANGENT
50/70	40	80
35/45	30	60
25/30	20	40

MINIMUM TAPER LENGTH (L) IN FEET									
Lane Width (feet)	Posted Speed (mph)								
	25	30	35	40	45	50	55	60	65 70
10	105	150	205	265	450	500	550	-	-
11	115	165	225	295	495	550	605	660	-
12	125	180	245	320	540	600	660	720	780 840

### LEGEND

□ □ □ TEMPORARY TRAFFIC CONTROL DEVICES

🚗 PROTECTIVE VEHICLE - RECOMMENDED

MERGING, SHIFTING & SHOULDER TAPER LENGTHS  
AND NUMBER OF CHANNELIZATION DEVICES USED

Lane Width	10 Feet						11 Feet						12 Feet						Shoulder Tapers (Assumes 10' Shoulders)		
	L			1/2 L			L			1/2 L			L			1/2 L			*1/3 L		
MPH	Merging	Devices	Shifting	Devices	Merging	Devices	Shifting	Devices	Merging	Devices	Shifting	Devices	Merging	Devices	Shifting	Devices	MPH	(ft) Length	Devices		
20	70	5	35	3	75	5	40	3	80	5	40	3	80	5	40	3	20	25	3		
25	105	6	55	4	115	7	60	4	125	7	65	4	125	7	65	4	25	35	3		
30	150	8	75	5	165	9	85	5	180	10	90	5	180	10	90	5	30	50	3		
35	205	8	105	5	225	9	115	5	245	9	125	5	245	9	125	5	35	70	4		
40	270	10	135	6	295	11	150	6	320	12	160	6	320	12	160	6	40	90	4		
45	450	16	225	9	495	18	250	9	540	19	270	10	540	19	270	10	45	150	6		
50	500	14	250	8	550	15	275	8	600	16	300	9	600	16	300	9	50	170	6		
55	550	15	275	8	605	16	305	9	660	18	330	9	660	18	330	9	55	185	6		
60	600	16	300	9	660	18	330	9	720	19	360	10	720	19	360	10	60	200	6		
65	650	17	325	9	715	19	370	10	780	21	390	11	780	21	390	11	65	220	7		
70	700	19	350	10	770	20	385	11	840	22	420	12	840	22	420	12	70	235	7		
*L for shoulder taper equals Shoulder Width x Speed. Figures shown are for a 10' shoulder.																					

*\*L for shoulder taper equals  
Shoulder Width x Speed.  
Figures shown are for a  
10' shoulder.*



## **STATIONARY OR SHORT DURATION WORK ZONES**

### **Traffic Control Plans (TCP's) 1 to 11**

Stationary work zones are used for work activities that exceed one hour but could last for several days. Signs and channelizing devices are required for stationary work zones. Devices, such as sequential arrow panels, barricades and protective vehicles, may also be used depending on the situation. For longer term projects, temporary concrete barriers or water filled barriers, temporary pavement markings and post mounted signs might be typical devices. Examples of stationary work zone operations include: light standard repair, paving, sign installation and bridge repair. Stationary work zone traffic control is usually associated with a substantial work operation that may have many workers, equipment, truck hauling and flagging. Traffic operation, all work activities, workers and flaggers must be incorporated into the work zone and provided for during planning and selecting the Traffic Control Plans (TCP's).


Short duration work zones are used for work activities less than 60 minutes. Due to the short work time simplified traffic control set-ups are allowed to reduce the hazards of traffic exposure to workers. The time it may take to set up a full complement of signs and devices could approach the amount of time it requires to perform the work. Careful consideration of traffic and roadway conditions must be given to each work zone prior to selecting the most appropriate traffic control set-up. Shoulder work and low speed, low volume lane work may only require the use of the work vehicle hazard beacon, a flagger and a warning sign. High speed, high volume lane work requires a full lane closure set-up, even though work duration may be 60 minutes or less. Remember, short duration work is not a "short cut", it's a traffic control method that reduces worker exposure to traffic hazards by using larger, more mobile equipment instead of many smaller devices (cones are recommended in most cases since they are quick to set up for small work zones). Examples of short duration work zone operations include, re-lamping, pot hole repair, Vector work, etc..

The following TCP's show typical stationary and short duration work zones.

BUFFER DATA												
BUFFER SPACE = B												
SPEED (MPH)	25	30	35	40	45	50	55	60	65			
LENGTH (feet)	55	85	120	170	220	280	335	415	485			
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*												
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)		POSTED SPEED (mph)		STATIONARY OPERATION (feet)							
4 YARD DUMP TRUCK	24,000		60-65		100							* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE. SEE PAGE 5.
			50-55		75							
			45		50							
2 TON CARGO TRUCK	15,000		60-65		150							
			50-55		100							
			45		75							
1 TON CARGO TRUCK	10,000		60-65		200							
			50-55		150							
			45		100							
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT.												
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.												

SIGN SPACING = X (FEET)		
Rural Roads	45/65 MPH	500'+-
Urban Arterials & Rural Roads	35/40 MPH	350'+-
Urban Streets, Residential & Business Districts	25/30 MPH	200'+-
All signs are 48"x48" black on orange unless otherwise designated.		

CHANNELIZING DEVICE SPACING (FEET)		
MPH	TAPER	TANGENT
50/65	40	80
35/45	30	60
25/30	20	40



FOR PILOT CAR OPERATIONS THE FOLLOWING SIGNS SHALL BE REQUIRED TO SUPPLEMENT THE SIGNS SHOWN ON THIS PLAN.

G20-4 36"X18" B/O

SP-1 14" X 14" 4" C B/O

STOP WAIT FOR PILOT CAR (ON PILOT CAR) (FOR ROAD APPROACHES AS NEEDED)

PILOT CAR FOLLOW ME

GENERAL NOTES

1. WORK HOURS SHALL BE DAYLIGHT HOURS ONLY, UNLESS TRAFFIC VOLUMES OR EMERGENCIES DICTATE OTHERWISE.
2. IF ENTIRE WORK AREA IS VISIBLE FROM ONE STATION, ONE FLAGGER MAY BE USED. OTHERWISE, ONE FLAGGER WILL BE REQUIRED FOR EACH DIRECTION.
3. EXTEND DEVICES TAPER ACROSS SHOULDER.
4. PROTECTIVE VEHICLE RECOMMENDED - MAY BE A WORK VEHICLE.
5. SIGN SEQUENCE IS THE SAME FOR BOTH DIRECTIONS OF TRAVEL ON THE HIGHWAY.

- W SIGN LOCATION
- □ □ TEMPORARY TRAFFIC CONTROL DEVICES
- FLAGGING STATION
- PROTECTIVE VEHICLE - RECOMMENDED


ALTERNATING ONE-WAY TRAFFIC  
FLAGGER CONTROLLED / PILOT CAR CONTROLLED  
TCP 1

BUFFER DATA																		
BUFFER SPACE = B																		
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70								
LENGTH (feet)	55	85	120	170	220	280	335	415	485	585								
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*																		
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)		POSTED SPEED (mph)		STATIONARY OPERATION (feet)													
4 YARD DUMP TRUCK	24,000		60-70		100		• VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE. SEE PAGE 5.											
			50-55		75													
			45		50													
2 TON CARGO TRUCK	15,000		60-70		150													
			50-55		100													
			45		75													
1 TON CARGO TRUCK	10,000		60-70		200													
			50-55		150													
			45		100													
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT.																		
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.																		

MINIMUM TAPER LENGTH (L) IN FEET												
Lane Width (feet)	Posted Speed (mph)											
	25	30	35	40	45	50	55	60	65	70		
10	105	150	205	265	450	500	550	-	-	-		
11	115	165	225	295	495	550	605	660	-	-		
12	125	180	245	320	540	600	660	720	780	840		

SIGN SPACING = X (FEET)			
Freeways & Expressways	55/70 MPH	1500' +- (OR AS PER MUTCD)	
Rural Roads	45/55 MPH	500' +-	
Urban Arterials & Rural Roads	35/40 MPH	350' +-	
Rural Roads	25/30 MPH	200' +-	
Urban Streets, Residential & Business Districts			
All signs are 48"x48" black on orange unless otherwise designated.			

CHANNELIZING DEVICE SPACING (FEET)			
MPH	TAPER	TANGENT	
50/70	40	80	
35/45	30	60	
25/30	20	40	



(SAMPLE MESSAGE)

PCMS		
1	2	
RIGHT LANE CLOSED	1 MILE AHEAD	
1.5 SEC	1.5 SEC	

Field locate 1 mile +-  
In advance of lane closure.

## GENERAL NOTES

1. PROTECTIVE VEHICLE RECOMMENDED - MAY BE A WORK VEHICLE.
2. CONTACT REGION TRAFFIC OFFICE STAFF FOR WORK HOURS.
3. EXTEND DEVICE TAPER ACROSS SHOULDER.
4. DEVICES SHOULD NOT ENCR OACH INTO ADJACENT LANES.
5. PCMS RECOMMENDED.
6. USE TRANSVERSE DEVICES IN CLOSED LANE EVERY 1000' +-
7. TRAFFIC SAFETY DRUMS RECOMMENDED FOR FREEWAY USE (IN LIEU OF CONES).


## LEGEND

- ▮ SIGN LOCATION
- ▮▮▮ SEQUENTIAL ARROW SIGN
- ▮▮▮ TEMPORARY TRAFFIC CONTROL DEVICES
- ▮▮▮ PROTECTIVE VEHICLE - RECOMMENDED


SINGLE-LANE CLOSURE  
FOR MULTI-LANE ROADWAYS  
TCP 2



BUFFER DATA										
BUFFER SPACE = B										
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70
LENGTH (feet)	55	85	120	—	—	—	—	—	—	—
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*										
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)	POSTED SPEED (mph)	STATIONARY OPERATION (feet)	* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.						
4 YARD DUMP TRUCK	24,000	60-70	-----							
		50-55	-----							
2 TON CARGO TRUCK	15,000	45	50							
		60-70	-----							
1 TON CARGO TRUCK	10,000	50-55	-----							
		45	75							
1 TON CARGO TRUCK	10,000	60-70	-----							
		50-55	-----							
		45	100							
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT										
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.										







BUFFER DATA												
BUFFER SPACE = B												
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70		
LENGTH (feet)	—	—	—	—	170	220	280	335	415	485	585	
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*												
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)		POSTED SPEED (mph)		STATIONARY OPERATION (feet)							
4 YARD DUMP TRUCK	24,000		60-70		100		• VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.					
			50-55		75							
15,000		45		50								
		60-70		150								
2 TON CARGO TRUCK		50-55		100								
		45		75								
1 TON CARGO TRUCK		60-70		200								
		50-55		150								
		45		100								
				</								

MINIMUM TAPER LENGTH (L) IN FEET												
Lane Width (feet)	Posted Speed (mph)											
	25	30	35	40	45	50	55	60	65	70		
	10	-	-	-	265	450	500	550	-	-	-	-
	11	-	-	-	295	495	550	605	660	-	-	-
	12	-	-	-	320	540	600	660	720	780	840	
SIGN SPACING = X (FEET)												
Freeways & Expressways					55/70 MPH					1500'++ (OR AS PER MUTCD)		
Rural Roads					45/65 MPH					500'++		
Urban Arterials					40 MPH					350'++		
All signs are 48"x48" black on orange unless otherwise designated.												

GENERAL NOTES

1. THE DESIRABLE RAMP OPENING WIDTH IS 14'.
2. A G20-2A END ROAD WORK SIGN SHOULD BE INSTALLED ABOUT 500 FEET BEYOND THE WORK AREA OR USE A DOWN STREAM TAPER.
3. CONTACT REGION TRAFFIC OFFICE STAFF FOR WORK HOURS.
4. PROTECTIVE VEHICLE RECOMMENDED - MAY BE A WORK VEHICLE.
5. EXTEND DEVICE TAPER ACROSS SHOULDER.
6. PCMS RECOMMENDED.
7. TRAFFIC SAFETY DRUMS RECOMMENDED FOR FREEWAY USE (IN LIEU OF CONES).
8. USE TRANSVERSE DEVICES IN CLOSED LANE EVERY 1000' ±

(SAMPLE MESSAGE)

PCMS	
1	2
RIGHT LANE CLOSED	1 MILE AHEAD
1.5 SEC	1.5 SEC

Field locate 1 mile ± in advance of lane closure.

CHANNELIZING DEVICE SPACING (FEET)		
MPH	TAPER	TANGENT
50/70	40	80
40/45	30	60

LEGEND

- SIGN LOCATION
- SEQUENTIAL ARROW SIGN
- TEMPORARY TRAFFIC CONTROL DEVICES
- PROTECTIVE VEHICLE - RECOMMENDED
- PORTABLE CHANGEABLE MESSAGE SIGN

TEMPORARY OFF-RAMP FOR MULTI-LANE FREEWAYS TCP 6


BUFFER DATA												
BUFFER SPACE = B												
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70		
LENGTH (feet)	—	—	—	170	220	280	335	415	485	585		
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*												
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)	POSTED SPEED (mph)	STATIONARY OPERATION (feet)	* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE. SEE PAGE 5.								
4 YARD DUMP TRUCK	24,000	60-70 50-55 45	100 75 50									
2 TON CARGO TRUCK	15,000	60-70 50-55 45	150 100 75									
1 TON CARGO TRUCK	10,000	60-70 50-55 45	200 150 100									
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT												
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.												

SIGN SPACING = X (FEET)		
Freeways & Expressways	55/70 MPH	1500'± (OR AS PER MUTCD)
Rural Roads	45/65 MPH	500'±
Urban Arterials	40 MPH	350'±
All signs are 48"x48" black on orange unless otherwise designated.		

CHANNELIZING DEVICE SPACING (FEET)		
MPH	TAPER	TANGENT
50/70	40	80
40/45	30	60

MINIMUM TAPER LENGTH (L) IN FEET										
Lane Width (feet)	Posted Speed (mph)									
	25	30	35	40	45	50	55	60	65	70
10	—	—	—	265	450	500	550	—	—	—
11	—	—	—	295	495	550	605	660	—	—
12	—	—	—	320	540	600	660	720	780	840

(Optional)  
W4-3



#### GENERAL NOTES

1. THE DESIRABLE RAMP OPENING WIDTH IS 14'.
2. A G20-2A END ROAD WORK SIGN SHOULD BE INSTALLED ABOUT 500 FEET BEYOND THE WORK AREA OR USE A DOWN STREAM TAPER.
3. CONTACT REGION TRAFFIC OFFICE STAFF FOR WORK HOURS.
4. PROTECTIVE VEHICLE RECOMMENDED - MAY BE A WORK VEHICLE.
5. EXTEND DEVICE TAPER ACROSS SHOULDER.
6. PCMS RECOMMENDED.
7. TRAFFIC SAFETY DRUMS RECOMMENDED FOR FREEWAY USE (IN LIEU OF CONES).
8. USE TRANSVERSE DEVICES IN CLOSED LANE EVERY 1000' ±

(SAMPLE MESSAGE)

PCMS	
1	2
RIGHT LANE CLOSED	1 MILE AHEAD
1.5 SEC	1.5 SEC

Field locate 1 mile ±  
In advance of lane closure.

#### LEGEND

- NI SIGN LOCATION
- SEQUENTIAL ARROW SIGN
- □ □ TEMPORARY TRAFFIC CONTROL DEVICES
- PROTECTIVE VEHICLE - RECOMMENDED
- PORTABLE CHANGEABLE MESSAGE SIGN

TEMPORARY ON-RAMP  
(RIGHT LANE CLOSED)  
TCP 7




BUFFER DATA												
BUFFER SPACE = B												
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70		
LENGTH (feet)	—	—	—	—	170	220	280	335	415	485	585	
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*												
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)	POSTED SPEED (mph)	STATIONARY OPERATION (feet)	• VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.								
4 YARD DUMP TRUCK	24,000	60-70	100	50-55	75	45	50	60-70	150	100	75	200
2 TON CARGO TRUCK	15,000	50-55	100	45	75	60-70	200	50-55	150	100	75	200
1 TON CARGO TRUCK	10,000	45	100	45	75	60-70	200	50-55	150	100	75	200
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT												
TMA - RECOMMENDED. SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.												

SIGN SPACING = X (FEET)		
Freeways & Expressways	55/70 MPH	1500'± (OR AS PER MUTCD)
Rural Roads	45/65 MPH	500'±
Urban Arterials	40 MPH	350'±
All signs are 48"x48" black on orange unless otherwise designated.		

MINIMUM TAPER LENGTH (L) IN FEET										
Lane Width (feet)	Posted Speed (mph)									
	25	30	35	40	45	50	55	60	65	70
10	-	-	-	265	450	500	550	-	-	-
11	-	-	-	295	495	550	605	660	-	-
12	-	-	-	320	540	600	660	720	780	840

CHANNELIZING DEVICE SPACING (FEET)		
MPH	TAPER	TANGENT
50/70	40	80
40/45	30	60



(SAMPLE MESSAGE)		
PCMS		
1	2	
RIGHT LANE CLOSED	1 MILE AHEAD	
1.5 SEC	1.5 SEC	

Field locate 1 mile +-  
in advance of lane closure.

### LEGEND


- PCMS SIGN LOCATION
  - ➡➡➡ SEQUENTIAL ARROW SIGN
  - □ □ TEMPORARY TRAFFIC CONTROL DEVICES
  - PROTECTIVE VEHICLE - RECOMMENDED
  - W20-1 ROAD WORK AHEAD
  - W20-5R RIGHT LANE CLOSED AHEAD
  - W4-2L RIGHT LANE CLOSED AHEAD
  - W3-2 YIELD AHEAD
  - R1-2 YIELD
- GENERAL NOTES
1. THE DESIRABLE RAMP OPENING WIDTH IS 14'.
  2. A G20-2A END ROAD WORK SIGN SHOULD BE INSTALLED ABOUT 500 FEET BEYOND THE WORK AREA OR USE A DOWN STREAM TAPER.
  3. CONTACT REGION TRAFFIC OFFICE STAFF FOR WORK HOURS.
  4. PROTECTIVE VEHICLE RECOMMENDED - MAY BE A WORK VEHICLE.
  5. EXTEND DEVICE TAPER ACROSS SHOULDER.
  6. PCMS RECOMMENDED.
  7. TRAFFIC SAFETY DRUMS RECOMMENDED FOR FREEWAY USE (IN LIEU OF CONES).
  8. USE TRANSVERSE DEVICES IN CLOSED LANE EVERY 1000' ±
- TEMPORARY ON-RAMP (RIGHT LANE CLOSED) TCP 8

BUFFER DATA											
BUFFER SPACE = B											
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70	
LENGTH (feet)	55	85	120	170	220	280	—	—	—	—	
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*											
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)	POSTED SPEED (mph)	STATIONARY OPERATION (feet)								
4 YARD DUMP TRUCK	24,000	60-70	-----	• VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.							
		50	75								
		45	50								
2 TON CARGO TRUCK	15,000	60-70	-----								
		50	100								
		45	75								
1 TON CARGO TRUCK	10,000	60-70	-----								
		50	150								
		45	100								
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT											
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.											

SIGN SPACING = X (FEET)			
Rural Roads	45/50 MPH	500'±	
Urban Arterials	35/40 MPH	350'±	
Rural Roads	25/30 MPH	200'±	
Urban Streets Residential & Business Districts			
All signs are 48" X 48" black on orange unless otherwise designated			

MINIMUM TAPER LENGTH = L (FEET)											
LANE WIDTH (feet)	25	30	35	40	45	50	55	60	65	70	
10	105	150	205	270	450	500	—	—	—	—	
11	115	165	225	295	495	550	—	—	—	—	
12	125	180	245	320	540	600	—	—	—	—	

CHANNELIZING DEVICE SPACING (FEET)		
MPH	TAPER	TANGENT
50	40	80
35/45	30	60
25/30	20	40



- GENERAL NOTES**
1. PROTECTIVE VEHICLE RECOMMENDED - MAY BE A WORK VEHICLE.
  2. EXTEND TAPER ACROSS SHOULDER.
  3. CONTACT REGION TRAFFIC OFFICE STAFF FOR WORK HOURS.
  4. MAINTAIN A MINIMUM OF ONE ACCESS POINT FOR EACH BUSINESS WITHIN WORK AREA LIMITS.
  5. IF THE LANE SHIFT IS SHORT AND HAS SHARP CURVES (30 MPH OR LESS) USE SIGN W1-3 IN LIEU OF SIGN W1-4.
- LEGEND**
- ☒ SIGN LOCATION
  - ☒ SIGN LOCATION
  - ☒ SEQUENTIAL ARROW SIGN
  - ☐ TEMPORARY TRAFFIC CONTROL DEVICES
  - ☐ PROTECTIVE VEHICLE - RECOMMENDED
  - ☐ PORTABLE CHANGEABLE MESSAGE SIGN


RIGHT LANE CLOSURE WITH SHIFT  
5 LANE ROADWAY  
TCP 9

BUFFER DATA												
BUFFER SPACE = B												
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70		
LENGTH (feet)	55	85	120	170	220	280	335	—	—	—		
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*												
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)		POSTED SPEED (mph)		STATIONARY OPERATION (feet)							
4 YARD DUMP TRUCK	24,000		60-70		-----		• VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.					
			50-55		75							
			45		50							
2 TON CARGO TRUCK	15,000		60-70		-----							
			50-55		100							
			45		75							
1 TON CARGO TRUCK	10,000		60-70		-----							
			50-55		150							
			45		100							
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT												
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.												

SIGN SPACING = X (FEET)			500' +- 350' +- 200' +- All signs are 48" X 48" black on orange unless otherwise designated		
Rural Roads	45/55 MPH	500' +-			
Urban Arterials	35/40 MPH	350' +-			
Rural Roads	25/30 MPH	200' +-			
Urban Streets Residential & Business Districts	25/30 MPH	200' +-			

MINIMUM TAPER LENGTH = L (FEET)									
LANE WIDTH (feet)	25	30	35	40	45	50	55	60	70
10	105	150	205	270	450	500	550	—	—
11	115	165	225	295	495	550	605	—	—
12	125	180	245	320	540	600	660	—	—

CHANNELIZING DEVICE SPACING (FEET)		
MPH	TAPER	TANGENT
50/55	40	80
35/45	30	60
25/30	20	40



BUFFER DATA												
BUFFER SPACE = B												
SPEED (MPH)	25	30	35	40	45	50	55	60	65	70		
LENGTH (feet)	—	—	—	—	170	220	280	335	415	—		
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*												
VEHICLE TYPE	TYPICAL VEHICLE LOADED WEIGHT (LBS)		POSTED SPEED (mph)		STATIONARY OPERATION (feet)		* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.					
4 YARD DUMP TRUCK	24,000		60 50-55 45		100 75 50							
2 TON CARGO TRUCK	15,000		60 50-55 45		150 100 75							
1 TON CARGO TRUCK	10,000		60 50-55 45		200 150 100							
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT												
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.												

down stream taper to show end of work area

G20-2a  
24"x30" B/W  
(TWO SIGNS)

END ROAD WORK

W20-1

W4-2(R)

W20-5(L)

SIGN LOCATION

SEQUENTIAL ARROW SIGN


TEMPORARY TRAFFIC CONTROL DEVICES

PROTECTIVE VEHICLE - RECOMMENDED

MINIMUM TAPER LENGTH = L (FEET)										
LANE WIDTH (feet)	25	30	35	40	45	50	55	60	65	70
10	105	150	205	270	450	500	550	—	—	—
11	115	165	225	295	495	550	605	660	—	—
12	125	180	245	320	540	600	660	720	—	—

SIGN SPACING = X (FEET)			
Rural Roads	45/60 MPH	500'±	
Urban Arterials	35/40 MPH	350'±	
Urban Streets	25/30 MPH	200'±	
Residential & Business Districts			
All signs are 48" X 48" black on orange unless otherwise designated			

CHANNELIZING DEVICE SPACING (FEET)			
MPH	TAPER	TANGENT	
50/60	40	80	
35/45	30	60	
25/30	20	40	



## GENERAL NOTES

1. FOR LONG-TERM PROJECTS, CONFLICTING PAVEMENT MARKINGS NO LONGER APPLICABLE SHALL BE REMOVED OR OBLITERATED AS SOON AS PRACTICABLE. TEMPORARY MARKINGS SHALL BE USED AS NECESSARY.
2. STEADY BURNING WARNING LIGHTS (TYPE C, MUTCD) SHOULD BE USED TO MARK CHANNELIZING DEVICES AT NIGHT AS NEEDED
3. IF THE LANE SHIFT IS SHORT AND HAS SHARP CURVES (30 MPH OR LESS) USE SIGN W1-3 IN LIEU OF SIGN W1-4.

LANE SHIFT / THREE LANE ROADWAY  
TCP 11

## ROLLING SLOWDOWN

### Traffic Control Plan (TCP) 12

A rolling slowdown is a legitimate form of traffic control commonly practiced by the WSP, contractors and highway maintenance people. Their use is valuable for emergency, or very short duration, closures (e.g. to pick debris from the roadway, to push a blocking disabled to the shoulder, or to pull power lines across the roadway). The traffic control vehicles form a moving blockade which reduces traffic speeds and creates a large gap in traffic, or clear area, allowing very short term work to be accomplished without totally stopping the traffic.

Other traditional forms of traffic control should be considered first. If the closure is to be a scheduled operation, then the Regional Traffic Office needs to be contacted to request a site specific, approved, Traffic Control Plan (TCP). The gap in traffic created by the rolling slowdown, and other traffic issues, would be addressed on an approved TCP. Also, use of WSP is encouraged whenever possible.

*In the event of debris in the roadway, a blocking disabled vehicle, or other emergency, the use of experience and resources at hand, along with sound judgment and common sense, will suffice in lieu of an approved, site specific, TCP. TCP 12 on page 28 has been designed to present the basic information for performing a safe and effective rolling slowdown.*

Equipment availability is a prime consideration. Before starting this operation, ensure there is at least one traffic control vehicle (with flashing amber lights) per lane to be slowed, and one vehicle to cover every point of access onto the 'rolling slowdown' segment of roadway. (Only during emergencies should less than one traffic control vehicle per lane be considered.) Truck mounted PCMS boards stating "Rolling Slowdown In Progress" are very helpful. **Be sure that every crew member participating is well briefed and knows what is needed from them. Good communications for this operation are essential!**


The traffic control vehicles leading the rolling slowdown must enter the roadway far enough upstream from the work operation site to allow a clear area in front of them to develop. The traffic control vehicles will work into position so that each lane is controlled. As in every other form of traffic control, sight distance is important, so that drivers are not surprised. While traveling at a fixed and reduced rate of speed, a gap in traffic must be created which is long enough to provide the estimated time needed for the work to be done.

A separate traffic control vehicle, "chaser vehicle", shall follow the slowest, or last, vehicle ahead of the blockade. When that last vehicle passes, the crew can begin the work operation.

All ramps and entrances to the roadway between the moving blockade and work operation must be temporarily closed using traffic control personnel. Each of those ramps must remain closed until the "all clear" signal is given by the crew doing the work, or, until the front of the moving blockade passes the closed on-ramp(s).

Radio communications between the work crew and the moving blockade are needed so the speed of the blockade can be adjusted, if necessary, to increase or decrease the closure time. Release traffic only after you have confirmation that all workers and their vehicles are clear of the roadway.

THIS PLAN DEPICTS THE MINIMUM REQUIREMENTS TO PERFORM AN EMERGENCY ROLLING SLOWDOWN. IF THE SLOWDOWN IS, OR CAN BE, A PLANNED EVENT, THEN A SITE SPECIFIC TRAFFIC CONTROL PLAN SHOULD BE DEVELOPED AND APPROVED BY THE REGION TRAFFIC OFFICE PRIOR TO THE OPERATION OCCURRING.



(SAMPLE MESSAGE)

TRUCK MOUNTED PCMS	
1	2
SLOW OR STOPPED VEHICLES	DO NOT PASS
1.5 SEC	1.5 SEC

## LEGEND



TRUCK MOUNTED ATTENUATOR

WARNING BEACON

TYPICAL (EMERGENCY)  
ROLLING SLOWDOWN  
TCP 12

## OPERATIONAL NOTES

1. ALL WORK VEHICLES SHALL USE WARNING BEACONS.
2. THE NUMBER OF VEHICLES SHOWN IS A MINIMUM. IF POSSIBLE USE ONE VEHICLE PER LANE DURING CLOSURE.
3. WSP SHALL BE NOTIFIED AND ON SITE WHEN AVAILABLE.
4. ALL ON-RAMP TRAFFIC SHALL BE STOPPED BY WSDOT VEHICLES.

## **MOBILE WORK ZONES**

### Traffic Control Plans (TCP's) 13 to 20



Mobile work zones are used for work activities that move along the road either intermittently or continuously. Frequent short stops, up to 15 minutes long, may be used for pothole patching, litter cleanup, herbicide spraying, lane marker replacement or other similar operations. Cones, truck mounted signs or Portable Changeable Message Signs (PCMS), warning lights and flaggers may be needed for these operations.

Mobile work zones also include slow moving operations where workers and equipment move along the road without stopping. Operations such as sweeping and paint striping are typical mobile operations. The warning signs move ahead with the work, usually mounted on a shadow vehicle. Truck mounted signs or PCMS, Truck Mounted Attenuator (TMA) and warning lights are some of the devices that may be used for moving operations. Messages for truck mounted PCMS's should conform to standard work messages whenever possible. Contact the Region Traffic Office Staff for assistance with selecting appropriate messages.

Mobile work zones are well suited to maintenance operations and can be an efficient way to accomplish many types of work, but due to the moving nature of these operations it is imperative that the crew is carefully coordinated. Careful consideration of traffic and roadway conditions as they relate to the specific operation must be done prior to starting work.

The following TCP's show typical examples of mobile work zones.

# TYPICAL FREEWAY APPLICATION (ACTUAL NUMBER OF LANES MAY VARY)



(SAMPLE MESSAGE)

PCMS			
1	2		
LEFT SHOULDER CLOSED	SLOW MOVING VEHICLES		
1.5 SEC	1.5 SEC		

W21-5  
48"x48"  
B/O

Field locate in advance of lane closure.  
(TRUCK MOUNTED OR TRAILER MOUNTED OPTIONAL)



PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*			
VEHICLE TYPE	VEHICLE WEIGHT (LBS)	STATIONARY	MOBILE
4 YARD DUMP TRUCK	24,000	100'	175'
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT			
* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.			
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.			

## OPERATIONAL NOTES

1. SHADOW VEHICLE #1, MOUNT SHOULDER CLOSURE SIGN ON BACK OF VEHICLE. DO NOT OBSCURE SEQUENTIAL ARROW PANEL. MAINTAIN 1000' TO 1500' OF SIGHT DISTANCE TO APPROACHING TRAFFIC (TMA RECOMMENDED).
2. PROTECTIVE VEHICLE #2, POSITION VEHICLE TO PROVIDE PROTECTION OF CREW. MAINTAIN MINIMUM ROLL AHEAD DISTANCE (TMA RECOMMENDED).
3. 2' MINIMUM CLEARANCE REQUIRED BETWEEN LANE EDGE AND WORK VEHICLE. OR ADJACENT LANE MUST BE CLOSED IF ADDITIONAL CLEARANCE IS REQUIRED OR IF WORK ACTIVITIES ADVERSELY INFLUENCE TRAFFIC.
4. CONTACT OLYMPIC RADIO AT 253-536-6089 OR SEATTLE RADIO AT 206-440-4490 OR INDIVIDUAL REGION RADIO PRIOR TO WORK BEGIN AND END.

## LEGEND

SEQUENTIAL ARROW PANEL - TYPE "B"  
(CAUTION MODE)



TRUCK MOUNTED ATTENUATOR



WARNING BEACON




MOBILE FREEWAY OPERATION  
LEFT SHOULDER CLOSED  
TCP 13




PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*			
VEHICLE TYPE	VEHICLE WEIGHT (LBS)	STATIONARY	MOBILE
4 YARD DUMP TRUCK	24,000	100'	175'
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT • VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5. TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.			

(SAMPLE MESSAGE) PCMS			
1	2	Field locate in	
LEFT LANE CLOSED	MERGE RIGHT	advance of lane closure.	
1.5 SEC	1.5 SEC	(TRUCK MOUNTED OR TRAILER MOUNTED OPTIONAL)	



### TYPICAL FREEWAY APPLICATION

(ACTUAL NUMBER OF LANES MAY VARY)



### OPERATIONAL NOTES

1. SHADOW VEHICLE #1, MOUNT LANE CLOSURE SIGN ON BACK OF VEHICLE. DO NOT OBSCURE SEQUENTIAL ARROW PANEL. MAINTAIN 1000' TO 1500' OF SIGHT DISTANCE TO APPROACHING TRAFFIC (TMA RECOMMENDED).
2. PROTECTIVE VEHICLE #2, POSITION VEHICLE TO PROVIDE PROTECTION OF CREW. MAINTAIN MINIMUM ROLL AHEAD DISTANCE (TMA RECOMMENDED).
3. 2' MINIMUM CLEARANCE REQUIRED BETWEEN LANE EDGE AND WORK VEHICLE. ADJACENT LANE MUST BE CLOSED IF ADDITIONAL CLEARANCE IS REQUIRED OR IF WORK ACTIVITIES ADVERSELY INFLUENCE TRAFFIC.
4. CONTACT OLYMPIC RADIO AT 253-536-6089 OR SEATTLE RADIO AT 206-440-4490 OR THE INDIVIDUAL REGION RADIO PRIOR TO WORK BEGIN AND END.

### LEGEND

SEQUENTIAL ARROW PANEL - TYPE "B" MIN.



TRUCK MOUNTED ATTENUATOR

WARNING BEACON


### MOBILE FREEWAY OPERATION

#### LEFT LANE CLOSURE

#### TCP 14

PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*			
VEHICLE TYPE	VEHICLE WEIGHT (LBS)	STATIONARY	MOBILE
4 YARD DUMP TRUCK	24,000	100'	175'
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT • VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5. TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.			

**TYPICAL FREEWAY APPLICATION**  
(ACTUAL NUMBER OF LANES MAY VARY)



**OPERATIONAL NOTES**

1. SHADOW VEHICLE #1, MOUNT LANE CLOSURE SIGN ON BACK OF VEHICLE. DO NOT OBSCURE SEQUENTIAL ARROW PANEL. MAINTAIN 1000' TO 1500' OF SIGHT DISTANCE TO APPROACHING TRAFFIC (TMA RECOMMENDED).
2. PROTECTIVE VEHICLE #2, POSITION VEHICLE TO PROVIDE PROTECTION OF CREW. MAINTAIN MINIMUM ROLL AHEAD DISTANCE (TMA RECOMMENDED).
3. 2' MINIMUM CLEARANCE REQUIRED BETWEEN LANE EDGE AND WORK VEHICLE. ADJACENT LANE MUST BE CLOSED IF ADDITIONAL CLEARANCE IS REQUIRED OR IF WORK ACTIVITIES ADVERSELY INFLUENCE TRAFFIC.
4. CONTACT OLYMPIC RADIO AT 253-536-6089 OR SEATTLE RADIO AT 206-440-4490 OR THE INDIVIDUAL REGION RADIO PRIOR TO WORK BEGIN AND END.

**LEGEND**

◁▷▷ SEQUENTIAL ARROW PANEL - TYPE "B" MIN.

TMA TRUCK MOUNTED ATTENUATOR


◊ WARNING BEACON

MOBILE FREEWAY OPERATION  
MIDDLE LANE WORK AREA  
TCP 15

PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*			
VEHICLE TYPE	VEHICLE WEIGHT (LBS)	STATIONARY	MOBILE
4 YARD DUMP TRUCK	24,000	100'	175'
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT			
• VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.			
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.			

R4-1  
36"X48"  
B/W  
(OPTIONAL)  
MOUNT ON  
PROTECTIVE  
VEHICLE

## 2 LANE HIGHWAY TYPICAL OPERATION



### OPERATIONAL NOTES

1. WORK VEHICLE AND PROTECTIVE VEHICLE SHALL USE WARNING BEACONS.
2. PROTECTIVE VEHICLE SHALL MAINTAIN 500'-1000' OF SIGHT DISTANCE TO APPROACHING TRAFFIC.
3. CONTACT REGION TRAFFIC OFFICE STAFF FOR ASSISTANCE WITH SPECIFIC IN LANE OPERATIONS SUCH AS STRIPING, FOG SEAL, ETC. THAT REQUIRE ADDITIONAL PLAN DETAILS.
4. THIS PLAN MAY BE IMPLEMENTED ON MULTI-LANE HIGHWAYS WITH LESS THAN 10,000 ADT.

### LEGEND



 SEQUENTIAL ARROW PANEL - TYPE "B" (CAUTION MODE)

 TRUCK MOUNTED ATTENUATOR

 WARNING BEACON

MOBILE OPERATION  
LANE CLOSURE  
TCP 16




PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*			
VEHICLE TYPE	VEHICLE WEIGHT (LBS)	STATIONARY	MOBILE
4 YARD DUMP TRUCK	24,000	100'	175'
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT			
* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.			
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.			



### OPERATIONAL NOTES

1. WORK VEHICLE AND SHADOW/PROTECTIVE VEHICLE SHALL USE WARNING BEACONS.
2. SHADOW/PROTECTIVE VEHICLE RECOMMENDED- SHALL MAINTAIN 500' - 1000' OF SIGHT DISTANCE TO APPROACHING TRAFFIC.
3. THIS PLAN MAY BE IMPLEMENTED ON MULTI-LANE HIGHWAYS WITH LESS THAN 10,000 ADT.


### LEGEND

-  SEQUENTIAL ARROW PANEL - TYPE "B"  
(CAUTION MODE)
-  TRUCK MOUNTED ATTENUATOR
-  WARNING BEACON

MOBILE OPERATION  
SHOULDER CLOSURE  
TCP 17

SIGHT DISTANCE DATA									
MIN. STOPPING SIGHT DIST. = S									
SPEED LIMIT MPH	25	30	35	40	45	50	55	60	65
DISTANCE FEET	75'	100'	150'	225'	300'	375'	450'	550'	650'

DISTANCES SHOWN ARE MINIMUMS, USE ADDITIONAL DISTANCE WHEN POSSIBLE.




## LEGEND

- |   |  |
|---|--|
|  | WORK VEHICLE WITH FLASHING AMBER WARNING BEACON  |
|  | SHADOW VEHICLE WITH FLASHING AMBER WARNING BEACON<br>(TMA RECOMMENDED, BUT NOT REQUIRED) |

## GENERAL NOTES

1. DAYLIGHT HOURS ONLY.
2. RADIO CONTACT BETWEEN WORK CREW AND SHADOW VEHICLE RECOMMENDED.

MOBILE SHOULDER OPERATION WITH LANE ENCROACHMENT  
(RECOMMENDED FOR RURAL ROADWAYS WITH LESS THAN 10,000 ADT)  
TCP 18



#### OPERATIONAL NOTES


1. WORK VEHICLES SHALL USE WARNING BEACONS.
2. REFER TO MAINTENANCE MANUAL CHAPTER 8 SNOW AND ICE CONTROL, FOR OPERATIONAL REQUIREMENTS.

TANDEM SNOW PLOW OPERATIONS  
MULTI-LANE FACILITIES  
TCP 19

(SAMPLE MESSAGE)

PCMS		
1	2	
AVALANCHE CONTROL TO STOP AHEAD		
1.5 SEC	1.5 SEC	1.5 SEC

FIELD LOCATE 1 MILE (++) IN  
ADVANCE OF LANE CLOSURE



#### OPERATIONAL NOTES

1. WORK VEHICLES SHALL USE WARNING BEACONS.
2. REFER TO MAINTENANCE MANUAL CHAPTER 8 SNOW AND ICE CONTROL, FOR OPERATIONAL REQUIREMENTS.
3. PCMS RECOMMENDED.
4. W.S.P. ASSISTANCE RECOMMENDED.

AVALANCHE CONTROL OPERATION  
TOTAL ROAD CLOSURE  
TCP 20





## INTERSECTION OPERATIONS

### Traffic Control Plans (TCP's) 21 to 23

Traffic control at intersections requires specific attention because traffic is usually inbound from all directions. The traffic on all approaches needs to be given the same advance warning with the messages on the warning signs to be appropriate for the situation ahead of them. When an intersection is to be controlled by flaggers, always be sure that an existing signal does not give the drivers a conflicting message. For example, don't stop traffic when the signal is green. It is always best to turn off the signal during flagging operations.


The traffic control plans in this section show a pair of rather complex intersections. In general, use these examples as guidelines and prepare specific traffic control plans for the intersections you will be working in, showing the lanes and turning movements as they appear on the roadway.

BUFFER DATA															
BUFFER SPACE = B															
SPEED (MPH)	25	30	35	40	45	50	55	60	65	* VALUES MAY BE REDUCED IN ACCORDANCE WITH TMA USE, SEE PAGE 5.					
LENGTH (feet)	55	85	120	170	220	280	335	415	485						
PROTECTIVE VEHICLE ROLL AHEAD DISTANCE = R*															
TYPICAL LOADED PROTECTIVE VEHICLE	TYPICAL VEHICLE LOADED WEIGHT (LBS)		POSTED SPEED (mph)		STATIONARY OPERATION (feet)										
4 YARD DUMP TRUCK	24,000		60-65 50-55 45		100 75 50										
2 TON CARGO TRUCK	15,000		60-65 50-55 45		150 100 75										
1 TON CARGO TRUCK	10,000		60-65 50-55 45		200 150 100										
ROLL AHEAD STOPPING DISTANCE ASSUMES DRY PAVEMENT															
TMA - RECOMMENDED, SEE TABLE FOR APPLICATION PRIORITIES, PAGE 6.															

MINIMUM TAPER LENGTH = L (FEET)										
LANE WIDTH (feet)	Posted Speed (mph)									
	25	30	35	40	45	50	55	60	65	780
10	105	150	205	270	450	500	550	-	-	-
11	115	165	225	295	495	550	605	660	-	-
12	125	180	245	320	540	600	660	720	780	-

SIGN SPACING = X (FEET)			
Rural Roads	45/65 MPH	500+/-	
Urban Arterials	35/40 MPH	350+/-	
Urban Streets Residential & Business Districts	25/30 MPH	200+/-	
All signs are 48" X 48" black on orange unless otherwise designated			

CHANNELIZING DEVICE SPACING (FEET)			
MPH	TAPER	TANGENT	
50/65	40	80	
35/45	30	60	
25/30	20	40	




### LEGEND


- ▮ SIGN LOCATION
- ▮ FLAGGING STATION
- ▮ TEMPORARY TRAFFIC CONTROL DEVICES
- ▮ PROTECTIVE VEHICLE - RECOMMENDED

### GENERAL NOTES

1. PROTECTIVE VEHICLE RECOMMENDED - MAY BE A WORK VEHICLE.
2. EXTEND TAPER ACROSS SHOULDER.
3. THIS PLAN MAY NEED TO BE ADJUSTED TO FIT SITE CONDITIONS. REFER TO THE MANUAL ON UNIFORM TRAFFIC CONTROL DEVICES (MUTCD) PART VI OR SEE REGION TRAFFIC OFFICE STAFF.
4. IF EXISTING SIGNAL IS PRESENT, SIGNAL SHALL BE SET TO "RED FLASH MODE" OR TURN OFF DURING FLAGGING OPERATIONS.
5. IF THE LANE SHIFT IS SHORT AND HAS SHARP CURVES (30 MPH OR LESS) USE SIGN W1-3 IN LIEU OF SIGN W1-4.



\* INSTALL ON TYPE II BARRICADES THROUGHOUT THE WORK AREA 24 HOURS PRIOR TO IMPLEMENTING TRAFFIC CONTROL. PRIOR NOTIFICATION OF POLICE DEPARTMENT REQUIRED.



# LEGEND

△ SIGN LOCATION

□ □ □ TEMPORARY TRAFFIC CONTROL DEVICES

▤ TYPE II BARRICADE

## GENERAL NOTES

### INTERSECTION PEDESTRIAN TRAFFIC CONTROL TCP 23

1. CONTROLS SHOWN ARE FOR PEDESTRIAN TRAFFIC ONLY.
2. USE WARNING LIGHTS ON BARRICADES.

## **EMERGENCY OPERATIONS**

### **Traffic Control Plan (TCP) 24**

The immediate response to an emergency situation must, by necessity, make use of whatever devices and equipment are available. Assistance from the Washington State Patrol and WSDOT Incident Response Team may be appropriate. The use of flares is allowed unless flammable material is present.

Implement the appropriate traffic control plan (lane closure, etc.) if the situation is expected to last longer than 60 minutes. This allows for short duration operation, while traffic control assistance arrives.

**Response to an emergency situation is inherently more dangerous than planned situations. Do not expose yourself to a life threatening situation. Wait for assistance and protect yourself at all times.**

ONE LANE ROAD AHEAD

W20-4

48" X 48"

B/O

WATER OVER ROADWAY

W8-1501

48" X 48"

B/O

ROAD CLOSED TO THRU TRAFFIC

R11-4

60" X 30"

B/W

YIELD

R1-2

36" X 36"

R/W

BUMP

W8-1

48" X 48"


B/O

NO SHOULDER

W8-1801

48" X 48"

B/O



## **SPECIAL DETAILS AND TCP REFERENCE CHART**


### **Traffic Control Details (TCD's) 1 to 4**

The following details show the placement of certain signs, channelizing devices, and pavement markings which are difficult to show on other traffic control plans. A detail is also included as a guideline for signing a chip seal operation (TCD 4) and this includes a reduced speed limit. Be sure to include specific warning signs along with any reduction in the legal speed so the drivers have proper expectancy and know why they are being asked to slow down.


The TCP Reference Chart (TCD 3) serves as a handy checklist to see which traffic control plans might be useful for particular kinds of operations.

WORK OPERATIONS THAT REMOVE OR OBSCURE EXISTING PAVEMENT MARKINGS MUST PROVIDE FOR TEMPORARY MARKINGS UNTIL THE PERMANENT MARKINGS ARE APPLIED. PERMANENT MARKINGS SHALL BE INSTALLED WITHIN 2 WEEKS. THE DETAILS BELOW SHOW SOME COMMON APPLICATIONS. CONTACT THE REGION TRAFFIC OFFICE STAFF FOR ASSISTANCE WITH MORE COMPLEX SITUATIONS.

## MULTI-LANE ROADWAYS



## 2 LANE ROADWAYS



TEMPORARY EDGE STRIPES ARE NOT REQUIRED FOR THE ABOVE SITUATIONS. TEMPORARY ROADSIDE DELINEATION WITH CHANNELIZATION DEVICES SHOULD BE CONSIDERED, BUT ARE OPTIONAL. DO NOT USE A "SKIP" PATTERN OF TAPE STRIPE OR T.R.P.M.'S TO SIMULATE AN EDGE STRIPE.


CHANNELIZATION DEVICE SPACING - TANGENT 200' +-  
CURVES 100' +-  
TAPERS 1/2 L

T.R.P.M. = TEMPORARY RAISED PAVEMENT MARKER




## WARNING SIGNS


LOCATE AS NEEDED FOR SITE CONDITIONS  
TO SUPPLEMENT WARNING SIGNS



W21-801  
48"X48"  
B/O



W8-1801  
48"X48"  
B/O



### OPERATIONAL NOTES

1. SHOULDER EXCAVATION SHALL BE LIMITED TO ONE SIDE OF ROADWAY AT A TIME.

SHOULDER WORK AREA PROTECTION  
NON-WORKING HOURS  
TCD 2

# TCP REFERENCE CHART

## FOR SELECTED WORK OPERATIONS

WORK OPERATION	STATIONARY AND SHORT DURATION	MOBILE	SUGGESTED TRAFFIC CONTROL PLAN*
Re-lamp		X	13 & 17
Light Standard Repair	X		2, 4, & 5
Rewire	X		2, 4, & 5
VACTOR		X	13 & 17
Sweeping		X	13 & 17
Striping		X	14, 15 & 16
RPM's		X	14, 15 & 16
Sign Installation	X	X	4, 5, & 14
Pot Hole Repair	X	X	1, 2, & 14
Paving / Chip Seal	X		1, 2, & TCD 4
Bridge Inspection	X	X	2, 13, & 14
EMERGENCY	X	X	24

### LEGEND

X=Applies

### Definitions:

Stationary----- Operation longer than 1 hour.  
 Short Duration----- Operations of 60 minutes or less.  
 Mobile----- Frequent short stops up to 15 minutes or continuously slow moving.  
 Emergency----- Mobile to Stationary, but unexpected (Call for traffic control if work is expected to last longer than 60 minutes. This allows for 60 minutes as a short duration operation while traffic control assistance arrives).

\* Others may apply, or a site specific plan may be appropriate.

POSTED SPEED	DECELERATION LENGTH NEEDED TO REACH LISTED ADVISORY SPEED - MPH = D				
	10	20	30	40	50
65	650	625	575	500	375
60	575	550	500	400	300
55	500	475	400	300	--
50	425	400	325	225	--
45	350	300	250	--	--
40	275	250	175	--	--
35	200	175	--	--	--
30	150	100	--	--	--

SIGN SPACING = X (FEET)		
Rural Roads	45/65 MPH	500'±
Urban Arterials	35/40 MPH	350'±
Rural Roads	25/30 MPH	200'±
Urban Streets Residential & Business Districts		
All signs are 48" X 48" black on orange unless otherwise designated		

## FOR PROJECT INFORMATION

# 444-5555

WASHINGTON STATE  
DEPARTMENT OF TRANSPORTATION



R4-1  
36"X48"  
B/W

G24-501  
48"X36"  
B/O

INSTALL AS REQUIRED THROUGHOUT  
PROJECT LIMITS

**CHIP SEAL PROJECT**  
NEXT X MILES  
**AUG XX TO AUG XX**

OR

PCMS	
1	2
CHIP SEAL PROJECT TO AUG XX	BEGINS AUG XX
1.5 SEC	1.5 SEC


SP-1  
48"X60"  
B/O

(SAMPLE MESSAGE)

\* CONTINUE SIGNS AS NEEDED BASED ON REQUIRED HAZARD WARNING AS SHOWN ON THE APPROPRIATE TCP.


### LEGEND

• SIGN LOCATION



WORK AREA LIMITS

## TYPICAL SPEEDZONE DETAIL CHIP SEAL PROJECTS TCD 4



### GENERAL NOTES

1. REFER TO LANE CLOSURE PLANS FOR LANE CLOSURE DETAILS.
2. THE TABLES PROVIDED ARE AN AID FOR DETERMINING SIGN LOCATIONS. THE VALUES CONTAINED IN THE TABLES SHOULD BE CONSIDERED MINIMUMS AND APPLIED IN THE FIELD WITH RESPECT TO SITE CONDITIONS.
3. CONTACT THE REGION TRAFFIC ENGINEER FOR ADDITIONAL GUIDANCE IF NEEDED DUE TO UNUSUAL SITE CONDITIONS OR TRAFFIC CHARACTERISTICS.
4. REGULATORY SPEED LIMIT SIGNING IS NOT A SUBSTITUTE FOR WORK ZONE SIGNING REQUIRED TO WARN MOTORISTS.
5. SPEED ZONE SIGNING SHALL ONLY REMAIN IN PLACE FOR AS LONG AS THE REDUCED SPEED CONDITION APPLIES.
6. SPEED LIMIT REDUCTION SHALL CONFORM TO RCW 47.48.020.
7. CONTACT THE REGION TRAFFIC OFFICE STAFF FOR SPECIAL SIGN ORDERS, SPEED REDUCTION NOTICES, ETC.

PLACE SIGN TO INDICATE LEGAL TO RESUME SPEED

ALL SPEED REDUCTIONS MUST BE APPROVED BY THE REGION TRAFFIC ENGINEER PRIOR TO IMPLEMENTATION.



M 22-24

**Highway Engineering**  
**Field Formulas**



**Washington State**  
**Department of Transportation**

## **Metric (SI) or US Units**

Unless otherwise stated the formulas shown in this manual can be used with any units. The user is cautioned not to mix units within a formula. Convert all variables to one unit system prior to using these formulas.

## **Significant Digits**

Final answers from computations should be rounded off to the number of decimal places justified by the data. The answer can be no more accurate than the least accurate number in the data. Of course, rounding should be done on final calculations only. It should not be done on interim results.

Persons with disabilities may request this information be prepared in alternate forms by calling collect (360) 664-9009. Deaf and hearing impaired people call 1-800-833-6388 (TTY Relay Service).

1998  
Engineering Publications  
Transportation Building  
Olympia, WA 98504  
360-705-7430

## CONTENTS

Nomenclature for Circular Curves .....	2
Circular Curve Equations .....	4
Simple Circular Curve .....	5
Degrees of Curvature to Various Radii .....	6
Nomenclature for Vertical Curves .....	7
Vertical Curve Equations .....	8
Nomenclature for Nonsymmetrical Curves .....	10
Nonsymmetrical Vertical Curve Equations .....	11
Determining Radii of Sharp Curves .....	12
Dist. from Fin. Shld. to Subgrade Shld. ....	13
Areas of Plane Figures .....	14
Surfaces and Volumes of Solids .....	18
Trigonometric Functions for all Quadrants .....	23
Trigonometric Functions .....	24
Right Triangle .....	25
Oblique Triangle .....	26
Conversion Factors .....	28
Metric Conversion Factors .....	30
Land Surveying Conversion Table .....	31
Steel Tape Temperature Corrections .....	31
Temperature Conversion .....	31
Less Common Conversion Factors .....	32
Water Constants .....	32
Cement Constants .....	32
Multiplication Factor Table .....	33
Recommended Pronunciations .....	33
Reinforcing Steel .....	34

## **Nomenclature For Circular Curves**

POT	Point On Tangent outside the effect of any curve
POC	Point On a circular Curve
POST	Point On a Semi-Tangent (within the limits of a curve)
PI	Point of Intersection of a back tangent and forward tangent
PC	Point of Curvature - Point of change from back tangent to circular curve
PT	Point of Tangency - Point of change from circular curve to forward tangent
PCC	Point of Compound Curvature - Point common to two curves in the same direction with different radii
PRC	Point of Reverse Curve - Point common to two curves in opposite directions and with the same or different radii
L	Total Length of any circular curve measured along its arc
$L_c$	Length between any two points on a circular curve
R	Radius of a circular curve
$\Delta$	Total intersection (or central) angle between back and forward tangents




## **Nomenclature For Circular Curves (Cont.)**

DC	Deflection angle for full circular curve measured from tangent at PC or PT
dc	Deflection angle required from tangent to a circular curve to any other point on a circular curve
C	Total Chord length, or long chord, for a circular curve
C'	Chord length between any two points on a circular curve
T	Distance along semi-Tangent from the point of intersection of the back and forward tangents to the origin of curvature (From the PI to the PC or PT)
tx	Distance along semi-tangent from the PC (or PT) to the perpendicular offset to any point on a circular curve. (Abscissa of any point on a circular curve referred to the beginning of curvature as origin and semi-tangent as axis)
ty	The perpendicular offset, or ordinate, from the semi-tangent to a point on a circular curve
E	External distance (radial distance) from PI to midpoint on a simple circular curve

## Circular Curve Equations


Equations	Units
$R = \frac{180^\circ}{\pi} \cdot \frac{L}{\Delta}$	m or ft.
$\Delta = \frac{180^\circ}{\pi} \cdot \frac{L}{R}$	degree
$L = \frac{\pi}{180} \cdot R\Delta$	m or ft.
$T = R \tan \frac{\Delta}{2}$	m or ft.
$E = \frac{R}{\cos \frac{\Delta}{2}} - R$	m or ft.
$C = 2R \sin \frac{\Delta}{2}, \text{ or } = 2R \sin DC$	m or ft.
$MO = R \left( 1 - \cos \frac{\Delta}{2} \right)$	m or ft.
$DC = \frac{\Delta}{2}$	degree
$dc = \frac{L_c}{L} \left( \frac{\Delta}{2} \right)$	degree
$C' = 2R \sin(dc)$	m or ft.
$C = 2R \sin(DC)$	m or ft.
$tx = R \sin(2dc)$	m or ft.
$ty = R[1 - \cos(2dc)]$	m or ft.

## Simple Circular Curve



Constant for  $\pi = 3.14159265$

## Degree of Curvature for Various Lengths of Radii




Exact for Arc Definition

$$D = \frac{100 \left( \frac{180}{\pi} \right)}{R} = \frac{18000}{\pi R}$$

Where D is Degree of Curvature

## Length of Radii for Various Degrees of Curvature




$$R = \frac{100 \left( \frac{180}{\pi} \right)}{D} = \frac{18000}{\pi D}$$

Where R is Radius Length

## Nomenclature For Vertical Curves

<b><math>G_1</math> &amp; <math>G_2</math></b>	Tangent Grade in percent
<b>A</b>	The absolute of the Algebraic difference in grades in percent
<b>BVC</b>	Beginning of Vertical Curve
<b>EVC</b>	End of Vertical Curve
<b>VPI</b>	Vertical Point of Intersection
<b>L</b>	Length of vertical curve
<b>D</b>	Horizontal distance to any point on the curve from BVC or EVC
<b>E</b>	Vertical distance from VPI to curve
<b>e</b>	Vertical distance from any point on the curve to the tangent grade
<b>K</b>	Distance required to achieve a 1 percent change in grade
<b><math>L_1</math></b>	Length of a vertical curve which will pass through a given point
<b><math>D_0</math></b>	Distance from the BVC to the lowest or highest point on curve
<b>X</b>	Horizontal distance from P' to VPI
<b>H</b>	A point on tangent grade $G_1$ to vertical position of point P'
<b>P and P'</b>	Points on tangent grades

## Symmetrical Vertical Curve Equations



$$A = (G_2) - (G_1)$$

$$E = \frac{AL}{800}$$

$$E = \frac{1}{2} \left( \frac{\text{Elev. BVC} + \text{Elev. EVC}}{2} - \text{Elev. VPI} \right)$$


$$e = \frac{4ED^2}{L^2}$$

Notes: All equations use units of length (not stations or increments)

The variable **A** is expressed as an absolute in percent (%)

Example: If  $G_1 = +4\%$  and  $G_2 = -2\%$   
Then **A** = 6

## Symmetrical Vertical Curve Equations (cont.)



$$e = \frac{AD^2}{200L}$$

$$L_1 = \frac{2(AX + 200e + 20\sqrt{AXe + 100e^2})}{A}$$

$$D_0 = |G_1| \frac{L}{A}$$

$$X = \frac{100(\text{Elev}H - \text{Elev}P')}{A}$$


$$K = \frac{L}{A}$$

## Nomenclature For Nonsymmetrical Vertical Curves

<b><math>G_1</math> &amp; <math>G_2</math></b>	Tangent Grades in percent
<b>A</b>	The absolute of the Algebraic difference in grades in percent
<b>BVC</b>	Beginning of Vertical Curve
<b>EVC</b>	End of Vertical Curve
<b>VPI</b>	Vertical Point of Intersection
<b><math>l_1</math></b>	Length of first section of vertical curve
<b><math>l_2</math></b>	Length of second section of vertical curve
<b>L</b>	Length of vertical curve
<b><math>D_1</math></b>	Horizontal distance to any point on the curve from BVC towards the VPI
<b><math>D_2</math></b>	Horizontal distance to any point on the curve from EVC towards the VPI
<b><math>e_1</math></b>	Vertical distance from any point on the curve to the tangent grade between BVC and VPI
<b><math>e_2</math></b>	Vertical distance from any point on the curve to the tangent grade between EVC and VPI
<b>E</b>	Vertical distance from VPI to curve



## Nonsymmetrical Vertical Curve Equations



$$A = (G_2) - (G_1)$$


$$L = l_1 + l_2$$

$$E = \frac{l_1 l_2}{200(l_1 + l_2)} A$$

$$e_1 = m \left\{ \frac{D_1}{l_1} \right\}^2$$

$$e_2 = m \left\{ \frac{D_2}{l_2} \right\}^2$$

## Determining Radii of Sharp Curves by Field Measurements



$$R = \frac{BC^2}{2BD} + \frac{BD}{2}$$
$$BC = \frac{AC}{2}$$

Note: Points A and C may be any two points on the curve

### Example:

Measure the chord length from A to C


$$AC = 18.4 \text{ then } BC = 9.2$$

Measure the middle ordinate length B to D

$$BD = 3.5$$

$$R = \frac{9.2^2}{7.0} + \frac{3.5}{2} = 13.8$$

## Distance From Finished Shld. to Subgrade Shld. and Slope Equivalents



$$\text{Equation: } x = \frac{100B}{A}$$

**A** = Algebraic difference in % between shld. slope and subgrade slope

**B** = Depth of surfacing at finished shoulder

**x** = Distance from finished shld. to subgrade shld.

Shoulder Slope	Equivalent Rate of Grade	Equivalent Vertical Angle
1:1.5	66.67%	33°41'24"
1:1.75	57.14%	29°44'42"
1:2	50.00%	26°33'54"
1:2.5	40.00%	21°48'05"
1:3	33.33%	18°26'06"
1:4	25.00%	14°02'10"
1:5	20.00%	11°18'36"
1:6	16.67%	9°27'44"
1:8	12.50%	7°07'30"
1:10	10.00%	5°42'38"

Subgrade Slope	Equivalent Rate of Grade	Equivalent Vertical Angle
.020 / 1	2.00%	1°08'45"
.025 / 1	2.50%	1°25'56"
.030 / 1	3.00%	1°43'06"
.035 / 1	3.50%	2°00'16"
.040 / 1	4.00%	2°17'26"
.050 / 1	5.00%	2°51'45"

## Areas of Plane Figures

### Nomenclature

**A** = Area


**h** = Height

**R** = Radius

**P** = Perimeter

---

### Triangle




$$A = \frac{bh}{2}$$

$$P = a + b + c$$

---

### Circle




$$A = \pi R^2$$

$$P = 2\pi R$$

---


### Ellipse



$$A = \pi ab$$

## Areas of Plane Figures


**Segment**



$$A = \pi R^2 \frac{\Delta}{360^\circ} - \frac{R^2 \sin \Delta}{2}$$


---

**Sector**




$$A = \pi R^2 \frac{\Delta}{360^\circ}$$

$$P = 2R + \frac{\Delta}{360^\circ} (2\pi R)$$


---

**Fillet**




$$A = RT - \left( \frac{\Delta}{360^\circ} \right) \pi R^2$$

$$\text{When: } \Delta = 90^\circ, A = 0.2146R^2$$


---

## Areas of Plane Figures

### Parallelogram




$$A = bh$$

$$A = ah'$$


$$P = 2(a + b)$$

### Trapezoid



$$A = \frac{(a + b)h}{2}$$


### Polygon



Divide into triangles  
 $A = \text{Sum of all triangles}$

## Areas of Plane Figures


### Annulus (Circular Ring)



$$A = \frac{\pi}{4} (D^2 - d^2)$$


---

### Irregular Figure



$$A = L \left( \frac{a+j}{2} + b + c + d + e + f + g + h + i \right)$$



---

## Surfaces/Volumes of Solids


### Nomenclature

- S** Lateral surface area  
**V** Volume  
**A** Area of section perpendicular to sides  
**B** Area of base  
**P** Perimeter of base  
**P<sub>A</sub>** Perimeter of section perpendicular to its sides  
**R** Radius of sphere or circle  
**L** Slant height or lateral length  
**H** Perpendicular Height  
**C** Circumference of circle or sphere
- 

### Parallelepiped




### Pyramid or Cone Right or Regular





## Surfaces\Volumes of Solids


**Pyramid or Cone, Right or Oblique, Regular or Irregular**



$$V = \frac{1}{3}BH$$

---

**Prism: Right or Oblique, Regular or Irregular**




$$S = PH = P_A L$$

$$V = BH = AL$$

---

**Cylinder: Right or Oblique, Circular or Elliptic**




$$S = PH = P_A L$$

$$V = BH = AL$$

## Surfaces/Volumes of Solids


### Frustum of any Prism or Cylinder



$$V = BH$$

$$V = \frac{1}{2}A(L_2 + L_1)$$


### Frustum of Pyramid or Cone Right and Regular, Parallel Ends



$$S = \frac{1}{2}L(P + p) \quad V = \frac{1}{3}H(B + b + \sqrt{Bb})$$

$p$  = perimeter of top       $b$  = area of top

### Frustum of any Pyramid or Cone, with Parallel Ends




$$V = \frac{1}{3}H(B + b + \sqrt{Bb})$$

$b$  = area of top

## Surfaces/Volumes of Solids


### Sphere



$$S = 4\pi R^2 \quad V = \frac{4}{3}\pi R^3$$


---


### Spherical Sector



$$S = \frac{1}{2}\pi R(4H + C) \quad V = \frac{2}{3}\pi R^2 H$$


---

### Spherical Segment




$$S = 2\pi R H = \frac{1}{4}\pi(4H^2 + C^2)$$

$$V = \frac{1}{3}\pi H^2(3R - H)$$


---

## Surfaces\Volumes of Solids


### Spherical Zone



$$S = 2\pi RH$$

$$V = \frac{1}{24}\pi H(3C_1^2 + 3C^2 + 4H^2)$$


### Circular Ring



$$S = 4\pi^2 Rr$$

$$V = 2\pi^2 Rr^2$$

### Prismoidal Formula




$$V = \frac{H}{6}(B + b + 4M)$$

**M** = Area of section parallel to bases,  
Midway between them

**b** = area of top


## Signs of Trigonometric Functions for All Quadrants



### Note:


When using a calculator to compute trigonometric functions from North Azimuths, the correct sign will be displayed

## Trigonometric Functions




<b>Sine</b>	$\sin \theta = \frac{y}{r} = \frac{\text{opposite}}{\text{hypotenuse}}$
<b>Cosine</b>	$\cos \theta = \frac{x}{r} = \frac{\text{adjacent}}{\text{hypotenuse}}$
<b>Tangent</b>	$\tan \theta = \frac{y}{x} = \frac{\text{opposite}}{\text{adjacent}}$
<b>Cotangent</b>	$\cot \theta = \frac{x}{y} = \frac{\text{adjacent}}{\text{opposite}}$
<b>Secant</b>	$\sec \theta = \frac{r}{x} = \frac{\text{hypotenuse}}{\text{adjacent}}$
<b>Cosecant</b>	$\csc \theta = \frac{r}{y} = \frac{\text{hypotenuse}}{\text{opposite}}$
<b>Reciprocal Relations</b>	$\sin \theta = \frac{1}{\csc}$ $\tan \theta = \frac{1}{\cot \theta}$ $\cos \theta = \frac{1}{\sec}$
<b>Rectangular</b>	$X = r \cdot \cos \theta$ $y = r \cdot \sin \theta$
<b>Polar</b>	$r = \sqrt{x^2 + y^2}$ $\theta = \arctan \frac{y}{x}$

## Right Triangles



A+B+C=180 <sup>0</sup>		K=Area	
Pythagorean Theorem		a <sup>2</sup> + b <sup>2</sup> = c <sup>2</sup>	
A and B are complementary angles			
sin A = cos B		tan A = cot B	
cos A = sin B		cot A = tan B	
		sec A = csc B	
		csc A = sec B	
Given	To Find	Equation	
a, c	A, B, b, K	sin A = $\frac{a}{c}$ cos B = $\frac{a}{c}$ b = $\sqrt{c^2 - a^2}$ K = $\frac{a}{2}\sqrt{c^2 - a^2}$	
a, b	A, B, c, K	tan A = $\frac{a}{b}$ tan B = $\frac{b}{a}$ c = $\sqrt{a^2 + b^2}$ K = $\frac{ab}{2}$	
A, a	B, b, c, K	B = 90 <sup>0</sup> - A      b = a · cot A c = $\frac{a}{\sin A}$ k = $\frac{a^2 \cdot \cot A}{2}$	
A, b	B, a, c, K	B = 90 <sup>0</sup> - A      a = b · tan A c = $\frac{b}{\cos A}$ K = $\frac{b^2 \cdot \tan A}{2}$	
A, c	B, a, b, K	B = 90 <sup>0</sup> - A      a = c · sin A b = c · cos A      K = $\frac{c^2 \cdot \sin 2A}{4}$	

## Oblique Triangles



Law of Sines		$\frac{a}{\sin A} = \frac{b}{\sin B} = \frac{c}{\sin C}$
Law of Cosines		$a^2 = b^2 + c^2 - 2bc \cdot \cos A$ $b^2 = a^2 + c^2 - 2ac \cdot \cos B$ $c^2 = a^2 + b^2 - 2ab \cdot \cos C$
Sum of Angles		$A + B + C = 180^\circ$
K = Area		$s = \frac{a + b + c}{2}$
Given	To Find	Equation
a, b, c	A	$\sin \frac{A}{2} = \sqrt{\frac{(s-b)(s-c)}{bc}}$ $\cos \frac{A}{2} = \sqrt{\frac{s(s-a)}{bc}}$ $\tan \frac{A}{2} = \sqrt{\frac{(s-b)(s-c)}{s(s-a)}}$



## Oblique Triangles

Given	To Find	Equation
a, b, c	B	$\sin \frac{B}{2} = \sqrt{\frac{(s-a)(s-c)}{ac}}$ $\cos \frac{B}{2} = \sqrt{\frac{s(s-b)}{ac}}$ $\tan \frac{B}{2} = \sqrt{\frac{(s-a)(s-c)}{s(s-b)}}$
a, b, c	C	$\sin \frac{C}{2} = \sqrt{\frac{(s-a)(s-b)}{ab}}$ $\cos \frac{C}{2} = \sqrt{\frac{s(s-c)}{ab}}$ $\tan \frac{C}{2} = \sqrt{\frac{(s-a)(s-b)}{s(s-c)}}$
a, b, c	K	$K = \sqrt{s(s-a)(s-b)(s-c)}$
a, A, B	b, c	$b = \frac{a \cdot \sin B}{\sin A} \quad c = \frac{a \cdot \sin(A+B)}{\sin A}$
a, A, B	K	$K = \frac{ab \cdot \sin C}{2} = \frac{a^2 \cdot \sin B \cdot \sin C}{2 \cdot \sin A}$
a, b, A	B	$\sin B = \frac{b \cdot \sin A}{a}$
a, b, A	c	$c = \frac{a \cdot \sin C}{\sin A} = \frac{b \cdot \sin C}{\sin B}$ $c = \sqrt{a^2 + b^2 - 2ab \cdot \cos C}$
a, b, A	K	$K = \frac{ab \cdot \sin C}{2}$
a, b, C	A	$\tan A = \frac{a \cdot \sin C}{b - a \cdot \cos C}$
a, b, C	c	$c = \frac{a \cdot \sin(A+B)}{\sin A}$ $c = \sqrt{a^2 + b^2 - 2ab \cdot \cos C}$
a, b, C	K	$K = \frac{ab \cdot \sin C}{2}$

## Conversion Factors

Class	multiply:	by:	to get:
<b>Length</b>	in	0.0833	ft
	in	0.028	yd
	ft	12	in
	ft	0.33	yd
	ft	0.06	rods
	yd	36	in
	yd	3	ft
	yd	0.18	rods
	rods	198	in
	rods	16.5	ft
	rods	5.5	yd
	mi	5280	ft
	mi	1760	yd
	mi	320	rods
<b>Area</b>	in <sup>2</sup>	0.007	ft <sup>2</sup>
	ft <sup>2</sup>	144	in <sup>2</sup>
	ft <sup>2</sup>	0.11	yd <sup>2</sup>
	yd <sup>2</sup>	1296	in <sup>2</sup>
	yd <sup>2</sup>	9	ft <sup>2</sup>
	yd <sup>2</sup>	0.03	rods <sup>2</sup>
	rods <sup>2</sup>	272.25	ft <sup>2</sup>
	rods <sup>2</sup>	30.25	yd <sup>2</sup>
	acres	43560	ft <sup>2</sup>
	acres	4840	yd <sup>2</sup>
	acres	160	rods <sup>2</sup>

## Conversion Factors

Class	multiply:	by:	to get:
<b>Volume</b>	ft <sup>3</sup>	1728	in <sup>3</sup>
	ft <sup>3</sup>	0.04	yd <sup>3</sup>
	ft <sup>3</sup>	7.48	gallons
	yd <sup>3</sup>	27	ft <sup>3</sup>
	yd <sup>3</sup>	202	gallons
	quarts	2	pints
	quarts	0.25	gallons
	gallons	8	pints
	gallons	4	quarts
	gallons	0.13	ft <sup>3</sup>
<b>Force</b>	ounces	0.06	pounds
	pounds	16	ounces
	tons (short)	2000	pounds
	tons (metric)	2205	pounds
<b>Velocity</b>	miles/hr	88	ft/min
	miles/hr	1.47	ft/sec

## Metric Conversion Factors

Class	multiply:	by:	to get:
<b>Length</b>	in	25.40	mm
	in	2.540	cm
	in	0.0254	m
	ft	0.3048	m
	yd	0.9144	m
	mi	1.6093	km
<b>Area</b>	ft <sup>2</sup>	0.0929	m <sup>2</sup>
	yd <sup>2</sup>	0.8361	m <sup>2</sup>
	mi <sup>2</sup>	2.590	km <sup>2</sup>
<b>Volume</b>	in <sup>3</sup>	16.387	cm <sup>3</sup>
	ft <sup>3</sup>	0.0283	m <sup>3</sup>
	yd <sup>3</sup>	0.7646	m <sup>3</sup>
	gal	3.785	L
	gal	0.0038	m <sup>3</sup>
	fl oz	29.574	mL
	acre ft	1233.48	m <sup>3</sup>
<b>Mass</b>	oz	28.35	g
	lb	0.4536	kg
	kip (1000 lb)	0.4536	metric ton (1000 kg)
	short ton 2000 lb	907.2	kg
	short ton	0.9072	metric ton

## Land Surveying Conversion Factors

Class	multiply:	by:	to get:
Area	acre	4046.8726	m <sup>2</sup>
	acre	0.40469	ha 10000 m <sup>2</sup>
Length	ft	12/39.37*	m

\* Exact, by definition of the U.S. Survey foot

## Steel Tape Temperature Corrections

$$C = 11.66 \cdot 10^{-6} (T_C - 20) L_m$$

or

$$C = 6.45 \cdot 10^{-6} (T_F - 68) L_f$$

Where:

- C** = Correction
- T<sub>C</sub>** = Temperature in degrees Celsius
- L<sub>M</sub>** = Length in meters
- T<sub>F</sub>** = Temperature in degrees Fahrenheit
- L<sub>f</sub>** = Length in feet

## Temperature Conversion

Fahrenheit to Celsius      $\frac{5}{9} (^{\circ}\text{F} - 32)$

Celsius to Fahrenheit      $\left(\frac{9}{5} ^{\circ}\text{C}\right) + 32$

## Less Common Conversion Factors

Class	multiply:	by:	to get:
Density	lb/ft <sup>3</sup>	16.0185	kg/m <sup>3</sup>
	lb/yd <sup>3</sup>	0.5933	kg/m <sup>3</sup>
Pressure	psi	6894.8	Pa
	ksi	6.8948	MPa
	lb/ft <sup>2</sup>	47.88	Pa
Velocity	ft/s	0.3048	m/s
	mph	0.4470	m/s
	mph	1.6093	km/h

## Water Constants

Freezing point of water = 0° C (32° F)  
 Boiling point of water under pressure of one atmosphere = 100° C (212° F)  
 The mass of one cu. meter of water is 1000 kg  
 The mass of one liter of water is 1 kg (2.20 lbs)  
 1 cu. ft. of water @60° F = 62.37 lbs (28.29 kg)  
 1 gal of water @60° F = 8.3377 lbs (3.78 kg)

## Cement Constants

1 sack of cement (appx.) = 1 ft<sup>3</sup> = 0.028 m<sup>3</sup>  
 1 sack of cement = 94 lbs. = 42.64 kg  
 1 gallon water = 8.3453 lbs. @39.2° F  
 1 gallon water = 3.7854 kg @4° C

## Multiplication Factor Table

Multiple	Prefix	Symbol
1 000 000 000 = $10^9$	giga	G
1 000 000 = $10^6$	mega	M
1 000 = $10^3$	kilo	k
100 = $10^2$	*hecto	h
10 = $10^1$	*deka	da
0.1 = $10^{-1}$	*deci	d
0.01 = $10^{-2}$	*centi	c
0.001 = $10^{-3}$	milli	m
0.000 001 = $10^{-6}$	micro	$\mu$
0.000 000 001 = $10^{-9}$	nano	n

\* Avoid when possible

## Recommended Pronunciations

Prefix	Pronunciation
<b>giga</b>	jig'a (i as in <i>jig</i> , a as in <i>a</i> -bout)
<b>mega</b>	as in <i>mega</i> -phone
<b>kilo</b>	kill' oh
<b>hecto</b>	heck' toe
<b>deka</b>	deck' a (a as in <i>a</i> -bout)
<b>centi</b>	as in <i>centi</i> -pede
<b>milli</b>	as in <i>milli</i> -tary
<b>micro</b>	as in <i>micro</i> -phone
<b>nano</b>	nan' oh

## Reinforcing Steel

Bar Size	Nominal Diameter	Nominal Area	Unit Weight
#3	9.5mm [0.375 in]	71mm <sup>2</sup> [0.110 in <sup>2</sup> ]	0.560kg\m [0.376 lb\ft]
#4	12.7mm [0.500 in]	127mm <sup>2</sup> [0.197 in <sup>2</sup> ]	0.994kg\m [0.668 lb\ft]
#5	15.9mm [0.625 in]	199mm <sup>2</sup> [0.309 in <sup>2</sup> ]	1.552kg\m [1.043 lb\ft]
#6	19.1mm [0.750 in]	287mm <sup>2</sup> [0.445 in <sup>2</sup> ]	2.235kg\m [1.502 lb\ft]
#7	22.2mm [0.875 in]	387mm <sup>2</sup> [0.600 in <sup>2</sup> ]	3.045kg\m [2.044 lb\ft]
#8	25.4mm [1.000 in]	507mm <sup>2</sup> [0.786 in <sup>2</sup> ]	3.973kg\m [2.670 lb\ft]
#9	28.7mm [1.128 in]	647mm <sup>2</sup> [1.003 in <sup>2</sup> ]	5.060kg\m [3.400 lb\ft]
#10	32.3mm [1.270 in]	819mm <sup>2</sup> [1.270 in <sup>2</sup> ]	6.404kg\m [4.303 lb\ft]
#11	35.8mm [1.410 in]	1007mm <sup>2</sup> [1.561 in <sup>2</sup> ]	7.907kg\m [5.313 lb\ft]
#14	43.0mm [1.693 in]	1452mm <sup>2</sup> [2.251 in <sup>2</sup> ]	11.384kg\m [7.650 lb\ft]
#18	57.3mm [2.257 in]	2579mm <sup>2</sup> [3.998 in <sup>2</sup> ]	20.239kg\m [13.600 lb\ft]



## Notes

## Notes

# Acronyms and Abbreviations

AAH-	Adopt a Highway
ACP-	Asphaltic Concrete Pavement
BMP-	Best Management Practices
BST-	Bituminous Surface Treatment
DOE-	Department of Ecology
HPA-	Hydraulic Project Approval
IVM-	Integrated Vegetation Management
LOS-	Level of Service
MAP-	Maintenance Accountability Process
MDT-	Measuring Distributor Tank
MUTCD-	Manual on Uniform Traffic Control Devices
PCC-	Portland Cement Concrete
PDA-	Preliminary Damage Assessment
PTO-	Power Take Off
RCP-	Roadside Classification Plan
RPM-	Raised Pavement Marker
RWIS-	Roadway Weather Information System
VMS-	Variable Message Signs
WDFW-	Washington State Department of Fish & Wildlife
WSDA-	Washington State Department of Agriculture
WSDOT-	Washington State Department of Transportation
WSP-	Washington State Patrol



AAH administrative roles and responsibilities, 6-25  
Abandoned cargo, 1-7  
Abandoned or illegally parked vehicles, 7-6  
Accidents, Work Zone Traffic Control Guidelines  
Administration and logistics, 1-4  
Adopt-a-Highway, 6-22  
Advance warning, 2-5, Work Zone Traffic Control Guidelines  
Aggregate, Emergency Procedures Manual, 3-16, 3-17, 3-25  
Aggregate chip seal, 3-16  
Alligator cracking, 3-4  
Anti-Icing and deicing chemicals, 7-4  
Application, 8-7  
Application of asphalt, 3-24  
Area of responsibility, 7-4  
Arrow boards, Work Zone Traffic Control Guidelines  
Asphalt emulsion surface treatments, 3-15, 3-16  
Assignment of sections, 6-22  
Attenuator, Work Zone Traffic Control Guidelines, 8-8, 8-11  
Automatic pumps, 4-5  
Auxiliary facilities, 6-26  
Bank protection, 4-5  
Barriers, Work Zone Traffic Control Guidelines, 8-8  
Bicycle control, 2-13  
Biological control, 6-19  
Bituminous surface, Emergency Procedures Manual  
Blade mixed asphalt mix, 3-29  
Bridge repair guidelines, 5-4  
Budget, 10-10  
Buffer space, 2-5, Work Zone Traffic Control Guidelines  
Burning debris, 6-20  
Calibration procedures, 3-18  
Catch basins, Emergency Procedures Manual  
Changeable message sign, Work Zone Traffic Control Guidelines, 2-5  
Channelization, Work Zone Traffic Control Guidelines  
Channelizing devices, 2-6  
Checking the bitumeter, 3-23  
Chip seal, Work Zone Traffic Control Guidelines, 3-16, 3-17  
Chip spreader, 3-26  
Chipspreader calibration, 3-25  
City streets on the state highway system, 7-5, Ai-1  
Cleaning of distributor, 3-23  
Closure, Emergency Procedures Manual, Work Zone Traffic Control Guidelines, 7-6  
Cold pour method, 3-11  
Common types of emulsions used for chip seals, 3-17  
Concepts of operations, 1-3  
Cone placement process, 2-7  
Cones, Work Zone Traffic Control Guidelines

Construction projects, Emergency Procedures Manual  
Container disposal, 6-17  
Control devices, Emergency Procedures Manual, 2-6, Work Zone Traffic Control Guidelines  
Crack pouring, 3-12  
Crack sealing, Emergency Procedures Manual, 3-11  
Cultural control methods, 6-19  
Culverts, Emergency Procedures Manual, 4-4  
Danger trees, 6-14  
Delineation, 8-5  
Detention ponds, 4-6  
Detours, Emergency Procedures Manual  
Devices, 2-6, Work Zone Traffic Control Guidelines  
Disposal of logs dumped on right of way, 6-14  
Disposal of surplus items, 10-8  
Distributor, 3-18, 3-23  
Ditches and gutters, 4-3  
Documentation, 9-2  
Drain pump systems, 9-3  
Drainage, 4-1  
Drainage from abutting properties, 4-2  
Drainage ways, 7-5  
Dry wells, 4-4  
Edge raveling, 3-6  
Effects on traffic on a patching operation, 3-10  
Electrical system maintenance, 9-1  
Emergency assistance, 7-7  
Emergency operating procedures, 1-4  
Emergency operations, Work Zone Traffic Control Guidelines  
Emergency procedures, 1-1, Emergency Procedures Manual  
Emulsified asphalt, 3-30  
Encroachment, 6-15  
Enclosure maintenance, 9-2  
Enforcement, 2-14  
Environmental aspects, 5-4  
Environmental sensitivity, 10-11  
Equipment, Emergency Procedures Manual, Work Zone Traffic Control Guidelines, 3-18, 6-18, 10-8  
Maintenance and Operations Programs responsibilities, 6-25  
Field repair, 8-4  
Flagger, Work Zone Traffic Control Guidelines  
Flagging, Work Zone Traffic Control Guidelines  
Flashing arrow board, Work Zone Traffic Control Guidelines  
Flushing, 3-5  
Fog seal, 3-15  
Franchises and permits, 6-15  
Fundamental principles, 2-2  
Gate and barrier systems, 9-3  
General permits for roadside enhancement, 6-25  
Grader patching, 3-9  
Guardrail, Emergency Procedures Manual

- Guideposts, 8-8
- Hand signaling devices, 2-9
- Herbicides, Work Zone Traffic Control Guidelines
- Highway categories, 7-3
- Highway sign installations, 7-5
- Historical markers, 6-27
- Hot pour method, 3-11
- Ice control operations, 7-4
- Illegal tree removal, 6-20
- Illumination systems, 9-3
- Impact attenuators, 8-8, 8-11
- Inspection, 5-2, 8-4, 8-9
- Instructions for radio operation, 10-9
- Integrated vegetation management, 6-11
- Intersection control beacons, 9-3
- Inventoried items, 10-8
- Islands, 8-11
- Lane closures, Work Zone Traffic Control Guidelines, A1, A3-A4
- Level of service coordination, 7-5
- Litter control and partnerships for road enhancement, 6-21
- Load and speed restrictions, 3-4
- Longitudinal cracking, Work Zone Traffic Control Guidelines, 3-4
- Maintain, Emergency Procedures Manual, Work Zone Traffic Control Guidelines
- Maintenance accountability process (MAP), 6-6
- Maintenance field personnel, 1-5
- Maintenance involvement in the roadside management process, 6-5
- Maintenance of flexible pavements, 3-3
- Maintenance of rigid pavements, 3-12
- Maintenance of structures, 5-1
- Maintenance responsibilities in cities, 10-2
- Maintenance superintendent or supervisor, 1-6
- Maintenance yards, 10-7
- Major structures, 5-2
- Marking renewal or replacement frequency, 8-7
- Material selection, 3-16
- Materials, 8-7
- Materials from state quarries or pits, 10-8
- Material specifications, 10-8
- Minor structures, Emergency Procedures Manual, 5-2
- Mobile operations, Work Zone Traffic Control Guidelines
- Multiple lane closure, A2
- MUTCD, Work Zone Traffic Control Guidelines
- Nighttime activities, 2-11
- Non-inventoried items, 10-9
- Nonmotorized traffic control, 2-12
- Noxious weed control, 6-13
- Nozzle size, 3-19
- Off-road activities, 2-11
- Oil separators, 4-6

Operations at interchanges, 7-5  
Organization and assignment of responsibilities, 1-4  
Other cutting methods, 6-18  
Other governmental agencies, 7-6  
Overlay patches, 3-7  
Park and ride lots, 6-27  
Participant eligibility, 6-22  
Patching, Emergency Procedures Manual, Work Zone Traffic Control Guidelines, 3-6, 3-8, 3-10  
Patching with base repair, 3-6  
Paving deficiencies, 3-4  
Pavement, Emergency Procedures Manual, Work Zone Traffic Control Guidelines, 3-1  
Pavement conditions for a successful project, 3-16  
Pavement maintenance techniques, 3-6  
Pavement markings, Work Zone Traffic Control Guidelines, 8-5  
Pedestrian control, 2-12, A5  
Pedestrian detection and display system, 9-4  
Pedestrian facilities, 7-5  
Pedestrian traffic, Work Zone Traffic Control Guidelines, A5  
Pesticide license, 6-16  
Pesticide sensitive individuals, 6-17  
Pesticides, 6-16  
Plan development and maintenance, 1-4  
Portland conditions for a successful project, 3-16  
Posting requirements, 6-17  
Potholes, 3-5  
Precautions, 7-8  
Preparation for winter operations, 7-2  
Private approaches, 7-6  
Procurement of materials, 10-8  
Product labels, 6-17  
Program rules, 6-22  
Proper nozzle angle, 3-23  
Proper pressure, 3-19  
Railroad crossings, 7-5  
Raveling and pitting, 3-5  
Reconstruction principles, 8-2  
Record keeping, 6-17  
Region responsibilities, 6-26  
Regional emergency response plans, 1-3  
Regulatory signs, Work Zone Traffic Control Guidelines  
Removal of dangerous objects and structures, 6-14  
Removal of debris and rubbish, Emergency Procedures Manual, 10-2  
Removal of markings, 8-8  
Repair, Emergency Procedures Manual, Work Zone Traffic Control Guidelines, 3-1  
Reporting, 10-10  
Resources for traffic control and work zone safety, 2-14  
Right of way fences, 10-2  
Road approaches, Work Zone Traffic Control Guidelines



Roadside functions, 6-4  
Roadside maintenance and the maintenance accountability process, 6-6  
Roadside management, 6-1  
Roadside management zones, 6-7  
Roadside treatment, 6-5  
Roadway illumination systems, 9-3  
Roadway preparation, 3-17  
Rockfall ditches and slope benches, 4-4  
Rolling, Work Zone Traffic Control Guidelines 3-9, 3-27  
Rolling hot mix patches, 3-9  
Rutting, 3-4  
Safety, Emergency Procedures Manual, 2-1, 2-13  
Safety rest areas, 6-26  
Sags and humps, 3-6  
Sand seal, 3-15  
Scheduling, 10-10  
Seal coat, 3-28, 3-29  
Services, 9-4  
Sign control systems, 9-5  
Sign installation, Work Zone Traffic Control Guidelines, 8-3  
Sign lighting systems, 9-4  
Sign storage and transportation, 8-5  
Sign visibility, 8-5  
Signs and supports, 2-6  
Signal control systems, 9-5  
Signal systems, 9-4  
Significant roadside activities, 6-20  
Signing, Work Zone Traffic Control Guidelines, 8-3  
Signing responsibility, 8-3  
Snow and ice control, Emergency Procedures Manual, 7-1  
Snow control operations, 7-4  
Special criteria, 7-4  
Spinner shut-off, 7-5  
Sponsored adoptions, 6-24  
Spray bar height, 3-22  
Spreader box patching, 3-8  
Spreading aggregate, 3-25  
Spreading of fines, 3-27  
Sprinkler systems, 9-5  
Standard run of barrier, 8-9  
Standards, Emergency Procedures Manual, Work Zone Traffic Control Guidelines  
Streaking will occur, 3-23  
Stockpile sites, 10-7  
Storm sewers, 4-5  
Stormwater, Emergency Procedures Manual  
Tandem plowing, 7-5  
Television systems, 9-5

Temporary pavement marking, Work Zone Traffic Control Guidelines  
Terminal and anchors, 8-10  
Traffic barriers and impact attenuators, 8-8  
Traffic conditions, Work Zone Traffic Control Guidelines  
Traffic control, Emergency Procedures Manual, 2-12, 3-24, 8-1  
Traffic control and safety, 2-1  
Traffic control devices, Emergency Procedures Manual, 2-6, Work Zone Traffic Control Guidelines  
Traffic control plan, Work Zone Traffic Control Guidelines, A1-A5  
Traffic control procedures, 2-10  
Traffic control, Emergency Procedures Manual, 2-1  
Traffic control zones, 2-3  
Traffic services, 8-1  
Training and exercises, 1-4  
Transit vehicle stop zones, 8-11  
Transitions, 8-10  
Transverse cracking, 3-5  
Trespass and encroachment, 6-15  
Underdrains, 4-5  
Use of mowing equipment, 6-18  
Use of pesticides, 6-16  
Vegetation management, Emergency Procedures Manual, 6-11  
Vehicle detection systems, 9-4  
Vehicle display system, 9-4  
Viewpoints, 6-27  
Volunteer adoptions, 6-23  
Warning light, Work Zone Traffic Control Guidelines  
Warning signs, Work Zone Traffic Control Guidelines  
Washington State Patrol (WSP), Work Zone Traffic Control Guidelines  
Water and concrete barrier, 2-8  
Weather, Emergency Procedures Manual, Work Zone Traffic Control Guidelines, 3-17  
Widening, Emergency Procedures Manual, 7-5  
Wiring and Connection Maintenance, 9-2  
Work area, Emergency Procedures Manual, 2-5, Work Zone Traffic Control Guidelines  
Work on other roads and areas, 7-6  
Work on state highways, 7-4  
Work scheduling and reporting, 10-10  
Work zone operations, 2-13  
WSDOT disaster plan, 1-3